

INSTRUCTION MANUAL BLOCK MANIFOLD W4G2-SERIES

SERIAL TRANSMISSION TYPE

MW4G※2-T8D※
(APPLICABLE TO DeviceNet)

- Please read this instruction manual carefully before using this product, particularly the section describing safety.
- Retain this instruction manual with the product for further consultation whenever necessary.

For Safety Use

To use this product safely, basic knowledge of pneumatic equipment, including materials, piping, electrical system and mechanism is required (to the level pursuant to JIS B 8370 Pneumatic System Rules).

We do not bear any responsibility for accidents caused by any person without such knowledge or arising from improper operation.

Our customers use this product for a very wide range of applications, and we cannot keep track of all of them. Depending on operating conditions, the product may fail to operate to maximum performance, or cause an accident. Thus, before placing an order, examine whether the product meets your application, requirements, and how to use it.

This product incorporates many functions and mechanisms to ensure safety. However, improper operation could result in an accident. To prevent such accidents, read this operation manual carefully for proper operation.

Observe the cautions on handling described in this manual, as well as the following instructions:


PRECAUTIONS

- Incorrect address settings of serial transmission slave stations could cause the solenoid valve and the cylinder to malfunction.
- For operation of serial transmission slave stations, read the communication system operation manual carefully.
- Do not touch electric-wiring connections (exposed live parts): this will cause an electric shock. During wiring, keep the power off. Also, do not touch these live parts with wet hands.
- This product does not meet the surge immunity requirements specified in EN61000-4-5 for CE marking. Please provide appropriate protective measures against lightning surges on the device side.
- When the valve power is turned on (i.e., at power-up), the valve lamp may light up momentarily. However, the valve itself is not turned on or off as a result of this.

INDEX

MW4G※2-T8D※
Serial Transmission Type
Manual No. SM-303116-A

| | |
|--|----|
| 1. PRODUCT | |
| 1.1 General outline of the system | 3 |
| 1.2 Structure of the System | 4 |
| 1.3 Specifications | 5 |
| 1.4 External dimensions of solenoid valve | 8 |
| 1.5 Outside view of valve slave station | 11 |
| 1.6 Switches and LED indications | 12 |
| 1.7 Connection connector | 13 |
| 2. CAUTION | 14 |
| 3. OPERATION | |
| 3.1 Switch setting | 15 |
| 3.2 Correspondence between slave station input/output No. and PLC address No. | 17 |
| 3.3 Programming | 19 |
| 3.4 Device profile | 19 |
| 4. INSTALLATION | |
| 4.1 Installation | 24 |
| 4.2 Wiring | 26 |
| 5. MAINTENANCE | |
| 5.1 Disassembling and reassembling this product (slave station) | 30 |
| 5.2 Troubleshooting | 31 |
| 6. HOW TO ORDER | 32 |



1. PRODUCT

1. 1 General outline of the system

1) MW4G※2-T8D※

This product is a solenoid valve equipped with remote I/O station (NW4G※2-T8D※), which can be connected to Omron's CompoBus/D applicable to DeviceNet, an open field network, as well as Toyota Machine Works' DLINK.

The following features are provided.

- (1) It helps to curtail wiring man-hours as it requires DeviceNet cables only to connect it with PLC.
- (2) This slave station is an environment-proof slave station applicable to the protection structure IP65 (dust-proof and jet-proof type).
- (3) Upper and side wiring directions are provided, ensuring reduction of the installation space.
- (4) The power supply for the slave station is separated from that for the valve, ensuring easy maintenance work.
- (5) The slave station output status, if the communication error occurs, can be set using the switch (holding or all points OFF).
- (6) Three kinds of communication speed levels can be set. (125k / 250k / 500k bps)

2) What are DeviceNet , CompoBus/D and DLNK?

The DeviceNet ,CompoBus/D and DLNK configure a multi-vendor network of a multiple bit system where the control and information of the Machine/Line control level exist together. The DeviceNet is maintained and controlled by ODVA (Open DeviceNet Vendor Association) and the CompoBus/D and DLNK are used as a network to work with the DeviceNet.

Note: Be sure to read the User's Manual.

This manual mainly describes the MW4G ※ 2-T8D ※ and the slave station(NW4G※2-T8D※). Also, read the User's Manual for the master station and other slave stations to be connected to this system.

In addition, regarding the manifold solenoid valve, please read this manual and the above manuals carefully to fully understand the functions and performance of the product to be able to use it properly.


1. 2 Structure of the system


This system chiefly consists of PLC body, Master unit, Solenoid valve MW4G※
2-T8D※ and peripheral equipment.

- Combination of PLC and Master unit

| Mnufacturer | Compatible PLC | Type of Master unit |
|---|--|---|
| OMRON Co.,Ltd. | SYSMAC CS series SYSMAC CJseries SYSMAC CV series SYSMAC α series SYSMAC C200HS series others | CS1W-DRM21 CJ1W-DRM21 CVM1-DRM21-V1 C200HW-DRM21-V1 ITNC-EI□01-DRM (Master built-in PLC) 3G8B3-DRM21 (VME board) |
| TOYOTA KOHKI Co.,Ltd | PC3J / 2J series PC3JD PC2F / PC2FS | THK-5398 TIC-5642 (Master built-in PLC) TFU-5359 |
| Other equipment compatible with DeviceNet | | |

- Fundamental structure of system





1. 3 Specifications

1) Specification of solenoid valve

(1) Common specifications

| | | |
|-----------------------------------|--|--|
| Model No. | W4G2 | |
| Item | | |
| Media | Compressed air | |
| Valve configuration | Pilot operation | |
| Applicable solenoid valve | Soft spool valve | |
| Minimum working pressure MPa | 2 positions | 0.2 |
| | 3 positions | 0.2 |
| Maximum working pressure MPa | 0.7 | |
| Proof pressure MPa | 1.05 | |
| Ambient temperature °C | -5~55 | |
| Media temperature °C | 5~55 | |
| Manual override | Common (standard) for non-locked and locked types | |
| Pilot air exhaust method | Internal pilot | Common exhaust for main and pilot valves |
| | External pilot | Individual exhaust for main and pilot valves |
| Lubrication ※1 | Not required | |
| Protection rating ※2 | Dust proof and jet-proof (IP65) | |
| Vibration/Impact m/s ² | 49 or less / 249 or less | |
| Atmosphere | Operation in the presence of corrosive gas not allowed | |

※1 : If lubrication is required, use turbine oil ISO VG32 ,1st grade.

Excessive lubrication or intermittent lubrication may cause unstable operation.

※2 : Based on IP65 (IEC60529[IEC529 : 1989-11]) standard test method. The sealing ability must be checked before starting operation.

Reference The unit of the pressure is MPa. The conversion rate is "1MPa=10.1972kgf/cm²".

(2) Electrical specifications

| | | |
|---|-----------------|--|
| Model No. | W4G2 | |
| Item | | |
| Rated voltage V | DC24 | |
| The range of rated voltage fluctuation. | ±10% | |
| Holding current A | 0.025 | |
| Power consumption W | 0.6 | |
| Heat-proof class | B | |
| Surge absorber | Standard device | |
| Indicator | Standard | |

(3) Specifications by model

| Item | | | ON | OFF |
|---------------------|-------------|----------------|----|-----|
| Response time ms | 2 positions | Single | 22 | 24 |
| | | Double | 26 | — |
| | 3 positions | ABR connection | 25 | 35 |

The response time shown in the table is with the supply pressure of 0.5 MPa and at 20°C without lubrication. It changes depending on the supply pressure and the type of oil in the case of lubrication.

| Item | Valve specifications | | Change-over position class | P→A/B | A/B→R | |
|---|----------------------|--------------|----------------------------|----------------|--------|--------|
| Effective sectional area mm ² | Sole unit | W4GB2 | 2 positions | 13 | 13 | |
| | | | 3 positions | CC | 11 | 11 |
| | | | | ABR connection | 11 | 13 |
| | | | | PAB connection | 15 | 11 |
| | Manifold | MW4G2 series | 2 positions | 11 | 9 (12) | |
| | | | 3 positions | CC | 10 | 10 |
| | | | | ABR connection | 10 | 9 (12) |
| | | | | PAB connection | 12 | 10 |


- Values shown in () are those when the exhaust malfunction prevention valve is not installed.
- These values are obtained when the connecting diameter of the A·B port is $\phi 8$ push-in joint.

2) Transmission specifications

| Item | Specification | | | |
|--------------------------------|---|---------------------|--------------------|--------------------------|
| Communication protocol | Conforms to DeviceNet | | | |
| Transmission speed | 500k / 250k / 125k bps (selectable) | | | |
| Communication media | Private 5-wire cable(2wire for signal system, 2-wire for power source system, 1-wire for shield) | | | |
| Transmission distance | Transmission speed | Max. network length | Branch line length | Total branch line length |
| | 500k bps | 100m or less ※1 | 6m or less | 39m or less |
| | 250k bps | 250m or less ※1 | 6m or less | 78m or less |
| | 125k bps | 500m or less ※1 | 6m or less | 156m or less |
| Power source for communication | 11.0V~25.0V DC | | | |
| Error control | CRC error | | | |

※1 Indicates values when a thick private cable is used. The value is less than 100 mm in cases where a thin private cable is used.

Note: For details for communication, refer to DeviceNet specifications published by ODVA



(1) Specification of solenoid valve


Always operate this product within its product specifications.

| Item | T8D1 | T8D2 | T8D7 |
|---|---|--|--|
| Power voltage (Unit side) | DC21.6V~26.4V (DC24V ±10%) | | |
| Electric consumption (Unit side) | 70mA or lower (While all points are ON.) | 90mA or lower (While all points are ON.) | 80mA or lower (While all points are ON.) |
| Power voltage (Communication side) | DC11.0V~25.0V | | |
| Electric consumption (Communication side) | 50mA or lower | | |
| Power voltage (Valve side) | DC22.8V~26.4V (DC24V +10%, -5%) | | |
| Electric consumption (Valve side) | 15mA or lower (While all points are OFF.) | | |
| I/O point | 0/16 | 0/32 | 16/16 |
| Insulation resistance | Between all external terminals in a lump and Case 30MΩ or more DC500VM | | |
| Withstanding voltage | Between all external terminals in a lump and Case AC500V for 1 minute | | |
| noise proof | 500Vp-p Pulse width 100nsce, 1 μ sec | | |
| Vibration proof | Durability | 10~150~10Hz 1 octave/min. 15 sweeps in the 3 each axis of X, Y and Z while the half amplitude is 0.75mm or 98m/s ² whichever smaller. | |
| | Wrong operation | 10~150~10Hz 1 octave/min. 4 sweeps in the 3 each axis of X, Y and Z while the half amplitude is 0.5mm or 68.6m/s ² whichever smaller. | |
| Shock proof | 294m/s ² 3directions 3 times | | |
| Ambient temperature | -5~55°C | | |
| Ambient humidity | 30~85%RH (No dew fall) | | |
| Working environment | No corrosive gas | | |
| Communication object | In conformity with DeviceNet | | |
| Transfer rate | 500K/250K/125K bps (A desired connector type is selected using the DIP-switch). | | |
| Connector types | Micro connector | | |
| Output insulation type | Photo coupler insulation | | |
| Max. load current | 40mA /point | | |
| Leak current | 0.1mA or lower | | |
| Residual voltage | 0.5V or lower | | |
| Output type | NPN transistor open collector output | | |
| Fuse | Power supply for slave stations:24V 2A / Power supply for valve:24V 2A/ Power supply for communication : 24V 1A (not replaceable) | | |
| Action indicator | LED (Unit status, power supply for valves and communication status indicator only) | | |


1. 4 External dimensions of solenoid valve

1) Upper wiring type


- MW4GA2※0-T8D※



| No. | Name of parts |
|-----|-------------------------------|
| 1 | Input/Output block |
| 2 | Electric component block T8D※ |
| 3 | Masking plate |
| 4 | Valve block |
| 5 | Solenoid valve main body |
| 6 | Supply/exhaust block |
| 7 | End block R |




2) Side wiring type
 • MW4GB2※0-T8D※




| No. | Name of parts |
|-----|-------------------------------|
| 1 | Input/Output block |
| 2 | Electric component block T8D※ |
| 3 | Masking plate |
| 4 | Valve block |
| 5 | Solenoid valve main body |
| 6 | Supply/exhaust block |
| 7 | End block R |

3) Side wiring type MW4GZ2※0-T8D※



| No. | Name of parts |
|-----|-------------------------------|
| 1 | Input/Output block |
| 2 | Electric component block T8D※ |
| 3 | Masking plate |
| 4 | Valve block |
| 5 | Solenoid valve main body |
| 6 | Supply/exhaust block |
| 7 | End block R |

1. 5 Outside view of valve slave station




- ① Monitor lamp
The monitor lamp LED indicates the status of the slave station main body and network.
- ② Setting switches
These switches are used to set a station No., transmission speed, and an output of the slave station when the communication error occurs.
- ③ Switch cover
This switch cover protects the monitor lamp and setting switches.
- ④ Power supply connector (M12-connector, male-pin)
The unit power supply and valve power supply are connected to this connector.
- ⑤ Communication connector
The communication cable of the network is connected to this connector.

1. 6 Switches and LED Indications

1) Switch

The address, communication speed, and output in case of communication error are set for this slave station.

| Name of switch | Content of setting |
|--|---|
| NA switch No.1-No.6 (Setting switch of Node address) | A node address of the slave station is set in a range of 0 to 63. |
| DR switch No.7-8 (Setting switch of communication rate) | A communication speed with the master unit is set. |
| H/C switch No.10 (Setting switch of output mode) | It is selected whether the output is held (H) or cleared (C) if the communication error occurs. |



2) MS (Module status)•NS (Network status) LED indications

The statuses of this slave station and network are displayed. For details about LED indications, refer to the table below.

| MS LED | NS LED | Content | Note |
|------------|------------|---|--|
| Green ⊗ | Green ⊗ | The I/O communication is being performed. | The input/output data is being communicated between the master station and slave station. This is the normal status. |
| Green ⊗ | ● | Whether or not the node address is duplicated is being checked. | Waiting for completion of node address duplication check on master If only a specific slave station is in this status, restart the slave station after checking that the same communication speed is used. |
| Green ⊗ | Green ⊗ | Waiting for connection | Waiting for establishment of connection from the master |
| Red ⊗ | ● | Watch dog timer error | The watch dog timer error occurs in the slave station. Replace the slave station with a new one. |
| Red ⊗ | ● | The switch setting is incorrect. | The switch setting, such as DIP-switch is incorrect. After checking the switch settings, restart the slave station. |
| Green ⊗ | Red ⊗ | The node address is duplicated. | The node address is duplicated with that of the master unit. After the node address is set again so that it is not duplicated, restart the slave station. |
| Green ⊗ | Red ⊗ | Busoff detection | Busoff (The communication is stopped if the data error occurs frequently.) After checking the following items, restart the slave station. |
| Green ⊗ | Red ⊗ | Communication time-out | • Check that the communication speed of the master station is the same as that of the slave station. • Check that the cable length (trunk line/branch line) is correct. • Check if any cable has broken wiring or is loose. • Check that the terminating resistor is mounted only at both ends of the trunk line. • Check if large noise exists. |
| ● | ● | The power is not turned ON. | After checking that the address and communication speed are set correctly, turn ON the power. |

3) VALVE LED indications

| VALVE LED | Content |
|------------|------------------------|
| Green ⊗ | Valve power ON status |
| ● | Valve power OFF status |

※ ⊗ lighting ⊗ flashing ● light out

※ The VALVE LED can monitor the status only when the unit power is turned ON.


1. 7 Connection connector

The wiring to this slave station is connected using the water-proof connector as shown in the Fig.


1) Wiring

The power supply and communication cables are connected to this slave station using the water-proof connectors. Tighten the power supply and communication connectors completely by hand. (Proper tightening torque: 0.4 to 0.5N·m)


| Symbol | Terminal name | Function |
|--------|-------------------------------|---|
| ① | Communication connector (IN) | Connect the communication cable from the fore station. (Male pins) |
| ② | Communication connector (OUT) | Connect the communication cable to the aft station. (Female pins) |
| ③ | Power supply connector | Connect the unit power supply and valve power supply. (M12 connector) |



(1) Multi-drop connection and T-branch connection methods



| | | |
|--|-----------|--|
| | CAUTION : | <ul style="list-style-type: none"> ● Touching the electrical wiring connection part (bare live part) may cause an electric shock. Before starting the wiring work, always shut-down the power completely. Additionally, do not touch any electrically live part by wet hand. ● Pay special attention so that any tensile force or impact is not applied to the power cable and communication cable. Additionally, if the wiring distance is long, unexpected force due to own weight or shock may be applied, causing the unit to break. Therefore, to prevent such troubles, take appropriate measures, such as securing of the wires and cables to the machine. ● When connecting the signal lines by means of the T-branch method, always attach the water-proof cap supplied with this product to the connector on the OUT side. ● When connecting the signal lines by means of the multi-drop method, pay special attention so that the rating of the communication power current flowing through this slave station is 2A or less. |
|--|-----------|--|



2. CAUTION

- Refer to User's manual for the master station concerning to transmission delay time. The transmission delay within the entire system depends on the scan time achieved by the PLC unit and on other devices included in the network.
- Solenoid valve responding time, of course, varies depending on model.
It is advisable of referring to valve specification.
- As for OFF time, there is another delay factor of approx. 20ms due to flywheel diode being used for surge absorbing circuit to valve slave station.
- Connect the power supply cable and signal cable correctly within the specifications so that any incorrect wiring is not performed.
- Pay special attention so that any tensile force or impact is not applied to the power supply cable and signal cable.
- Before turning ON the power, make sure that the various connection cables and connectors are connected firmly.
- Disassembly, modification, and/or repair made by the customer may cause a trouble or malfunction. Never attempt to disassembly, modify, and/or repair the unit.
- Many precision devices are mounted inside the unit. Do not drop the unit or apply vibration or impact to the unit.
- If any connector is disconnected or connected with the electric power supplied, this may cause a trouble or malfunction. Do not disconnect or connect any connector with the electric power supplied.

3 OPERATION

3. OPERATION

3. 1 Switch setting


The setting switches are used to set three kinds of functions, node address, transmission speed, and output mode if the communication error occurs. Since the function may vary depending on the switch positions, always carefully check the switch positions during setup work.

1) Setting the node address

Set the node address of the slave station in the 0 to 63 range.

(It is not possible to set duplicated node addresses).

| Node address | Switch No. | | | | | |
|--------------|------------|-------|-------|-------|--------|--------|
| | 1 (1) | 2 (2) | 3 (4) | 4 (8) | 5 (16) | 6 (32) |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 1 | 1 | 0 | 0 | 0 | 0 | 0 |
| 2 | 0 | 1 | 0 | 0 | 0 | 0 |
| 3 | 1 | 1 | 0 | 0 | 0 | 0 |
| ⋮ | ⋮ | | | | | |
| 60 | 0 | 0 | 1 | 1 | 1 | 1 |
| 61 | 1 | 0 | 1 | 1 | 1 | 1 |
| 62 | 0 | 1 | 1 | 1 | 1 | 1 |
| 63 | 1 | 1 | 1 | 1 | 1 | 1 |



1 : ON
0 : OFF
Value() is indicated on the sheet.

Example) To set the node address to "50":

$$50 = 1 \cdot (0) + 2 \cdot (1) + 4 \cdot (0) + 8 \cdot (0) + 16 \cdot (1) + 32 \cdot (1)$$


According to the above formula, turn ON the switch Nos.6,5,and 2,and turn OFF other switches(Nos.4,3,and1).

※ T8D2 is Omron's PLC. For the fixed allocations (without configurator), two channels from the set address are shared.

2) Setting the Transmission Speed

Set the transmission speed for the master unit.

| Transmission speed | Switch No. | |
|--------------------|------------|---------|
| | 7 (DRO) | 8 (DR1) |
| 125 kbps | 0 | 0 |
| 250 kbps | 1 | 0 |
| 500 kbps | 0 | 1 |
| Cannot be set | 1 | 1 |



CAUTION :

Set the same transmission speed as that set for all nodes (master and slave stations) on the network. If the transmission speed is set incorrectly, slave stations with a transmission speed different from that of the master station cannot only be communicated, but also cause the communication error to occur in the communication between nodes with the correct transmission speed set.

3) Setting the Output mode

The output data status if the communication error occurs in this product is set as shown below.

| | Switch No.10 (H/C) | Content of setting |
|-------------|--------------------|--|
| HOLD (HLD) | 1 | Used to hold the output data in the status immediately before the data is output from the master station in case of a communication error. |
| CLEAR (CLR) | 0 | Used to clear to "0" all the output data from the master station in case of a communication error. |



CAUTION:

- If the switches are set with the power turned ON, the set contents may not be recognized correctly. Always set the switches with the slave station power(including the communication power) turned OFF.
- Tighten the switch cover screw with a specified tightening torque (0.3 to 0.4N·m). If the screw is tightened insufficiently, the protection structure may not be kept.
- Always close the switch cover except for the setting work. If the switch cover is opened, any foreign matter may enter the internal circuit through the cover opening, causing the product to malfunction or the cover to break. Additionally, great care should also be taken so that no foreign matter enters the inside during setting work.
- Setting switch has been precisely built. Disorderly handling may cause damage of switch. To set station number, never touch internal circuit printed board.

3. 2 Correspondence between slave station input/output No. and PLC address No.

1) PLC address correspondence table

This correspondence table describes an example based on Omron's PLC "SYSMAC α"-series used as typical model. Additionally, the table shows the conditions when the serial transmission slave station is set at "node address 1" and the fixed allocation (without configuration) is used.

| Exclusive output type | | | Allocated channels | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------------------------|-------------|--------------|---|----|----|----|----|----|----|----|-----|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|-----|-----|-----|-----|-----|----|
| | | | 51ch | | | | | | | | | | | | | | | | 52ch | | | | | | | | | | | | | | | |
| Type of slave station | Input block | Output block | Serial-transmission slave station I/O No. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 |
| T8D1 (16points output) | — | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 1 unit | s1 | s2 | s3 | s4 | s5 | s6 | s7 | s8 | s9 | s10 | s11 | s12 | s13 | s14 | s15 | s16 | | | | | | | | | | | | | | | | | |
| | 2 unit | | | | | | | | | | | | 1-0 | 1-1 | 1-2 | 1-3 | | | | | | | | | | | | | | | | | | |
| T8D2 (32points output) | — | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 1 unit | s1 | s2 | s3 | s4 | s5 | s6 | s7 | s8 | s9 | s10 | s11 | s12 | s13 | s14 | s15 | s16 | s17 | s18 | s19 | s20 | s21 | s22 | s23 | s24 | s25 | s26 | s27 | s28 | s29 | s30 | s31 | s32 | |
| | 2 unit | | | | | | | | | | | | 1-0 | 1-1 | 1-2 | 1-3 | 2-0 | 2-1 | 2-2 | 2-3 | 3-0 | 3-1 | 3-2 | 3-3 | | | | | | | | | | |
| | 3 unit | | | | | | | | | | | | 1-0 | 1-1 | 1-2 | 1-3 | 2-0 | 2-1 | 2-2 | 2-3 | 3-0 | 3-1 | 3-2 | 3-3 | 4-0 | 4-1 | 4-2 | 4-3 | | | | | | |
| 4 unit | | | | | | | | | | | | 1-0 | 1-1 | 1-2 | 1-3 | 2-0 | 2-1 | 2-2 | 2-3 | 3-0 | 3-1 | 3-2 | 3-3 | 4-0 | 4-1 | 4-2 | 4-3 | | | | | | | |

※For the T8D2 (32-point output), both allocated channels, 51ch and 52ch, are shared.

| Input/output mixed type | | | Allocated channels | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|-------------|--------------|---|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|------|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| | | | 351ch | | | | | | | | | | | | | | | | 51ch | | | | | | | | | | | | | | | |
| Type of slave station | Input block | Output block | Serial-transmission slave station I/O No. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 |
| T8D7 (16 points input / 16 point output) | 1 unit | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 1 unit | 1-0 | 1-1 | 1-2 | 1-3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 2 unit | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 1 unit | 1-0 | 1-1 | 1-2 | 1-3 | 2-0 | 2-1 | 2-2 | 2-3 | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3 unit | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 1 unit | 1-0 | 1-1 | 1-2 | 1-3 | 2-0 | 2-1 | 2-2 | 2-3 | 3-0 | 3-1 | 3-2 | 3-3 | | | | | | | | | | | | | | | | | | | | |
| | 4 unit | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 1 unit | 1-0 | 1-1 | 1-2 | 1-3 | 2-0 | 2-1 | 2-2 | 2-3 | 3-0 | 3-1 | 3-2 | 3-3 | 4-0 | 4-1 | 4-2 | 4-3 | | | | | | | | | | | | | | | | |

※A numeric value in the field of the input/output block shows the number of stations(connector No.) counted from the serial transmission slave station.


※One field by bold lines shows one input/output block.

▨ : Input block □ : Output block □ : Solenoid output

How to read the table

- ① Check the type of the serial transmission slave station to be used and the connection style of the input/output block.
- ② Read out the PLC address corresponding to each input/output point of the unit on the table.
 - (Example 1) <Style> Serial-transmission slave station: T8D1、Output block: 0 unit
 «Output point» 11th solenoid output ⇒ «Address» Allocated channels 51ch (Input/Output relay Nos.5110)
 - (Example 2) <Style> Serial-transmission slave station: T8D2、Output block: 3 units
 «Output point» No.1 of 2nd output block station ⇒ «Address» Allocated channels 52ch (Input/Output relay Nos.5209)
 - (Example 3) <Style> Serial-transmission slave station: T8D7、Input block: 2 units、Output block: 2 units
 «Input point» No.2 of 2nd input block station ⇒ «Address» Allocated channels 351ch (Input/Output relay Nos.35106)
 «Output point» No.3 of 3rd output block station ⇒ «Address» Allocated channels 51ch (Input/Output relay Nos.5111)

How to count the number of manifold stations.



2) Valve No. assignments corresponding to T8D※ solenoid output No. (Example)

※ The numbers in valve No. 1a, 2a, 2b... indicate the station No.1 station No.2 and so on, while the alphabets (a) and (b) mean, respectively the solenoid on the side (a) and the solenoid on the side (b). The maximum number of stations on the manifold differs among the models. Refer to the specifications of the model you selected.

<Standard wiring>

● For single solenoid valve (Corresponds with up to the 16th manifold block.)

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--------------------|----|----|----|----|----|----|----|----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|--|--|
| Solenoid output No | s1 | s2 | s3 | s4 | s5 | s6 | s7 | s8 | s9 | s10 | s11 | s12 | s13 | s14 | s15 | s16 | s17 | s18 | s19 | s20 | s21 | s22 | s23 | s24 | s25 | s26 | s27 | s28 | s29 | s30 | s31 | s32 | | |
| Valve No | 1a | 2a | 3a | 4a | 5a | 6a | 7a | 8a | 9a | 10a | 11a | 12a | 13a | 14a | 15a | 16a | | | | | | | | | | | | | | | | | | |

● For double solenoid valve

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--------------------|----|----|----|----|----|----|----|----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Solenoid output No | s1 | s2 | s3 | s4 | s5 | s6 | s7 | s8 | s9 | s10 | s11 | s12 | s13 | s14 | s15 | s16 | s17 | s18 | s19 | s20 | s21 | s22 | s23 | s24 | s25 | s26 | s27 | s28 | s29 | s30 | s31 | s32 |
| Valve No | 1a | 1b | 2a | 2b | 3a | 3b | 4a | 4b | 5a | 5b | 6a | 6b | 7a | 7b | 8a | 8b | 9a | 9b | 10a | 10b | 11a | 11b | 12a | 12b | 13a | 13b | 14a | 14b | 15a | 15b | 16a | 16b |

● For mixed installation of single and double solenoid valve stations

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--------------------|----|----|----|----|----|----|----|----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|--|
| Solenoid output No | s1 | s2 | s3 | s4 | s5 | s6 | s7 | s8 | s9 | s10 | s11 | s12 | s13 | s14 | s15 | s16 | s17 | s18 | s19 | s20 | s21 | s22 | s23 | s24 | s25 | s26 | s27 | s28 | s29 | s30 | s31 | s32 | |
| Valve No | 1a | 2a | 3a | 3b | 4a | 4b | 5a | 6a | 7a | 7b | 8a | 9a | 10a | 10b | 11a | 11b | 12a | 13a | 14a | 14b | 15a | 15b | 16a | | | | | | | | | | |

<Double wiring>

● For single solenoid valve

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--------------------|----|----|----|----|----|----|----|----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Solenoid output No | s1 | s2 | s3 | s4 | s5 | s6 | s7 | s8 | s9 | s10 | s11 | s12 | s13 | s14 | s15 | s16 | s17 | s18 | s19 | s20 | s21 | s22 | s23 | s24 | s25 | s26 | s27 | s28 | s29 | s30 | s31 | s32 |
| Valve No | 1a | ※1 | 2a | ※1 | 3a | ※1 | 4a | ※1 | 5a | ※1 | 6a | ※1 | 7a | ※1 | 8a | ※1 | 9a | ※1 | 10a | ※1 | 11a | ※1 | 12a | ※1 | 13a | ※1 | 14a | ※1 | 15a | ※1 | 16a | ※1 |

● For double solenoid valve

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--------------------|----|----|----|----|----|----|----|----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Solenoid output No | s1 | s2 | s3 | s4 | s5 | s6 | s7 | s8 | s9 | s10 | s11 | s12 | s13 | s14 | s15 | s16 | s17 | s18 | s19 | s20 | s21 | s22 | s23 | s24 | s25 | s26 | s27 | s28 | s29 | s30 | s31 | s32 |
| Valve No | 1a | 1b | 2a | 2b | 3a | 3b | 4a | 4b | 5a | 5b | 6a | 6b | 7a | 7b | 8a | 8b | 9a | 9b | 10a | 10b | 11a | 11b | 12a | 12b | 13a | 13b | 14a | 14b | 15a | 15b | 16a | 16b |

● For mixed installation of single and double solenoid valve stations

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--------------------|----|----|----|----|----|----|----|----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Solenoid output No | s1 | s2 | s3 | s4 | s5 | s6 | s7 | s8 | s9 | s10 | s11 | s12 | s13 | s14 | s15 | s16 | s17 | s18 | s19 | s20 | s21 | s22 | s23 | s24 | s25 | s26 | s27 | s28 | s29 | s30 | s31 | s32 |
| Valve No | 1a | ※1 | 2a | ※1 | 3a | 3b | 4a | 4b | 5a | ※1 | 6a | ※1 | 7a | 7b | 8a | ※1 | 9a | ※1 | 10a | ※1 | 11a | 11b | 12a | 12b | 13a | ※1 | 14a | ※1 | 15a | 15b | 16a | ※1 |

※1 : Not used

3. 3 Programming

This slave station shares one node and is handled as 16-point output unit, T8D1, 32-point output unit, T8D2, or 16-point input/16-point output unit, T8D7. When creating a program refer to the User's Manual(programming section)prepared by the PLC manufacturer.

Note) 32-point output unit, T8D2, shares the memory for two nodes when using the fixed allocation (without configurator). For details about memory allocations, refer to section 3.2, Correspondence between slave station input/output No. and PLC address No. (on page 16).

3. 4 Device Profile

When connecting to a master station other than that made by OMRON Corporation, ensure you understand the following device profile before use.

Device Profile

| | | | |
|---------------------------|---|---|-----------------|
| General Device Data | Conforms to DeviceNet Specification | Volume I - Release 2.0 Volume II - Release 2.0 | Errata4 |
| | Vendor Name | CKD Corporation | Vendor ID = 201 |
| | Device Profile Name | Slave : Generic | Profile No. = 0 |
| | Product Catalog Number | Manual Number (SM-303116) | |
| | Product Revision | 10.7 | |
| Physical Conformance Data | Network power Consumption | DC24V 50mA or lower | |
| | Connector Style | Shield type micro connector | |
| | Isolated Physical Layer | YES | |
| | LEDs Supported | Module, Network | |
| | MAC ID Setting | DIP Switch | |
| | Default MAC ID | 1 | |
| | Communication Rate Setting | DIP switch | |
| Communication Data | Communication Rates Supported | 125kbit/s, 250kbit/s, 500kbit/s | |
| | Predefined Master/Slave Connection Set | Server for group 2 only | |
| | Dynamic Connections Supported (UCMM) | NO | |
| | Fragmented Explicit Messaging Implemented | YES | |
| | | Timeout : 2000ms | |
| | | Normal object class : 0x01 | |
| Instance: 1 | | | |
| Attributes: 7 | | | |

DeviceNet Required Object Implementation

- Identity Object (0x01)

| | | |
|--------------|------------|----------------|
| Object Class | Attributes | None Supported |
| | Services | None Supported |

| Object Instance | Attributes | ID Description | Get | Set | Value limit | | |
|-----------------|---------------------------|----------------|-------------------|------------|-------------|------------|------|
| | | | | | T8D1 | T8D2 | T8D7 |
| | | 1 | Vendor | ○ | × | 201 | 201 |
| 2 | Device type | ○ | × | 0 | 0 | 0 | |
| 3 | Product code | ○ | × | 50 | 51 | 52 | |
| 4 | Revision | ○ | × | 10.7 | 10.7 | 10.7 | |
| 5 | Status(bits supported) | ○ | × | bit 0 only | bit 0 only | bit 0 only | |
| 6 | Serial number | ○ | × | Every unit | Every unit | Every unit | |
| 7 | Product name | ○ | × | OPP5-1D | OPP5-2D | OPP5-7D | |
| 8 | State | × | × | | | | |
| 9 | Config. Consistency Value | × | × | | | | |
| 10 | Heartbeat Interval | × | × | | | | |
| Services | DeviceNet Services | | Parameter Options | | | | |
| | 05H Reset | | NO | | | | |
| | 0EH Get_Attribute_Single | | NO | | | | |

- Message Router Object (0x02)

| | | |
|---------------------------|------------|----------------|
| Object Class | Attributes | None Supported |
| | Service | None Supported |
| Object Instance | Attributes | None Supported |
| | Services | None Supported |
| Vendor Specific Additions | | NO |

- DeviceNet Object (0x03)

| Object Class | Attributes | ID Description | Get | Set | Value limit |
|--------------|-------------------------------|----------------|-------------------|-----|-------------|
| | | 1 | Revision | ○ | × |
| 2 | Max instance | × | × | | |
| 3 | Number of instances | × | × | | |
| 4 | Optional attribute list | × | × | | |
| 5 | Optional service list | × | × | | |
| 6 | Max ID class attributes | × | × | | |
| 7 | Max ID of instance attributes | × | × | | |
| Services | DeviceNet Services | | Parameter Options | | |
| | 0EH Get_Attribute_Single | | NO | | |

| Object Instance | Attributes | ID Description | Get | Set | Value limit |
|-----------------|---------------------------------|----------------|-------------------|-----|-------------|
| | | 1 | MAC ID | ○ | × |
| 2 | Baud rate | ○ | × | | |
| 3 | BOI | ○ | × | 00H | |
| 4 | Bus-off counter | × | × | | |
| 5 | Allocation information | ○ | × | | |
| 6 | MAC ID switch changed | × | × | | |
| 7 | Baud rate switch changed | × | × | | |
| 8 | MAC ID switch value | × | × | | |
| 9 | Baud rate switch value | × | × | | |
| Services | DeviceNet services | | Parameter Options | | |
| | 0EH Get_Attribute_Single | | NO | | |
| | 10H Set_Attribute_Single | | NO | | |
| | 4BH Allocate M/S connection set | | NO | | |
| | 4CH Release M/S connection set | | NO | | |

3
OPERATION

● Assembly Object (0x04)

| | | |
|--------------|------------|----------------|
| Object Class | Attributes | None Supported |
| | Services | None Supported |

| | | | | | | |
|-----------------|------------|--------------------------|---------------------------|-------------------|-----|-------------|
| Object Instance | | Instance Type | | Instance Id (s) | | |
| | | Static Input | | × | | |
| | | Static Output | | × | | |
| | | Static I/O | | ○ | 100 | |
| | | Static Configuration | | × | | |
| | | Dynamic | | × | | |
| | Attributes | ID description | | Get | Set | Value limit |
| | | 1 | Number of members in list | × | × | |
| | | 2 | Member list | × | × | |
| | | 3 | Data | ○ | × | |
| | Services | DeviceNet Services | | Parameter Options | | |
| | | 0EH Get_Attribute_Single | | NO | | |

● Connection Object (0x05)

| | | |
|--------------|-----------------------------------|----------------|
| Object Class | Attributes | None Supported |
| | Services | None Supported |
| | Total active connections possible | 1 |

| | | | | | | |
|--------------------------|--------------------|------------------|---------------------------------|-----|-------------------|-------------|
| Object Instance 1 | Section | Information | Max. instances | | | |
| | Instance type | Explicit Message | 1 | | | |
| | Production trigger | Cyclic | | | | |
| | Transport type | Server | | | | |
| | Transport class | 3 | | | | |
| | Attributes | ID description | | Get | Set | Value limit |
| | | 1 | State | ○ | × | |
| | | 2 | Instance type | ○ | × | 00H |
| | | 3 | Transport class trigger | ○ | × | 83H |
| | | 4 | Produced connection ID | ○ | × | |
| | | 5 | Consumed connection ID | ○ | × | |
| | | 6 | Initial comm. Characteristics | ○ | × | 21H |
| | | 7 | Produced connection size | ○ | × | 1200H |
| | | 8 | Consumed connection size | ○ | × | 1200H |
| | | 9 | Expected packet rate | ○ | ○ | |
| | | 12 | Watchdog time-out action | ○ | × | 01 |
| | | 13 | Produced connection path length | ○ | × | 00 |
| | | 14 | Produced connection path | ○ | × | |
| | | 15 | Consumed connection path length | ○ | × | 00 |
| | | 16 | Consumed connection path | ○ | × | |
| | | 17 | Production inhibit time | ○ | × | 00 |
| | | Services | DeviceNet Services | | Parameter Options | |
| | 05H Reset | | NO | | | |
| 0EH Get_Attribute_Single | | | NO | | | |
| 10H Set_Attribute_Single | | | NO | | | |

| | | | | | | | |
|-----------------------------|--------------------------|------------------------------------|--------------------------|-------------------|-------------------|-------------------|-------------------|
| Object Instance 2 | Section | Information | Max. number of instances | | | | |
| | Instance type | Polled I/O | 1 | | | | |
| | Production trigger | Cyclic | | | | | |
| | Transport type | Server | | | | | |
| | Transport class | 2 | | | | | |
| | Attributes | ID description | Get | Set | Value limit | | |
| | | | | | T8D1 | T8D2 | T8D7 |
| | | 1 State | ○ | × | | | |
| | | 2 Instance type | ○ | × | 01H | 01H | 01H |
| | | 3 Transport class trigger | ○ | × | 82H | 82H | 82H |
| | | 4 Produced connection ID | ○ | × | | | |
| | | 5 Consumed connection ID | ○ | × | | | |
| | | 6 Initial comm. Characteristics | ○ | × | 01H | 01H | 01H |
| | | 7 Produced connection size | ○ | × | 0000H | 0000H | 0200H |
| | | 8 Consumed connection size | ○ | × | 0200H | 0400H | 0200H |
| | | 9 Expected packed rate | ○ | × | | | |
| | | 12 Watchdog time-out action | ○ | × | | | |
| | | 13 Produced connection path length | ○ | × | 00 | 00 | 06 |
| | | 14 Produced connection path | ○ | × | – | – | 20_04_24_01_30_03 |
| | | 15 Consumed connection path length | ○ | × | 06 | 06 | 06 |
| 16 Consumed connection path | | ○ | × | 20_04_24_01_30_03 | 20_04_24_01_30_03 | 20_04_24_01_30_03 | |
| 17 Production inhibit time | | ○ | × | 00 | 00 | 00 | |
| Services | DeviceNet services | | Parameter Options | | | | |
| | 05H Reset | | NO | | | | |
| | 0EH Get_Attribute_Single | | NO | | | | |
| | 10H Set_Attribute_Single | | NO | | | | |

3
OPERATION

| | | | | | | | |
|-----------------------------|--------------------------|------------------------------------|--------------------------|-------------------|-------------------|-------------------|-------------------|
| Object Instance 3 | Section | Information | Max. number of instances | | | | |
| | Instance type | Bit Strobed I/O | 1 | | | | |
| | Production trigger | Cyclic | | | | | |
| | Transport type | Server | | | | | |
| | Transport class | 2 | | | | | |
| | Attributes | ID description | Get | Set | Value | | |
| | | | | | T8D1 | T8D2 | T8D7 |
| | | 1 State | ○ | × | | | |
| | | 2 Instance type | ○ | × | 01H | 01H | 01H |
| | | 3 Transport class trigger | ○ | × | 82H | 82H | 82H |
| | | 4 Produced connection ID | ○ | × | | | |
| | | 5 Consumed connection ID | ○ | × | | | |
| | | 6 Initial comm. Characteristics | ○ | × | 01H | 01H | 01H |
| | | 7 Produced connection size | ○ | × | 0000H | 0000H | 0200H |
| | | 8 Consumed connection size | ○ | × | 0100H | 0100H | 0100H |
| | | 9 Expected packed rate | ○ | × | | | |
| | | 12 Watchdog time-out action | ○ | × | | | |
| | | 13 Produced connection path length | ○ | × | 00 | 00 | 06 |
| | | 14 Produced connection path | ○ | × | — | — | 20_04_24_01_30_03 |
| | | 15 Consumed connection path length | ○ | × | 06 | 06 | 06 |
| 16 Consumed connection path | | ○ | × | 20_04_24_01_30_03 | 20_04_24_01_30_03 | 20_04_24_01_30_03 | |
| 17 Production inhibit time | | ○ | × | 00 | 00 | 00 | |
| Services | DeviceNet Services | | Parameter Options | | | | |
| | 05H Reset | | None | | | | |
| | 0EH Get_Attribute_Single | | None | | | | |
| | 10H Set_Attribute_Single | | None | | | | |

4. INSTALLATION

4. 1 Installation

⚠ WARNING : When installing a solenoid valve unit, never attempt to hold it in position by means of the pipes connected to it.


- Mount the solenoid valve by applying the mounting screws and/or mounting plate to the solenoid valve.

⚠ CAUTION : If you choose to mount the solenoid valve manifold on a DIN rail, make sure that the DIN rail is strong enough.

4.1.1 Please secure an enough space around the solenoid valve for mounting, dismounting and piping work.

4.1.2 In case of installing directly


Mount the master station on the mounting hole by using the screw. (M5 screw, appropriate tightening torque: 1.2N·m) For the mounting hole pitch, see section 1.4, External dimensions of solenoid valve. (P8~10)



4 INSTALLATION


4.1.3 In case of installing by means of DIN rail

For W4G2 Series, you can change the manifold of direct mounting type to DIN rail mounting type. If not counted properly, dropping down of the manifold or damage to it may be caused, to which please pay your careful attention. In addition, in case of the gross weight of manifold exceeding 1.0kg or it is installed in an environment where vibration or shock occurs, fix DIN rail to the mounting face with a distance of 50 – 100mm. Make sure that the installation has been carried out completely and then start using. There is no restriction to the mounting direction or mounting posture, but the mounting screws may become loose due to resonance with any vibration which may cause the manifold to drop down. Please pay your careful attention to this point when operating.




● How to mount DIN rail

1. Fit the fixtures for mounting DIN rail (Tightening torque: 1.8 – 2.3N·m)
 2. Hook the jaws on DIN rail in the order of ① and ②.
 3. Push toward ③ direction.
 4. Tighten the screws for fixing DIN rail.
- (Tightening torque: 1.2 – 1.6N · m)



4. 2 Wiring

In order for the MW4G※2-T8D※ to function, it is necessary to connect the communication line(device net cable) and the power line. If these lines are not properly connected, the MW4G※2-T8D※ may not only function improperly but may also cause serious problems to other equipment being used at the same time. Read both this manual and each User's Manual for the PLC and other units before use, and connect them properly.

| | | |
|---|------------------------|---|
|  | <p>CAUTION:</p> | <ul style="list-style-type: none"> ● Touching the electrical wiring connection part (bare live part) may cause an electric shock. Before starting the wiring work, always shut-down the power completely. Additionally, do not touch any electrically live part by wet hand. ● Pay special attention so that any tensile force or impact is not applied to the power cable and communication cable. Additionally, if the wiring distance is long, unexpected force due to own weight or shock may be applied, causing the unit to break. Therefore, to prevent such troubles, take appropriate measures, such as securing of the wires and cables to the machine. |
|---|------------------------|---|

1) Communication line

This system uses a private DeviceNet cable as the communication line.
The following are the recommended cables.


| Model | Specification | Manufacturer |
|-----------------|-------------------------------|-------------------------------|
| Model DCA2-5C10 | Thick cable, 5-wire, 100m | OMRON |
| Model DCA1-5C10 | Thin cable, 5-wire, 100m | OMRON |
| TDN18-10G | Thick cable, 5-wire, 10m | Showa Electric Wire and Cable |
| TDN18-30G | Thick cable, 5-wire, 30m | Showa Electric Wire and Cable |
| TDN18-50G | Thick cable, 5-wire, 50m | Showa Electric Wire and Cable |
| TDN18-100G | Thick cable, 5-wire, 100m | Showa Electric Wire and Cable |
| TDN18-300G | Thick cable, 5-wire, 300m | Showa Electric Wire and Cable |
| TDN18-500G | Thick cable, 5-wire, 500m | Showa Electric Wire and Cable |
| TDN24-10G | Thin cable, 5-wire, 10m | Showa Electric Wire and Cable |
| TDN24-30G | Thin cable, 5-wire, 30m | Showa Electric Wire and Cable |
| TDN24-50G | Thin cable, 5-wire, 50m | Showa Electric Wire and Cable |
| TDN24-100G | Thin cable, 5-wire, 100m | Showa Electric Wire and Cable |
| TDN24-300G | Thin cable, 5-wire, 300m | Showa Electric Wire and Cable |
| TDN24-500G | Thin cable, 5-wire, 500m | Showa Electric Wire and Cable |
| 1485C-P1-A50 | Thick cable, 5-wire, 50m | Allen-Bradly |
| 1485C-P1-C150 | Thin cable, 5-wire, 5 線, 150m | Allen-Bradly |

4 INSTALLATION


2) Communication line

When connecting the DeviceNet cable to this product, follow the steps below.

- ① Turn OFF the unit power and communication power to this slave station.
- ② Connect the DeviceNet cable to the communication connector as described in the following pin assignments.
- ③ Connect the communication cable from the fore station to the IN side and the communication cable to the aft station to the OUT side as shown in the wiring diagram.
- ④ Tighten the connector to the communication connector of the slave station completely by hand.



| Pin No. | Terminal name | Connection object | Indication cable color |
|---------|---------------|--|------------------------|
| 1 | Drain | Shield line of cable | — |
| 2 | V+ | Use a DC11 to 25V power supply with less noise. | Red |
| 3 | V- | Use a DC11 to 25V power supply with less noise. | Black |
| 4 | CAN_H | Connect to the communication cable "CAN_H" of the master or other slave station. | White |
| 5 | CAN_L | Connect to the communication cable "CAN_L" of the master or other slave station. | Blue |




Recommended connector Manufacturer : OMRON Corp.
 Connector with cable attached to both sides : Model DCA1-5CN※※W1 (Socket/Plug)
 Connector with cable attached to one side, For IN side : Model DCA1-5CN※※F1 (Socket)
 For OUT side : Model DCA1-5CN※※H1 (Plug)

※ Do not use any L-type connector.


3) Power line wiring

In NW4G※2·T8D※, the unit power supply is separated from the valve power supply. Additionally, each power supply is connected by using the sensor connector (M12). The following shows examples of each power supply connections.


(1) When the common power supply is used for the unit power supply and valve power supply:



(2) When only the valve power supply is turned ON or OFF:



(3) When the unit power supply is separated from the valve power supply:




4 INSTALLATION

Power cable (4-pole for DC)

Follow the steps below to connect the power cable to this product.

- ① After checking the safety, turn OFF the power supply to be connected to the slave station.
- ② Check the following pin assignments and connect the slave station power supply and valve power supply to the power cable.
- ③ Connect the connector to the power connector on the slave station, and then tighten it firmly by hand.



| Pin No. | Signal name | Remarks |
|---------|-------------|--|
| 1 | 24V | Positive(+) side of unit power supply |
| 2 | V | Positive(+) side of valve power supply |
| 3 | 0V | Positive(-) side of unit power supply |
| 4 | G | Positive(-) side of valve power supply |

<Recommended connectors>

Connector with cable : Model XS2F-D421-※ (one-side connector socket)

L-type connector with cable : Model XS2F-D422-※ (one-side connector socket)

⚠ CAUTION:


- For the signal line, be sure to use the cable conforming to the DeviceNet specification.
- Run the communication cable far from the power and high voltage lines.
- If the OUT connector is not used, always tighten the water-proof cap completely by hand.
- Run the communication cable with a sufficient bending radius so that it is not bent forcibly.
- Always tighten the connector firmly by hand. (Appropriate tightening torque: 0.4 to 0.5N·m)
- After checking the polarities and rated voltage carefully, perform the connections.
- Select a power cable after calculating the current consumption.
- When designing the system to supply power to duplex number of slave stations and remote I/O stations, choose and wire the source of power cord with a consideration of voltage drop.
- Secure ample voltage within rating by providing dual wiring, if necessary, to keep as small voltage loss of single system as possible or installing source of power near-by solenoid.
- To avoid any problems due to noise, observe the following when wiring:
 - ① If it is predicted that the noise may affect, provide a power source for every manifold solenoid valve wherever possible, and provide wiring individually.
 - ② Minimize the wiring distance whenever possible.
 - ③ Do not share a common power source with equipment such as an inverter or motor, etc. which can be a possible source of noise.
 - ④ Do not wire the power line and signal line in parallel with another power line.

5. MAINTENANCE

5. 1 Disassembling and reassembling this product (slave station)

- Slave station(NW4G※2-T8D※)

- (1) Loosen the fixing screws on DIN rail of retainer.
 - (2) Remove the hexagon socket bolts (2 bolts).
 - (3) Separate the serial transmission blocks and pull out the tie rod.
 - (4) Pass the serial transmission block through the tie rod and push it between the adjacent blocks without leaving any clearance and then connect.
 - (5) Make sure that all blocks have been connected without leaving any clearance, and then tighten the hexagon socket bolts.
 - (6) Hook the retainer jaw on DIN rail securely, push in the direction of arrow indicated on the retainer and tighten the fixing screws of DIN rail.
- (Proper tightening torque: 1.1 - 1.3N·m)
- (Proper tightening torque: 1.2 - 1.6N·m)



CAUTION:

- Before turning the unit power ON, check the slave station address, transfer rate and output setting during abnormal communication.
- Avoid pulling out the slave station while pulling the cable or connector; otherwise, broken circuit and damage may result.
- Touching the electrical wiring connection part (bare live part) may cause an electric shock.

5. 3 Troubleshooting

Troubleshooting should address the entire system rather than a particular slave station. This slave station shows the LED indications in conformity with the DeviceNet specifications. If an error occurs, check the contents of the error according to the LED indications of the slave station and the display of the master unit, and take appropriate corrective actions. If only this LED is off, check the voltage of the power supply to the valve power and the fuse.


1) Abnormalities and corrective actions related to the slave station are shown below.

| MS LED | NS LED | Description | | Remarks |
|------------|------------|--|---|--|
| Green ⊗ | Green ⊗ | I/O being communicated | I/O data being communicated between the master station and slave station. | This is the normal status. |
| Green ⊗ | ● | Node address duplication being checked | Waiting for completion of the node address overlap check by the master station. | In case only a specific slave station is in this state, check that the transmission speed is the same, and restart the slave station. |
| Green ⊗ | Green ⊗ | Waiting for connection | State of waiting for established connection from the master station. | |
| Red ⊗ | ● | Watch dog timer fault | Watch dog timer fault occurred in the slave station. | Replace the slave station. |
| Red ⊗ | ● | Incorrect switch setting | Setting of switch, such as dip switch, is incorrect. | Check for proper switch setting, and restart the slave station. |
| Green ⊗ | Red ⊗ | Node address duplication | Master unit and node address overlap. | Reset the master station while preventing the node address from overlapping, and restart the slave station. |
| Green ⊗ | Red ⊗ | Busoff detected | Busoff status (communication stopped due to frequent data error) | Check the following items and restart the slave station. <ul style="list-style-type: none"> • Check that the transmission speed of the master/slave stations is the same. • Check for proper cable length(main line/branch line). • Check for broken or loose cables. • Check that termination resistance exists only on both ends of the main line. • Check for frequent noise. |
| Green ⊗ | Red ⊗ | Communication time out | | Check the following items and restart the slave station. <ul style="list-style-type: none"> • Check that the transmission speed of the master/slave stations is the same. • Check for proper cable length(main line/branch line). • Check for broken or loose cables. • Check that termination resistance exists only on both ends of the main line. • Check for frequent noise. |

⊗: lighting ⊗: flashing ●: light out

2) VALVE LED Indication

| VALVE LED | Description |
|------------|-----------------------|
| Green ⊗ | Valve power ON status |




| | |
|--|------------------------|
| | Valve power OFF status |
|--|------------------------|

6
HOW TO ORDER

6. HOW TO ORDER

- Manifold



| (a) No. of port | | (b) Piping direction | | (c) Series model | | (d) Operator type | |
|-----------------|--------------|----------------------|----------------------------|------------------|-------------|-------------------|-----------------------|
| Code | Description | Code | Description | Code | Description | Code | Description |
| 3 | 3 port valve | A | Top porting(Direct piping) | 2 | MW4G2 | 1 | 2-position single |
| 4 | 5 port valve | B | Side porting(Base piping) | | | 2 | 2-position double |
| | | Z | Back porting(Base piping) | | | 3 | 3-position CC |
| | | | | | | 4 | 3-position ABR |
| | | | | | | 5 | 3-position PAB |
| | | | | | | 1 | Normal close NC (3GA) |
| | | | | | | 11 | Normal open NO (3GA) |
| | | | | | | 8 | Mix |

| (e)Connecting port diameter | | (f)Wiring type | | (g) Pin layout | | (h) Option | |
|-----------------------------|-------------|----------------|----------------------|----------------|--------------------|------------|--------------------------------------|
| Code | Description | Code | Description | Code | Description | Code | Description |
| See table 1 (※1) | | T8D1 | 16 point output | No code | Standard | No code | No option |
| | | T8D2 | 32 point output | W | Double wiring type | M | Manual override of non-locked type |
| | | T8D7 | 16point output/input | | | M7 | Manual override with OFF function |
| | | | | | | H | Wrong operation prevention valve(※2) |
| | | | | | | K | External pilot |
| | | | | | | A | Ozone and cutting oil |
| | | | | | | F | Built-in A·B port filters |
| | | | | | | Y※※ | Input/output block(※3) |

| (i) Mount type | | (j) No. of stations | | (k) Voltage | |
|----------------|----------------|---------------------|-----------------|-------------|-------------|
| Symbol | Description | Code | Description | Code | Description |
| No mark | Direct mount | 2~16 | No. of stations | 3 | DC24V (※4) |
| D | DIN rail mount | | | | |

Table 1: (e) Connecting port

| | Symbol | Connection specifications | MW4GA2 | MW4GB2 | MW4GZ2 |
|----------------------------|--------|----------------------------|------------------------------------|--------|--------|
| A/B Port | C4 | One-touch joint φ4 | ● | ● | ● |
| | C6 | One-touch joint φ6 | ● | ● | ● |
| | C8 | One-touch joint φ8 | ● | ● | ● |
| | 06 | Rc1/8 | ● | | |
| | CL6 | One-touch joint L-shape φ6 | | ● | |
| | CL8 | One-touch joint L-shape φ8 | | ● | |
| P/R Port (one-touch joint) | | | φ8, φ8 L-shape φ10, φ10 L-shape | | |

- ※1 The diameter of the P·R port is specified by the air intake/exhaust block.
- ※2 For the 3-position all-port block and PAB connection, valve specifications(H) for the malfunction prevention are not available.
- ※3 A numeric value showing the combination of continuous number of input/output block stations is put in ※※.
- ※4 For the serial transmission connection specifications, AC 100V and DC12V settings are not provided.

For details, check the catalog.