

INSTRUCTION MANUAL

EXPLOSION PROOF 5 PORT PILOT OPERATED VALVE

4F3EX to 4F7EX M4F3EX to M4F7EX

(Complies with internationally
harmonized guide on explosion
protection)

- Please read this instruction manual carefully before using this product, particularly the section describing safety.
- Retain this instruction manual with the product for further consultation whenever necessary.

For Safety Use


To use this product safely, basic knowledge of pneumatic equipment, including materials, piping, electrical system and mechanism, is required (ISO 4414 *1, JIS B 8370 *2).


We do not bear any responsibility for accidents caused by any person without such knowledge or arising from improper operation.


Our customers use this product for a very wide range of applications, and we cannot keep track of all of them. Depending on operating conditions, the product may fail to operate to maximum performance, or cause an accident. Thus, before placing an order, examine whether the product meets your application, requirements, and how to use it.

This product incorporates many functions and mechanisms to ensure safety. However, improper operation could result in an accident. To prevent such accidents, **read this operation manual carefully for proper operation.**

Observe the cautions on handling described in this manual, as well as the following instructions:

 **DANGER** : Failure to pay attention to DANGER notices may cause a situation that results in a fatality or serious injury and that requires urgent addressing

 **WARNING** : Failure to pay attention to WARNING notices may result in a fatality or serious injury.

 **CAUTION** : Failure to pay attention to WARNING notices may result in injury or damage to equipment or facilities.

*1) ISO 4414 : Pneumatic fluid power ... Recommendations for the application of equipment to transmission and control systems.

*2) JIS B 8370 : General rule for pneumatic systems

DESIGN & SELECTION (Page 7)



WARNING :

- a) This valve is used in the first dangerous spot (Zone 1) or the second dangerous spot (Zone 2) containing combustible gas or vapor. It cannot be used in a Class 0 Zone.
- b) Select and install the mode following JIS C 60079. Please perform the factory explosion-proof equipment guide for a user (JNIOH-TR-NO.44 (2012)).
- c) 4F Flame-proof series is not applicable neither within dust environment nor marine.

UNPACKING (Page 12)



CAUTION :

- Bags containing solenoid valves should be opened only when you are ready to connect the valves to the pipes immediately afterward.
- If bags are opened before the valves are ready to be connected to the pipes, the entry of foreign matter from the piping ports could cause the solenoid valves to fail or malfunction.

INSTALLATION (Page 13)



CAUTION :

If you have to use the product under conditions that are different from the specified conditions or if you intend to use the product for a special application, be sure to consult us about the product specifications before using the product.

ENVIRONMENT (Page 13)



CAUTION :

- a) In a dusty environment, foreign matter may enter even through the exhaust port.
 - The movement of the exhaust valve causes a respiratory action at the exhaust valve, which may cause inhalation of foreign matter near the exhaust port. This potential situation would be worse if the exhaust port is facing upward. Attach a silencer to the exhaust port or have the exhaust port face downward.
- b) The coils will produce heat.
 - Particularly if the solenoid valve system is installed in a control board or if the solenoid coils need to be energized for a long time, consider providing sufficient ventilation to release the heat. The coils can get very hot.
- c) Do not use the solenoid valve system in an atmosphere that includes a corrosive gas or solvent vapors.
 - Do not use the solenoid valve system in an atmosphere that includes a corrosive gas such as the sulfur dioxide gas or in an atmosphere that includes solvent vapors.
- d) Vibration resistance and Shock resistance
Do not subject the solenoid valve system to vibrations 50m/s^2 or stronger or shocks 300m/s^2 or stronger.

ENVIRONMENT (Page 13)



CAUTION :

e) In use on the outdoors, please do not make opening the exhaust port (E1, E2, and PE port), but take the measure in which neither garbage and dust nor rain water infiltrates into the inside of this product.

Moreover, please take a waterproofing measure also about electric wire piping in a cable ground etc

f) Avoid using the solenoid valve system in a humid environment because the humidity is likely to cause condensation with a change in the temperature.

g) The packing and gaskets may deteriorate sooner than usual if used in an atmosphere with a higher than normal density of ozone (for example, the atmosphere near a beach or in an area with frequent thunderstorms).

- Please replace parts periodically.

INSTALLATION (Page 14)



WARNING :

When installing a solenoid valve unit, never attempt to hold it in position by means of the pipes connected to it.

- Mount the solenoid valve by applying the mounting screws and/or mounting plate to the solenoid valve.

PIPING (Page 14)



CAUTION :

a) Observe the recommended tightening torque when connecting pipes.

- Observing the recommended tightening torque prevents air leakage and damage to the screw threads. To prevent damage to the screw threads, first use your hand to lightly tighten the screw and then use a tool to tighten the screw to the recommended torque.

b) Make sure that the pipes will not be disconnected at the joints by mechanical movements, vibrations or tension.

- If the exhaust piping of the pneumatic circuit is disconnected, the actuator speed control is disabled.
- If the above happens to a chuck holding mechanism, the chuck will open. The inadvertent opening of the chuck may cause a serious accident.

c) When supplying the compressed air for the first time after completing the piping, be sure to check every joint in the piping for air leakage.

d) When supplying the compressed air for the first time after completing the piping, increase the air pressure gradually but never introduce a highly pressurized air suddenly.

- A sudden introduction of a highly pressurized air may disconnect pipes at joints and/or cause the tubes to jump around, any of which may cause an injury.

PIPING (Page 14,15)



CAUTION :

- e) Do not decrease the inside diameter of the piping from any of the solenoid valve exhaust ports to a diameter less than the exhaust pipe connecting port size.
 - Normal operation of the actuator depends on the smoothness of the exhaust flow. With a manifold system, a restriction to the exhaust flow may prevent normal operation of other solenoid valves.
- f) Removal of foreign matter
 - Rust and other foreign matter in the pneumatic circuit may cause a malfunction or leakage from the valve seat. Insert a filter (maximum allowable particle size $5\ \mu\text{m}$ or less) immediately upstream of the solenoid valve.
- g) Air supply
 - Do not restrict the flow of air through the air supply piping. With a manifold system with multiple stations, a drop in the air supply pressure may cause trouble through a delay in the operation timing.
- h) A pilot air bleed hole is provided on the pilot actuator. Consult with CKD when using this product where problems could occur from exhaust, such as in a clean room.

WIRING (Page 17)



WARNING :

- a) When carrying out electrical connections, please perform disassembling and assembling work after reading the Instruction Manual carefully and with full understanding of its contents.
 - Your understanding of the structure of solenoid valve and its operation principle is required in order to secure the safety.
- b) The packing size (the number that was displayed by packing) is four kinds of follows.
 $\phi 7.5-9.5$ 、 $\phi 9.5-10.5$ 、 $\phi 10.5-11.5$ 、 $\phi 11.5-13.5$
Please use cable diameter in the packing indication level range by all means. When cable diameter does not accord with packing size, reduce the explosion-proof performance.



CAUTION :

- a) Before supplying the power, check the power supply voltage and the current type (AC or DC).
- b) Check leakage current to prevent malfunctions caused by current leaking from other control components.
- c) For outdoors, ensure that rain water does not enter from lead wire outlet G1/2.

MANUAL OVERRIDE (Page 25)



WARNING :

- a) After using the manual override, be sure to reset the manual override to the original (OFF) position before resuming the operation of the device.
After a lock type operation (push and lock), be sure to release the lock to turn the manual override OFF.
- b) Before using the manual override, make sure that nobody is present near the cylinder to be activated.

AIR QUALITY (Page 26)



WARNING :

- a) Do not supply anything other than compressed air.
- b) Supply clean compressed air without any mixture of corrosive gas.

AIR QUALITY (Page 26)



CAUTION :


- a) Compressed air usually contains a large amount of drain, oxidized oil, tar, foreign matter, and rust from the piping. Filter out those elements in the supplied air because they may cause a malfunction and decrease service life. In addition, clean the exhaust before it is released to the air to minimize pollution.
- b) Once you have lubricated a pre-lubricated valve, the valve is no longer capable of running without being lubricated from the outside. Do not leave the valve without lubrication but keep it lubricated.
- c) Do not use spindle oil or machine oil. They may induce expansion of the rubber parts, which may cause a malfunction.

ELECTRIC CIRCUITS (Page 27)



CAUTION :

- a) Check for the presence of any current leak from the external control device because it may cause an erroneous valve operation.
 - When a programmable controller or a similar control device is used, a current leak may prevent the normal returning of the valve when the solenoid is de-energized.
- b) Restriction on current leak
 - When controlling solenoid valves using a programmable controller or a similar control device, make sure that the current leak in the programmable controller output is equal to or less than the level shown in the table below. A current leak larger than the allowable level may cause an erroneous valve operation.



12 to 127VAC	4.0 mA or less
200 to 380VAC	2.0 mA or less
12 to 48VDC	1.5 mA or less
80 to 125VDC	0.6 mA or less

PERIODIC INSPECTION (Page 28)



WARNING :

Before providing a maintenance service, cut the power and the supply of compressed air and confirm the absence of residual pressure.

- The above is required to ensure safety.



CAUTION :

Regularly perform the daily and periodic inspections to correctly maintain product performance.

- If the product is not correctly maintained, product performance may deteriorate dramatically, resulting in a shorter service life, fractures of components, and malfunctions.

DISASSEMBLING AND REASSEMBLING (Page 29)



WARNING :

a) Before disassembling and reassembling solenoid valves, read the instruction manual carefully and understand the instructions.

- A person who disassembles and reassembles a solenoid valve system needs to have a knowledge for safely performing such operation based on the understanding about the mechanisms and operating principles of solenoid valves.
- Personnel involved in this step must have passed the Pneumatic Pressure Skill Test Class 2 or higher.

b) Do not disassemble components of the pilot actuator other than the gland parts and the terminal box cap. The explosion proof structure cannot not be guaranteed if disassembled.

c) The explosion proof certification is acquired for the pilot actuator assembly. When replacing the coil, replace the pilot actuator assembly.

Complies with “Recommended Practices for Explosion-Protected Electrical Installations in General Industries”

Explosion proof functionality Exd II BT4X

(Flameproof enclosure “d”/Group IIB/Temperature class T4)

Certification No. No.TC20523

Overview

4F series this explosion proof 5 port valve provides reliable and high performance, compact design and easy operation even in the flammable working environment Optimum for driving cylinders of 63 to 250 mm bore.

Features

- Complies with internationally harmonized guide on explosion protection (Explosion proof functionality Ex d IIB T4)
- Outdoors use is available.
Conformable with JIS jet proof structure.
Outdoors use is possible.
(This evaluation is not based on explosion proof certification)
- Wider range of cable diameters to choose from: $\phi 7.5$ to 13.5

Design & Selection



WARNING :

- a) This valve is used in the first dangerous spot (Zone 1) or the second dangerous spot (Zone 2) containing combustible gas or vapor. It cannot be used in a Class 0 Zone.
- b) Select and install the mode following JIS C 60079. Please perform the factory explosion-proof equipment guide for a user (JNIO SH-TR-NO.44 (2012)).
- c) 4F Flame-proof series is not applicable neither within dust environment nor marine.

INDEX

SELEX VALVE


Manual No.SM-P00050-A/1

1. PART NAME AND DESCRIPTION	9
2. INTERNATIONAL SYSTEM OF UNITS (SI) AND PORT INDICATION	
2.1 Conversion between International System Units (SI) and Conventional Units	12
3. UNPACKING	12
4. INSTALLATION	
4.1 Environment	13
4.2 Installation	14
4.3 Piping	15
4.4 Wiring	17
5. OPERATING RECOMMENDATION	
5.1 Operation	20
5.2 Manual Override	25
5.3 Air Quality	26
5.4 Electric Circuits	27
6. MAINTENANCE	
6.1 Periodic Inspection	28
6.2 Disassembling and Reassembling	29
6.3 Internal Structure and Parts List	37
7. TROUBLE SHOOTING	43
8. PRODUCT SPECIFICATIONS AND HOW TO ORDER	
8.1 Product Specifications	44
8.2 How to Order	51
9. APPENDIX	
9.1 Reference Date-1	54


1. PART NAME AND DESCRIPTION

● 2-position single


JIS SYMBOL




● 4F3



● 4F4~7




No.	Parts Name	Description
①	Cap	Seal the pressure, which is returned to the return side as the pressure of the air source is received.
②	Body ass'y	Changing the main flow passage
③	Pilot actuator ass'y	The pilot flow passage is changed by the electric signal to supply or exhaust the pilot pressure.
④	Manual override	Change the pilot flow passage using manual operation.
⑤	Sub plate	Main flow passage




● 2-position double


JIS SYMBOL



● 4F3



● 4F4~4F7






No.	Parts Name	Description
①	Body ass'y	Changing the main flow passage
②	Pilot actuator ass'y	The pilot flow passage is changed by the electric signal to supply or exhaust the pilot pressure.
③	Manual override	Change the pilot flow passage using manual operation.
④	Sub plate	Main flow passage

● 3-pos. all ports closed


3-pos. ABR connection

3-pos. PAB connection


JIS SYMBOL




● 4F3



● 4F4~4F7



No.	Parts Name	Description
①	Body block	A spring is mounted to return to the neutral position when the 3-position type is energized or turned OFF.
②	Body ass'y	Changing the main flow passage
③	Pilot actuator ass'y	The pilot flow passage is changed by the electric signal to supply or exhaust the pilot pressure.
④	Manual override	Change the pilot flow passage using manual operation.
⑤	Sub plate	Main flow passage



2. INTERNATIONAL SYSTEM OF UNITS (SI) AND PORT INDICATION

2.1 Conversion between International System of Units (SI) and Conventional Units

In this manual, values are expressed using the International System of Units (SI).
Use the table below to convert them into values expressed in conventional units.

Table of conversion between SI units and conventional units

(The values printed in **Bolds** fonts are values given in the International System of Units (SI)):

Example (converting a pressure value):	
$1\text{kgf/cm}^2 \rightarrow$	0.980665MPa 1MPa $\rightarrow 1.01972 \times 10\text{kgf/cm}^2$

• Force

N	dyn	kgf
1	1×10^5	1.01972×10^{-1}
1×10^{-5}	1	1.01972×10^{-6}
9.80665	9.80665×10^5	1

• Stress

Pa or N/m ²	Mpa or N/mm ²	kgf/mm ²	kgf/cm ²
1	1×10^{-6}	1.01972×10^{-7}	1.01972×10^{-5}
1×10^6	1	1.01972×10^{-1}	1.01972×10
9.80665×10^6	9.80665	1	1×10^2
9.80665×10^4	9.80665×10^{-2}	1×10^{-2}	1

Note: 1Pa=1N/m², 1MPa=1N/mm²

• Pressure

Pa	kPa	MPa	bar	kgf/cm ²	atm	mmH ₂ O	mmHg or Torr
1	1×10^{-3}	1×10^{-6}	1×10^{-5}	1.01972×10^{-5}	9.86923×10^{-6}	1.01972×10^{-1}	7.50062×10^{-3}
1×10^3	1	1×10^{-3}	1×10^{-2}	1.01972×10^{-2}	9.86923×10^{-3}	1.01972×10^2	7.50062
1×10^6	1×10^3	1	1×10	1.01972×10	9.86923	1.01972×10^5	7.50062×10^3
1×10^5	1×10^2	1×10^{-1}	1	1.01972	9.86923×10^{-1}	1.01972×10^4	7.50062×10^2
9.80665×10^4	9.80665×10	9.80665×10^{-2}	9.80665×10^{-1}	1	9.67841×10^{-1}	1×10^4	7.35559×10^2
1.01325×10^5	1.01325×10^2	1.01325×10^{-1}	1.01325	1.01323	1	1.03323×10^4	7.60000×10^2
9.80665	9.80665×10^{-3}	9.80665×10^{-6}	9.80665×10^{-5}	1×10^{-4}	9.67841×10^{-5}	1	7.35559×10^{-2}
1.33322×10^2	1.33322×10^{-1}	1.33322×10^{-4}	1.33322×10^{-3}	1.35951×10^{-3}	1.31579×10^{-3}	1.35951×10	1

Note: 1Pa=1N/m²

3. UNPACKING



CAUTION : Bags containing solenoid valves should be opened only when you are ready to connect the valves to the pipes immediately afterward.

- If bags are opened before the valves are ready to be connected to the pipes, the entry of foreign matter from the piping ports could cause the solenoid valves to fail or malfunction.

- 1) Check the model number imprinted on the product to make sure that the product you received is exactly the product you ordered.
- 2) Check the exterior of the product for any damage.
- 3) Before using the product, read the supplied documentation.

4. INSTALLATION



CAUTION :

If you have to use the product under conditions that are different from the specified conditions or if you intend to use the product for a special application, be sure to consult us about the product specifications before using the product

4.1 Environment



CAUTION :

- a) In a dusty environment, foreign matter may enter even through the exhaust port.
 - The movement of the exhaust valve causes a respiratory action at the exhaust valve, which may cause inhalation of foreign matter near the exhaust port. This potential situation would be worse if the exhaust port is facing upward. Attach a silencer to the exhaust port or have the exhaust port face downward.
- b) The coils will produce heat.
 - Particularly if the solenoid valve system is installed in a control board or if the solenoid coils need to be energized for a long time, consider providing sufficient ventilation to release the heat. The coils can get very hot.
- c) Do not use the solenoid valve system in an atmosphere that includes a corrosive gas or solvent vapors.
 - Do not use the solenoid valve system in an atmosphere that includes a corrosive gas such as the sulfur dioxide gas or in an atmosphere that includes solvent vapors.
- d) Vibration resistance and Shock resistance
 - Do not subject the solenoid valve system to vibrations 50m/s^2 or stronger or shocks 300m/s^2 or stronger.
- e) In use on the outdoors, please do not make opening the exhaust port (E1, E2, and PE port), but take the measure in which neither garbage and dust nor rain water infiltrates into the inside of this product.
Moreover, please take a waterproofing measure also about electric wire piping in a cable ground etc
- f) Avoid using the solenoid valve system in a humid environment because the humidity is likely to cause condensation with a change in the temperature.
- g) The packing and gaskets may deteriorate sooner than usual if used in an atmosphere with a higher than normal density of ozone (for example, the atmosphere near a beach or in an area with frequent thunderstorms).
 - Please replace parts periodically.

4.2 Installation



WARNING :

When installing a solenoid valve unit, never attempt to hold it in position by means of the pipes connected to it.

- Mount the solenoid valve by applying the mounting screws and/or mounting plate to the solenoid valve.

4.2.1 A workspace for installation, removal, wiring, and piping operations should be provided around the installed solenoid valve system.

4.3 Piping



CAUTION :

a) Observe the recommended tightening torque when connecting pipes.

- Observing the recommended tightening torque prevents air leakage and damage to the screw threads. To prevent damage to the screw threads, first use your hand to lightly tighten the screw and then use a tool to tighten the screw to the recommended torque.

b) Make sure that the pipes will not be disconnected at the joints by mechanical movements, vibrations or tension.

- If the exhaust piping of the pneumatic circuit is disconnected, the actuator speed control is disabled.
- If the above happens to a chuck holding mechanism, the chuck will open. The inadvertent opening of the chuck may cause a serious accident.

c) When supplying the compressed air for the first time after completing the piping, be sure to check every joint in the piping for air leakage.

d) When supplying the compressed air for the first time after completing the piping, increase the air pressure gradually but never introduce a highly pressurized air suddenly.

- A sudden introduction of a highly pressurized air may disconnect pipes at joints and/or cause the tubes to jump around, any of which may cause an injury.

e) Do not decrease the inside diameter of the piping from any of the solenoid valve exhaust ports to a diameter less than the exhaust pipe connecting port size.

- Normal operation of the actuator depends on the smoothness of the exhaust flow. With a manifold system, a restriction to the exhaust flow may prevent normal operation of other solenoid valves.

f) Removal of foreign matter

- Rust and other foreign matter in the pneumatic circuit may cause a malfunction or leakage from the valve seat. Insert a filter (maximum allowable particle size 5 μ m or less) immediately upstream of the solenoid valve.

4.3 Piping



CAUTION :

g) Air supply

- Do not restrict the flow of air through the air supply piping. With a manifold system with multiple stations, a drop in the air supply pressure may cause trouble through a delay in the operation timing.

- #### h) A pilot air bleed hole is provided on the pilot actuator. Consult with CKD when using this product where problems could occur from exhaust, such as in a clean room.


Appropriate torque

Joint screw	Appropriate torque N·m	Joint screw	Appropriate torque N·m
Rc1/8	3 to 5	Rc1/2	16 to 18
Rc1/4	6 to 8	Rc1/4	19 to 40
Rc3/8	13 to 15	Rc3/8	41 to 70


4.3.1 Sealant

Refrain from applying sealant or sealing tape approx. two pitches of thread off the tip of pipe to avoid residual substances from falling into piping system.

●Seal Tape




(Correct)




(Incorrect)

●Sealant (Paste or liquid)




(Correct)



(Incorrect)

4.3.2 Flushing

Before connecting pipes, flush the interiors of the tubes, solenoid valves, and connected devices to remove foreign matter.



4.3.3 Blow circuit

Do not open the cylinder port circuit to the air because a drop in the air supply pressure may cause a malfunction. Additionally, when opened to the atmosphere, the grease of the sliding part flows out and the minimum working pressure is increased, causing the service life of the seal part to be shortened.


4.3.4 Exhaust port

Minimize the restriction to the flow of the exhaust air because such restriction may cause a delay in the cylinder response. If such a delay happens, the speed needs to be adjusted between the cylinder and solenoid valve.

Avoid applying a plug screw at the end of PE, otherwise its exhaust is hindered.

4.3.5 Pipe connections

- (1) Strictly observe the effective thread length of gas pipe and give a chamfer of approx. 1/2 pitch from the threaded end.



- (2) Tubes to be used

For use with solenoid valves with one-touch joints, select tubes of the type specified by us:

Soft nylon tubes (F-1500 Series)
Urethane tubes (U-9500 Series)

- (3) For installation at a site that has spatters in the air, select incombustible tubes or metal pipes.
- (4) For piping used for both hydraulic and pneumatic controls, select a hydraulic hose.

When combining a spiral tube with a standard one-touch joint, fix the tube origin using a hose band. Otherwise the rotation of the tube will decrease the efficiency of the clamping.

For use in a high-temperature atmosphere, select fastener joints instead of one-touch joints.

- (5) When selecting from tubes commercially available, carefully study the accuracy of the outside diameter as well as the wall thickness and the hardness. The hardness of an urethane tube should be 93°C or more (as measured by a rubber hardness meter).

With a tube that does not have a sufficient accuracy of the outside diameter or the specified hardness, a decrease in the chucking force may cause disconnection or difficulty in inserting.

Tube dimensions

Outside diameter mm	Inside diameter mm	
	Nylon	Urethane
φ 4	φ 2.5	φ 2
φ 6	φ 4	φ 4
φ 8	φ 5.7	φ 5
φ 10	φ 7.2	φ 6.5

Outside diameter allowance

Soft or hard nylon		±0.1mm
Urethane	φ 4, φ 6	+0.1mm −0.15mm
Urethane	φ 8, φ 10	+0.1mm −0.2mm

(6) Minimum bending radius of tubes

Observe the minimum bending radius of tubes. Neglecting the minimum bending radius may cause disconnection or leaks.

Tube bore	Minimum bending radius mm	
	Nylon	Urethane
φ 4	10	10
φ 6	20	20
φ 8	30	30
φ 10	40	40

(7) Cutting a tube

To cut a tube, use a tube cutter to cut the tube perpendicularly to the length of the tube. Inserting an obliquely cut end of a tube may cause air leakage.


(8) Tube connections

Do not bend a tube immediately at where it is connected to the joint but lead it out straight from the end of the joint for a length equal to or greater than the outside diameter of the tube. The tension applied sideways through the tube should not exceed 40N.

4.3.6 Prevention of back flow from C1/C2 port to S

Make sure a check valve is installed to Supply port of selex valve, 3-position, all closed type, because much more accuracy of intermediate stopping position is achieved once a check valve is added to the supply port of this type valve.

Verify that there is no leakage from the sealed portions of the piping from the check valve to the cylinder.



4.4 Wiring



WARNING :

- a) When carrying out electrical connections, please perform disassembling and assembling work after reading the Instruction Manual carefully and with full understanding of its contents.
 - Your understanding of the structure of solenoid valve and its operation principle is required in order to secure the safety.
- b) The packing size (the number that was displayed by packing) is four kinds of follows.

φ 7.5-9.5、 φ 9.5-10.5、 φ 10.5-11.5、 φ 11.5-13.5

Please use cable diameter in the packing indication level range by all means. When cable diameter does not accord with packing size, reduce the explosion-proof performance.

CAUTION :

- a) Before supplying the power, check the power supply voltage and the current type (AC or DC).
- b) Check leakage current to prevent malfunctions caused by current leaking from other control components.
- c) For outdoors, ensure that rain water does not enter from lead wire outlet G1/2.

4.4.1 Wiring connections

1) Wiring work


- (1) Wire based on JIS explosion proof policy.
- (2) Remove the terminal box cap with the enclosed disassembling tool. Use the tool below to crimp the crimp terminal during wiring. After wiring, tighten the terminal box cap correctly.
Personnel should store the disassembling tool for maintenance.
- (3) In order to ensure the valve's explosion-proof performance, choose the cable for use on the valve from the circular cables specified below. Do not use a non-approved sealing ring since the flameproof sealing ring is specific to each cable diameter.

Junction box	Nominal section area	Cable finish outside diameter
G9	1.04~2.63mm ² (AWG14, AWG16)	ϕ 7.5~9.5
G10		ϕ 9.5~10.5
G11		ϕ 10.5~11.5
G13		ϕ 11.5~13.5

※Please use a cable of 85 °C or more rated temperature.

- (4) Screw in the cable gland completely in to the end face of terminal box and secure with a set screw.
- (5) Secure the cable with the cable holder and screw in the connector cap.
(Tightening torque of holder fastening screw: 1.9 to 2.0 N•m)
- (6) Use fuse of 0.5 to 1A within a circuit.
- (7) It is recommended the use of snap action switch(es) such as relay or magnetic switch to build a circuit.


2) Junction box



3) Direction of conductor entry point

Direction of terminal box and conductor entry point can be changed.

Note: This change cannot be made by the customer as it involves explosion-proof parts. Please make this request when ordering.



[NOTE]

Apply protective cover over terminal box and leading in port of cord as well during outdoor installation, because it may cause short circuit due to penetrated water resulting coil burning, if leave it without any protective measure.


5. OPERATING RECOMMENDATION

5.1 Operation

- 2-position single

4F4 to 4F7

4F3



1) Valve operation

Operation when not energized


S→C1
C2→E2
E1→Closed

Operation when energized

S→C2
C1→E1
E2→Closed

- Solenoid on = Cylinder advances(retracts)
- Solenoid off = Cylinder retracts(advances)


2) Fundamental circuit diagram




5 OPERATION

- 2-position double

4F3



4F4 to 4F7



1) Valve operation

X solenoid on


S → C1
C2 → E2
E1 → Closed

Y solenoid on

S → C2
C1 → E1
E2 → Closed


- One side solenoid on = Cylinder advances(retracts)
The same solenoid off = Holds present position
The other solenoid on = Cylinder retracts(advances)
- This concept is also used for self holding (Cylinder does not move even at the occasion of power failure.)

2) Fundamental circuit diagram




- 3-position

4F3



4F4 to 4F7



1) Valve operation

(1) All ports closed

When both solenoids receive no signal current

Every port such as S, C1, C2, E1 and E2 is blocked.

X solenoid on	S→C1 C2→E2 E1→Closed
Y solenoid on	S→C2 C1→E1 E2→Closed

- Cylinder stops at intermediate positions (when off). Once it stops, cylinder is locked and external force is unable to move the cylinder.

(2) ABR connection

When both solenoids receive no signal current

S→Closed
C1→E1
C2→E2

X solenoid on	S→C1 C2→E2 E1→Closed
Y solenoid on	S→C2 C1→E1 E2→Closed

- Cylinder stops at intermediate positions same as (1) above. But an external force is able to move the once stopped cylinder.

(3) PAB connection

When both solenoids receive no signal current


$S \rightarrow C1 \cdot C2$
 $E1 \rightarrow \text{Closed}$
 $E2 \rightarrow \text{Closed}$

X solenoid on $S \rightarrow C1$
 $C2 \rightarrow E2$
 $E1 \rightarrow \text{Closed}$
 Y solenoid on $S \rightarrow C2$
 $C1 \rightarrow E1$
 $E2 \rightarrow \text{Closed}$


- Cylinder stops at intermediate positions (when current is off) as same as (1) above. But the cylinder is not to stay still unless the unit pressure from both side of cylinder balances up due to individual pressurization to C1 port as well as to C2 port.

2) Fundamental circuit diagram


• All ports closed



• ABR connection



• PAB Connection




PAB connection is used for the purpose of letting either Rod-less cylinder or Sel-top cylinder make intermediate stops.

3) Circuit diagrams for Seltop cylinder application are as shown below.


- (1) In case of horizontal load

When piping is laid as shown in Fig1, equal pressure is applied to both sides of the piston when the system is in the OFF mode, thereby preventing the piston from jumping out. Install a regulator with a check valve on the head cover side to balance the thrust.




- (2) In case of downward load

When the lay-out of circuit is as shown in Fig. 2, install a reducing valve with a check valve to the circuit of cylinder head side for the purpose of reducing the downward thrust of the rod and keeping a balance because the cylinder rod is apt to be suddenly pulled down due to the load at the moment the brake system is released.



- (2) In case of upward load

When the load is upward as shown in Fig.3, install a reducing valve with a check valve to the circuit of piston rod side for the purpose of reducing reversed thrust of the rod and keeping a balance because the cylinder rod is apt to be pushed backward due to the load at the moment the brake system is released.



5.2 Manual Override



WARNING :


- a) After using the manual override, be sure to reset the manual override to the original (OFF) position before resuming the operation of the device.
After a lock-type operation (push and lock), be sure to release the lock to turn the manual override OFF.
- b) Before using the manual override, make sure that no-body is present near the cylinder to be activated.

5.2.1 Manual Operation Device


Since manual override is with a lock, Lock off the manual override when it not used. When using, turn manual override with minus screw driver.

- 4F3 C: OFF Match "C" to the arrow.
 O: ON Turn to the arrow direction until it is locked.
 (The arrow and "O" may not match.)

OFF




ON




- 4F4 to7 0: OFF Match "•" to "0".
 1: ON Turn to "1" direction until it is locked.
 ("1" and "•" may not match.)

OFF





ON



Note: Do not stop turning the manual override halfway.
Doing so may cause unstable operation.

5.3 Air Quality

 **WARNING :** a) Do not supply anything other than compressed air.
b) Supply clean compressed air without any mixture of corrosive gas.

 **CAUTION :** a) Compressed air usually contains a large amount of drain, oxidized oil, tar, foreign matter, and rust from the piping. Filter out those elements in the supplied air because they may cause a malfunction and decrease service life. In addition, clean the exhaust before it is released to the air to minimize pollution.
b) Once you have lubricated a pre-lubricated valve, the valve is no longer capable of running without being lubricated from the outside. Do not leave the valve without lubrication but keep it lubricated.
c) Do not use spindle oil or machine oil. They may induce expansion of the rubber parts, which may cause a malfunction.

5.3.1 Lubrication

The 4F Series this explosion proof valve systems use pre-lubricated valves that usually do not require lubrication from the outside. If you have to lubricate a valve, use Type 1 turbine oil (ISO-VG32) without additives.

Excessive lubrication and extremely low pressure may cause a longer response time. The response time in the catalogue assumes no lubrication from the outside and the air supply pressure of 0.5 MPa.

5.3.2 Ultra-dry compressed air

The use of ultra-dry compressed air will cause splashing of the lubrication oil and result in a shorter service life.

5.3.3 Drain


- 1) The drain is produced by a drop of temperature in pneumatic piping and devices.
- 2) The drain may enter and instantaneously block a passage inside a pneumatic device and cause a malfunction.
- 3) The drain accelerates the production of rust, which may cause the failure of pneumatic devices.
- 4) The drain may wash away the lubrication pill, causing a malfunction from the lack of lubrication.

5.3.4 Foreign matter in the compressed air

- 1) Supply clean compressed air that does not include oxidized oil, tar, carbon, or other foreign matter from the air compressor.
 - (1) If oxidized oil, tar, carbon, or the like enters a pneumatic device and sticks to its components, an increase in the resistance at sliding portions may cause a malfunction.
 - (2) If oxidized oil, tar, carbon, or the like is mixed with the supplied lubrication oil, wear of the sliding components of the pneumatic device may be accelerated.
- 2) Supply clean compressed air that does not include solid foreign matter.
 - (1) Solid foreign matter in the compressed air may cause wear of the sliding components of the pneumatic device or stick to such components and cause hydraulic lock.

5.3.5 Cleaning the supplied air

Compressed air usually contains a large amount of drain (water, oxidized oil, tar, and foreign matter). Remove these elements and clean the supplied air because they may cause a failure of the air compressor. For example, remove the humidity using an after-cooler dryer and remove the tar using a tar filter.



5.4 Electric Circuits




CAUTION :

a) Check for the presence of any current leak from the external control device because it may cause an erroneous valve operation.

- When a programmable controller or a similar control device is used, a current leak may prevent the normal returning of the valve when the solenoid is de-energized.

b) Restriction on current leak

- When controlling solenoid valves using a programmable controller or a similar control device, make sure that the current leak in the programmable controller output is equal to or less than the level shown in the table below. A current leak larger than the allowable level may cause an erroneous valve operation.



12 to 127VAC	4.0 mA or less
200 to 380VAC	2.0 mA or less
12 to 48VDC	1.5 mA or less
80 to 125VDC	0.6 mA or less

- (1) With a double solenoid type valve system, energize the solenoid for at least 0.1 second even for an instantaneous valve operation. However, since the cylinder may malfunction depending on the load conditions on the secondary side, energize or perform the manual operation until the cylinder reaches its stroke end position. If the target valve can be affected by a back pressure induced by another solenoid valve, it is recommendable to energize the solenoid as long as the cylinder is making an action.
- (2) If solenoids are energized for a prolonged period of time, the surface temperature of the manifold will rise. Through this increase in the temperature should not be regarded as abnormal, provide a suitable means of ventilation or heat release.

6. MAINTENANCE

6.1 Periodic Inspection



WARNING :

Before providing a maintenance service, cut the power and the supply of compressed air and confirm the absence of residual pressure.

- The above is required to ensure safety.



CAUTION :


Regularly perform the daily and periodic inspections to correctly maintain product performance.

- If the product is not correctly maintained, product performance may deteriorate dramatically, resulting in a shorter service life, fractures of components, and malfunctions.

1) To use the solenoid valve system under optimum conditions, perform a periodic inspection once or twice a year.

2) Check the screws for loosening and the joints in the piping for integrity of the sealing.

Regularly remove the drain from the air filters.



(1) Checking the compressed air supply pressure:

Is the supply pressure at the specified level?

Does the pressure gauge indicate the specified pressure when the system is operating?

(2) Checking the air filters:

Is the drain normally discharged?

Is the amount of dirt attached to the bowl and element at a normal level?

(3) Checking joints in the piping for the leakage of compressed air:

Are the pipes normally connected at joints, especially at the movable parts?

(4) Checking the operation of solenoid valves:

Is not there any delay in the operation? Is the exhaust flow normal?

(5) Checking the operation of pneumatic actuators:

Is the operation smooth?

Does the actuator stop normally at the end of the stroke?

Is the coupling with the load normal?

(6) Checking the lubricator:

Is the amount of oil adjusted properly?

(7) Checking the lubrication oil:

Is the supplied lubrication oil of the type specified by the manufacturer?

6.2 Disassembling and Reassembling




WARNING :

- a) Before disassembling and reassembling solenoid valves, read the instruction manual carefully and understand the instructions.
 - A person who disassembles and reassembles a solenoid valve system needs to have a knowledge for safely performing such operation based on the understanding about the mechanisms and operating principles of solenoid valves.
 - Personnel involved in this step must have passed the Pneumatic Pressure Skill Test Class 2 or higher.
- b) Do not disassemble components of the pilot actuator other than the terminal box cap. The explosion proof structure cannot not be guaranteed if disassembled.
- c) The explosion proof certification is acquired for the pilot actuator assembly. When replacing the coil, replace the pilot actuator assembly.

2) Disassembling and assembling Body part

- (1) Loosen the mounting screws^⑫ of the caps^⑪ on the X to detach the cap.
Push the internal spacer from the E2 port of the body^④ toward the Y side using a standard driver to project the cylinder^② forward. After that, take out the cylinder^② and piston^③.
- (2) After the internal spacer has been pushed from the E1 port of the body^④ toward the X side using a standard driver, take out the cylinder^⑩ and piston^⑨.
- (3) For built-in components, after the spool^⑧ has been taken out from the body^④, put your finger and take out the seal ass'y^⑦.
- (4) The assembly position and orientation of the built-in piston^③^⑨, cylinder^②^⑩ and seal ass'y^⑦ are specified. Always carefully check the position and orientation when reassembling the parts after disassembly.
Carry out the above work if the valve operation is faulty or if leak occurs.
 - Wash parts or blow each part or replace it with a new one.
 - Carefully avoid giving striking indentation because each part is vitally important component for sealing effect.
 - Eliminate of using organic solvent. There is potentiality of deterioration of rubber parts of malfunction due to swollen rubber parts.
 - Take the reversed sequence of disassembling to assemble it back.
Avoid minor assembling forgotten, o-ring getting out of place or leaving loosen screws.
 - Carefully avoid slipping gasket out and contamination with foreign particles.
 - Apply our company specification greases over seal ass'y, spool, cylinder, piston ass'y of sliding parts, body guide part and packing of stem ass'y.

- 4F4 to 7 2-position single



1) Disassembling Pilot actuator ass'y

- (1) When removing the hexagon socket head cap screw ②②, the pilot actuator ass'y ④ can be disassembled from the body ①⑦.

Carry out the above work if the valve operation is leak occurs.

The pilot actuator ass'y ④ cannot be disassembled as it is an explosion-proof component.


2) Disassembling and assembling Body part

- (1) Loosen the mounting screws ②③ of the caps ①④ on the X and Y sides to detach the caps. Push the internal spacer from the exhaust passage of the body ①⑦ toward the Y side using a standard driver to project the cylinder ⑨ forward. After that, take out the cylinder ⑨ and piston ⑩.
- (2) After the internal spacer has been pushed from the exhaust passage of the body ①⑦ toward the X side using a standard driver, take out the cylinder ⑩ and piston ⑩.
- (3) For built-in components, after the spool ⑪ has been taken out from the body ①⑦, put your finger and take out the seal ass'y ⑫.
- (4) The assembly position and orientation of the built-in piston ⑩⑩, cylinder ⑨ ⑩ and seal ass'y ⑫ are specified. Always carefully check the position and orientation when reassembling the parts after disassembly.

Carry out the above work if the valve operation is faulty or if leak occurs.

- Wash parts or blow each part or replace it with a new one.
- Carefully avoid giving striking indentation because each part is vitally important component for sealing effect.
- Eliminate of using organic solvent. There is potentiality of deterioration of rubber parts of malfunction due to swollen rubber parts.
- Take the reversed sequence of disassembling to assemble it back.
Avoid minor assembling forgotten, o-ring getting out of place or leaving loosen screws.
- Carefully avoid slipping gasket out and contamination with foreign particles.
- Apply our company specification greases over seal ass'y, spool, cylinder, piston ass'y of sliding parts, body guide part and packing of stem ass'y.

- 4F3 2-position double



1) Disassembling Pilot actuator ass'y

- (1) When removing the hexagon socket head cap screw⑤, the pilot actuator ass'y① can be disassembled from the body④.

Carry out the above work if the valve operation is leak occurs.

The pilot actuator ass'y① cannot be disassembled as it is an explosion-proof component.

2) Disassembling and assembling Body part

- (1) After the pilot actuator ass'y① has been removed, push the internal spacer from the E2 port of the body④ toward the Y side using a standard driver to project the cylinder② forward. After that, take out the cylinder② and piston③.

- (2) After the internal spacer has been pushed from the E1 port of the body④ toward the X side using a standard driver, take out the cylinder⑩ and piston⑨.


- (3) For built-in components, after the spool⑧ has been taken out from the body④, put your finger and take out the seal ass'y⑦.

- (4) The assembly position and orientation of the built-in piston③⑨, cylinder②⑩ and seal ass'y⑦ are specified. Always carefully check the position and orientation when reassembling the parts after disassembly.

Carry out the above work if the valve operation is faulty or if leak occurs.

- Wash parts or blow each part or replace it with a new one.
- Carefully avoid giving striking indentation because each part is vitally important component for sealing effect.
- Eliminate of using organic solvent. There is potentiality of deterioration of rubber parts of malfunction due to swollen rubber parts.
- Take the reversed sequence of disassembling to assemble it back.
Avoid minor assembling forgotten, o-ring getting out of place or leaving loosen screws.
- Carefully avoid slipping gasket out and contamination with foreign particles.
- Apply our company specification greases over seal ass'y, spool, cylinder, piston ass'y of sliding parts, body guide part and packing of stem ass'y.

- 4F4 to 7 2-position double



1) Disassembling Pilot actuator ass'y

- (1) When removing the hexagon socket head cap screw⑯, the pilot actuator ass'y④ can be disassembled from the body⑫.

Carry out the above work if the valve operation is leak occurs.

The pilot actuator ass'y④ cannot be disassembled as it is an explosion-proof component.


2) Disassembling and assembling Body part

- (1) Loosen the mounting screws⑱ of the caps⑪ on the X and Y sides to detach the caps. Push the internal spacer from the exhaust passage of the body⑫ toward the Y side using a standard driver to project the cylinder⑥' forward. After that, take out the cylinder⑥' and piston⑦'.
- (2) After the internal spacer has been pushed from the exhaust passage of the body⑫ toward the X side using a standard driver, take out the cylinder⑥ and piston⑦.
- (3) For built-in components, after the spool⑧ has been taken out from the body⑫, put your finger and take out the seal ass'y⑨.
- (4) The assembly position and orientation of the built-in piston⑦⑦', cylinder⑥⑥' and seal ass'y⑨ are specified. Always carefully check the position and orientation when reassembling the parts after disassembly.

Carry out the above work if the valve operation is faulty or if leak occurs.

- Wash parts or blow each part or replace it with a new one.
- Carefully avoid giving striking indentation because each part is vitally important component for sealing effect.
- Eliminate of using organic solvent. There is potentiality of deterioration of rubber parts of malfunction due to swollen rubber parts.
- Take the reversed sequence of disassembling to assemble it back.
Avoid minor assembling forgotten, o-ring getting out of place or leaving loosen screws.
- Carefully avoid slipping gasket out and contamination with foreign particles.
- Apply our company specification greases over seal ass'y, spool, cylinder, piston ass'y of sliding parts, body guide part and packing of stem ass'y.

• 4F3 3-position



1) Disassembling Pilot actuator ass'y

(1) When removing the hexagon socket head cap screw⑧, the pilot actuator ass'y① can be disassembled from the body⑦. Since the spring④⑭ is put inside, pay special attention to jump-up of the spring④⑭.

(2) After the cylinder②⑯ has been taken out from the pilot actuator ass'y①, take out the piston③⑮ spring④⑭ and spring holder⑤⑬.

Carry out the above work if the valve operation is leak occurs.

The pilot actuator ass'y① cannot be disassembled as it is an explosion-proof component.


2) Disassembling and assembling Body part

(1) For built-in components, after the spool⑫ has been taken out from the body⑦, put your finger and take out the seal ass'y⑩.

(2) The assembly position and orientation of the built-in piston③⑮, cylinder②⑯ spring holder⑤⑬, and seal ass'y⑩ are specified. Always carefully check the position and orientation when reassembling the parts after disassembly. Carry out the above work if the valve operation is faulty or if leak occurs.

- Wash parts or blow each part or replace it with a new one.
- Carefully avoid giving striking indentation because each part is vitally important component for sealing effect.
- Eliminate of using organic solvent. There is potentiality of deterioration of rubber parts of malfunction due to swollen rubber parts.
- Take the reversed sequence of disassembling to assemble it back.
Avoid minor assembling forgotten, o-ring getting out of place or leaving loosen screws.
- Carefully avoid slipping gasket out and contamination with foreign particles.
- Apply our company specification greases over seal ass'y, spool, cylinder, piston ass'y of sliding parts, body guide part and packing of stem ass'y.

- 4F4 to 7 3-position



1) Disassembling Pilot actuator ass'y

- (1) When removing the hexagon socket head cap screw⑤, the pilot actuator ass'y④ can be disassembled from the body⑮.
The pilot actuator ass'y④ cannot be disassembled as it is an explosion-proof component.


2) Disassembling and assembling Body part

- (1) Loosen the mounting screws⑨ of the caps⑧ on the X and Y sides to detach the caps. When taking out the caps⑧, pay special attention to jump-up of the spring⑩ since the spring⑩ is put inside.
After the cylinder⑥ has been taken out from the body⑮, take out the piston⑦, spring⑩, spring holder⑪ and body block⑬.
- (2) For built-in components, after the spool⑫ has been taken out from the body⑮, put your finger and take out the seal ass'y⑭.
- (3) The assembly position and orientation of the built-in piston⑦⑦', cylinder⑥⑥' spring holder⑪⑪' and seal ass'y⑭ are specified. Always carefully check the position and orientation when reassembling the parts after disassembly. Carry out the above work if the valve operation is faulty or if leak occurs.
 - Wash parts or blow each part or replace it with a new one.
 - Carefully avoid giving striking indentation because each part is vitally important component for sealing effect.
 - Eliminate of using organic solvent. There is potentiality of deterioration of rubber parts of malfunction due to swollen rubber parts.
 - Take the reversed sequence of disassembling to assemble it back.
Avoid minor assembling forgotten, o-ring getting out of place or leaving loosen screws.
 - Carefully avoid slipping gasket out and contamination with foreign particles.
 - Apply our company specification greases over seal ass'y, spool, cylinder, piston ass'y of sliding parts, body guide part and packing of stem ass'y.

6.3 Internal Structure and Consumable Parts List

●4F3 2-position single

1)Internal Structure



No	Parts	Material		No	Parts	Material	
①	Cross headed pan small screw with spring washer	SUS	Stainless steel	⑦	Gasket	NBR	Acrylonitrile-butadiene rubber
②	Cylinder (B)	—		⑧	Body	ADC12	Aluminum alloy die casting
③	Piston ass'y (B)	—		⑨	Spool	A5056	Aluminum alloy
④	Cylinder (A)	—		⑩	Seal ass'y	—	
⑤	Piston ass'y (A)	—		⑪	O-Ring	NBR	Acrylonitrile-butadiene rubber
⑥	Cap	ADC12	Aluminum alloy die casting	⑫	Actuator ass'y	—	

2)Consumable Parts List


Part no. and name	⑩	⑤	③	⑫
Model no.	Seal ass'y	Piston ass'y (A)	Piston ass'y (B)	Actuator ass'y
4F310EX	4F9-106	4F9-104	4F9-103	Actuator ass'y model No.

Note: For consumable parts, kit is available. Please replace a whole kit but not a part. (The kit includes packing seal ass'y, piston ass'y (A) and (B).)

: When replacing the coil, replace the pilot actuator assembly.

● 4F4 to 7 2-position single

1) Internal Structure



No	Parts	Material	No	Parts	Material
①	Body	ADC12 Aluminum alloy die casting	⑧	Sub plate	ADC12 Aluminum alloy die casting
②	Cylinder (B)	—	⑨	Actuator ass'y	—
③	Piston ass'y (B)	—	⑩	Gasket	NBR Acrylonitrile-butadiene rubber
④	Cap	ADC12 Aluminum alloy die casting	⑪	Seal ass'y	—
⑤	Cross headed pan small screw with spring washer	SUS Stainless steel	⑫	Piston ass'y (A)	—
⑥	Gasket	NBR Acrylonitrile-butadiene rubber	⑬	Spool	A5056 Aluminum alloy
⑦	Gasket	NBR Acrylonitrile-butadiene rubber	⑭	Cylinder	—

2) Consumable Parts List


Part no. and name	⑪	⑫	⑬	⑨
Model no.	Seal ass'y	Piston ass'y (A)	Piston ass'y (B)	Actuator ass'y
4F410EX	4F9-106	4F9-104	4F9-103	Actuator ass'y model No.
4F510EX	4F9-107	4F9-108	4F9-109	
4F610EX	4F9-118	4F9-117	4F9-116	
4F710EX	4F9-119	4F9-121	4F9-120	

Note: For consumable parts, kit is available. Please replace a whole kit but not a part. (The kit includes packing seal ass'y, piston ass'y (A) and (B).)

: When replacing the coil, replace the pilot actuator assembly.

●4F3 2-position Double

1)Internal Structure



No	Parts	Material	No	Parts	Material
①	Body	ADC12 Aluminum alloy die casting	⑤	Spool	A5056 Aluminum alloy
②	Cylinder (A)	—	⑥	Seal ass'y	—
③	Piston ass'y (A)	—	⑦	Actuator ass'y	—
④	O-Ring	NBR Acrylonitrile-butadiene rubber			

2)Consumable Parts List


Part no. and name	⑥	③	⑦
Model no.	Seal ass'y	Piston ass'y (A)	Actuator ass'y
4F320EX	4F9-106	4F9-104	Actuator ass'y model No.

Note: For consumable parts, kit is available. Please replace a whole kit but not a part. (The kit includes packing seal ass'y, piston ass'y (A).)

: When replacing the coil, replace the pilot actuator assembly.

● 4F4 to 7 2-position Double

1) Internal Structure



No	Parts	Material	No	Parts	Material
①	Body	ADC12 Aluminum alloy die casting	⑧	Sub plate	ADC12 Aluminum alloy die casting
②	Cylinder (A)	—	⑨	Actuator ass'y	—
③	Piston ass'y (A)	—	⑩	Gasket	NBR Acrylonitrile-butadiene rubber
④	Cap	ADC12 Aluminum alloy die casting	⑪	Seal ass'y	—
⑤	Cross headed pan small screw with spring washer	SUS Stainless steel	⑫	Spool	A5056 Aluminum alloy
⑥	Gasket	NBR Acrylonitrile-butadiene rubber	⑬	Piston ass'y (B)	—
⑦	Gasket	NBR Acrylonitrile-butadiene rubber			

2) Consumable Parts List


Part no. and name	⑪	③	③	⑨
Model no.	Seal ass'y	Piston ass'y (A)	Piston ass'y (B)	Actuator ass'y
4F420EX	4F9-106	4F9-104	—	Actuator ass'y model No.
4F520EX	4F9-107	4F9-108	—	
4F620EX	4F9-118	—	4F9-116	
4F720EX	4F9-119	—	4F9-120	

Note: For consumable parts, kit is available. Please replace a whole kit but not a part. (The kit includes packing seal ass'y, piston ass'y (A) and (B).)

: When replacing the coil, replace the pilot actuator assembly.

●4F3 3-position

1)Internal Structure



No	Parts	Material		No	Parts	Material	
①	Body block	ADC12	Aluminum alloy die casting	⑦	O-Ring	NBR	Acrylonitrile-butadiene rubber
②	Spring	SWP	Steel	⑧	Body	ADC12	Aluminum alloy die casting
③	Spring holder	SUS304	Stainless steel	⑨	Spool	A5056	Aluminum alloy
④	Cylinder	—		⑩	Seal ass'y	—	
⑤	O-Ring	NBR	Acrylonitrile-butadiene rubber	⑪	Actuator ass'y	—	
⑥	Piston ass'y	—					

2)Consumable Parts List


Part no. and name	⑩	⑥	⑪
Model no.	Seal ass'y	Piston ass'y	Actuator ass'y
4F330EX	4F9—106	4F9—114	Actuator ass'y model No.
4F340EX			
4F350EX			

Note: For consumable parts, kit is available. Please replace a whole kit but not a part. (The kit includes packing seal ass'y, piston ass'y.)

: When replacing the coil, replace the pilot actuator assembly.

● 4F4 to 7 3-position

1) Internal Structure



No	Parts	Material	No	Parts	Material
①	Gasket	NBR	⑨	Gasket	NBR
②	Cap	ADC12	⑩	Spring	SWP
③	Cross headed pan small screw with spring washer	SUS	⑪	Piston ass'y	—
④	Body block	ADC12	⑫	Spool	A5056
⑤	Body	ADC12	⑬	O-Ring	NBR
⑥	Gasket	NBR	⑭	Cylinder	—
⑦	Sub plate	ADC12	⑮	Seal ass'y	—
⑧	Actuator ass'y	—			

2) Consumable Parts List

Part no. and name	⑮	⑪	⑧
Model no.	Seal ass'y	Piston ass'y	Actuator ass'y
4F430EX	4F9－106	4F9－114	Actuator ass'y model No.
4F440EX			
4F450EX			
4F530EX	4F9－107	4F9－115	
4F540EX			
4F550EX			
4F630EX	4F9－118	4F9－122	
4F640EX			
4F650EX			
4F730EX	4F9－119	4F9－123	
4F740EX			
4F750EX			

Note: For consumable parts, kit is available. Please replace a whole kit but not a part. (The kit includes packing seal ass'y, piston ass'y.)

: When replacing the coil, replace the pilot actuator assembly.

7. TROUBLE SHOOTING

Motion troubles	Suspected cause	Remedies
Does not actuate	No electric signals	Turn on the power
	Damage to signal wiring system	Repair the control circuit
	Excessive fluctuating range of current or voltage	Reaffirm the power capacity. (within $\pm 10\%$ of voltage fluctuation)
Malfunctions	Excessive leaking current	Correct control circuit and / or set a bleed circuit
	Chattering	Inspect switching system and / or tighten each loosen terminal screw
	Voltage deviates than specified on the name plate	Rectify the voltage to meet the specification
	Damaged or short circuited coil	Replace the actuator ass'y
	Erroneous shut off pressure source	Turn on the power source
	Insufficient pressure	Reset the pressure reducer valve or install a pressure raising valve
	Insufficient flow of fluid	Rectify the size of pipe or install a surge tank
	Erroneous piping, erroneous omitting some piping	Rectify the piping system
	Speed control valve completely closed by error	Reset the needle valve
	Sticking tarry or liquid jelly substitute	Carry out pipe dressing Operate it periodically
	Valve is frozen	Add remedies of avoiding freezing (Heating system or dehumidifying system etc.)
	Delayed return of a plunger (Excessive oil, existence of far)	Check the quality of the lubricant. (Turbine oil class 1, ISO VG 32 or equivalent)
	"	Rectify the quantity of lubricant drip
	"	Install a tar removing filter
	Clogged-up exhausting port with dust	Install a cover or silencer and clean it regularly.
Internal leakage	Bulged or decomposed packing Initial lubricant is washed off or excessive lubricants	Check the quality of the lubricant. (Turbine oil class 1, ISO VG 32 or equivalent)
	"	Relocate the valves away from splashing area of cutting coolant
	"	Keep organic chemicals away from valves.
	Initial lubricant is washed off or drain contamination	Change the piping to an external pilot system. Install dryer, Filter or grease up. Grease it up
	Foreign particles cut into packing lips.	Remove the foreign particle away from the packing Install a filter.
Malfunctions when manifold is used	Delayed response when multiple blocks are used. Insufficient air supply flow.	Install Sup. (P) piping to P ports on both sides of manifold block
	Delayed response when multiple blocks are used. Insufficient exhaust air flow.	Connect Exh. (R) piping to R ports on both sides of manifold block so as to exhaust to an open air through
	Adjacent cylinder pops out. Intrusion of exhaust air.	Rewire to have the solenoid valve in question is actuated prior to others sequentially. Increase exhaust air Change type to individual exhaust

8. PRODUCT SPECIFICATIONS AND HOW TO ORDER

8.1.1 Product Specifications

1) Explosion-proof actuator specifications

	EX3-GP	EX4-GP	EX5-GP
explosion-proof construc-	Exd II BT4		
Certificate Number	TC20523		
Ambient temperature	-10~70℃		
Fluid temperature	-10~70℃		
Bolt strength	A2-70		
Use cable	Permission temperature 85 degrees Celsius		

2) Electric Specifications

Descriptions Rated voltage (V)	Starting current (A) (50/60Hz)	Holding current (A) (50/60Hz)	Power consumption (W)
AC100	0.186/0.135	0.060/0.050	4.5/4.0
AC200	0.093/0.068	0.030/0.025	4.5/4.0
AC110	0.169/0.123	0.055/0.045	4.5/4.0
AC220	0.085/0.061	0.027/0.023	4.5/4.0
DC12	0.332	0.332	4.0
DC24	0.166	0.166	4.0
Voltage fluctuation	±10%		
Thermal class	H		

8
SPECIFICATIONS

1) 4F3 solenoid valve specifications

Descriptions		2-postion Single	2-postion Double	3pos. All port closed	3-pos. ABR connection	3-pos.PAB connection
Working fluid		Compressed air				
Valve type and operation		Pilot type spool valve				
Min. working pressure	MPa	0.10		0.15		
Max. working pressure	MPa	1.0				
Proof pressure	MPa	1.5				
Ambient temperature ※1	℃	－10 to 60				
Fluid temperature	℃	5 to 60				
Lubrication ※2		Not required				
Leakage	cm ³ /min	25				
Vibration resistance	m/s ²	50 or less				
Shock resistance	m/s ²	300 or less				
Atmosphere		No corrosive gas should exist				
Port size Air supplying port S※3		Rp1/4 ・ Rp3/8				
Cylinder port C						
Exhaust port E						
Pilot exhaust port PE		Rp1/8				
Effective cross-sectional area (Rp1/4 / Rp3/8)	mm ²	25／32		17／21	19／22	17／21
Response time ※4		100				
Weight	kg	0.92	1.48	1.69		

※1 Ambient temperature applies when stored or sitting, and does not apply to the fluid temperature in operation.

※2 Use turbine oil type 1,ISO VG32 when required. If the oil is lubricated excessively or intermittently, this may cause unstable operation.

※3 As for models 4F3, Rp thread is adopted so as to be built with manifold. Rp, parallel female thread, has been adopted broadly to put in tapered male thread. (It is, also, clearly specified in JIS.)

※4 The response time above is the figure on the non-lubricated type at the supply pressure of 0.5MPa, and is subject to change by pressure and or quality of lubrication.

1)4F4 solenoid valve specifications

Descriptions		2-postion Single	2-postion Double	3pos. All port closed	3-pos. ABR connection	3-pos.PAB connection
Working fluid		Compressed air				
Valve type and operation		Pilot type spool valve				
Min. working pressure	MPa	0.10		0.15		
Max. working pressure	MPa	1.0				
Proof pressure	MPa	1.5				
Ambient temperature ※1	℃	－10 to 60				
Fluid temperature	℃	5 to 60				
Lubrication ※2		Not required				
Leakage	cm ³ /min	25				
Vibration resistance	m/s ²	50 or less				
Shock resistance	m/s ²	300 or less				
Atmosphere		No corrosive gas should exist				
Port size	Air supplying port S	Rc1/4 · Rc3/8				
	Cylinder port C					
	Exhaust port E					
Pilot exhaust port PE		Rc1/8				
Effective cross-sectional area	mm ²	32		21	22	21
Response time ※3		120				
Weight	kg	1.27	1.85	2.02		

※1 Ambient temperature applies when stored or sitting, and does not apply to the fluid temperature in operation.

※2 Use turbine oil type 1,ISO VG32 when required. If the oil is lubricated excessively or intermittently, this may cause unstable operation.

※3 The response time above is the figure on the non-lubricated type at the supply pressure of 0.5MPa,and is subject to change by pressure and or quality of lubrication.

1) 4F5 solenoid valve specifications

Descriptions		2-postion Single	2-postion Double	3pos. All port closed	3-pos. ABR connection	3-pos.PAB connection
Working fluid		Compressed air				
Valve type and operation		Pilot type spool valve				
Min. working pressure	MPa	0.10		0.15		
Max. working pressure	MPa	1.0				
Proof pressure	MPa	1.5				
Ambient temperature ※1	℃	－10 to 60				
Fluid temperature	℃	5 to 60				
Lubrication ※2		Not required				
Leakage	cm³/min	25				
Vibration resistance	m/s²	50 or less				
Shock resistance	m/s²	300 or less				
Atmosphere		No corrosive gas should exist				
Port size Air supplying port S		Rc3/8 ・ Rc1/2				
Cylinder port C						
Exhaust port E						
Pilot exhaust port PE		Rc1/8				
Effective cross-sectional area	mm²	47		41	43	
Response time ※3		140				
Weight	kg	1.53	2.14	2.40		

※1 Ambient temperature applies when stored or sitting, and does not apply to the fluid temperature in operation.

※2 Use turbine oil type 1,ISO VG32 when required. If the oil is lubricated excessively or intermittently, this may cause unstable operation.

※3 The response time above is the figure on the non-lubricated type at the supply pressure of 0.5MPa, and is subject to change by pressure and or quality of lubrication.

1)4F6 solenoid valve specifications

Descriptions	2-postion Single	2-postion Double	3pos. All port closed	3-pos. ABR connection	3-pos.PAB connection
Working fluid	Compressed air				
Valve type and operation	Pilot type spool valve				
Min. working pressure MPa	0.15				
Max. working pressure MPa	1.0				
Proof pressure MPa	1.5				
Ambient temperature ※1 °C	－10 to 60				
Fluid temperature °C	5 to 60				
Lubrication ※2	Not required				
Leakage cm ³ /min	50				
Vibration resistance m/s ²	50 or less				
Shock resistance m/s ²	300 or less				
Atmosphere	No corrosive gas should exist				
Port size Air supplying port S	Rc1/2 ・ Rc3/4				
Cylinder port C					
Exhaust port E					
Pilot exhaust port PE	Rc1/4				
Effective cross-sectional area mm ²	90		80		
Response time ※3	400				
Weight kg	2.20	2.82	3.20		

※1 Ambient temperature applies when stored or sitting, and does not apply to the fluid temperature in operation.

※2 Use turbine oil type 1,ISO VG32 when required. If the oil is lubricated excessively or intermittently, this may cause unstable operation.

※3 The response time above is the figure on the non-lubricated type at the supply pressure of 0.5MPa,and is subject to change by pressure and or quality of lubrication.

8
SPECIFICATIONS

1) 4F7 solenoid valve specifications

Descriptions	2-postion Single	2-postion Double	3pos. All port closed	3-pos. ABR connection	3-pos.PAB connection
Working fluid	Compressed air				
Valve type and operation	Pilot type spool valve				
Min. working pressure MPa	0.15				
Max. working pressure MPa	1.0				
Proof pressure MPa	1.5				
Ambient temperature ※1 °C	- 10 to 60				
Fluid temperature °C	5 to 60				
Lubrication ※2	Not required				
Leakage cm ³ /min	50				
Vibration resistance m/s ²	50 or less				
Shock resistance m/s ²	300 or less				
Atmosphere	No corrosive gas should exist				
Port size Air supplying port S	Rc3/4 · Rc1				
Cylinder port C					
Exhaust port E					
Pilot exhaust port PE	Rc1/4				
Effective cross-sectional area mm ²	160				
Response time ※3	600				
Weight kg	3.74	4.34	5.36		

※1 Ambient temperature applies when stored or sitting, and does not apply to the fluid temperature in operation.

※2 Use turbine oil type 1,ISO VG32 when required. If the oil is lubricated excessively or intermittently, this may cause unstable operation.

※3 The response time above is the figure on the non-lubricated type at the supply pressure of 0.5MPa, and is subject to change by pressure and or quality of lubrication.

8.1.2 Manifold Product Specifications

1) Specifications

Descriptions	
Manifold structure	Manifold integrated
Manifold type	Common exhaust ・ Individual exhaust (M4F3)
Station #	2 to 10 station
Working fluid	Compressed air
Valve type and operation	Pilot type spool valve
Min. working pressure MPa	Refer to following individual specifications.
Max. working pressure MPa	1.0
Proof pressure MPa	1.5
Ambient temperature ※1 °C	−10 to 60
Fluid temperature °C	5 to 60
Lubrication ※2	Not required
Vibration resistance m/s ²	50 or less
Shock resistance m/s ²	300 or less
Atmosphere	No corrosive gas should exist
Port size	Refer to following individual specifications.
Effective cross-sectional area mm ²	Refer to following individual specifications.

※1 Ambient temperature applies when stored or sitting, and does not apply to the fluid temperature in operation.

※2 Use turbine oil type 1, ISO VG32 when required. If the oil is lubricated excessively or intermittently, this may cause unstable operation.

2) Individual specifications

Descriptions			M4F3	M4F4	M4F5	M4F6	M4F7
Min. working pressure MPa	2-pos.	Single	0.10	0.10	0.10	0.15	0.15
		Double					
	3-pos.	All port closed	0.15	0.15	0.15		
		ABR connection					
		PAB connection					
Port size ※3	Common exhaust method	Cylinder port C	Rp1/4 (08) Rp3/8 (10)	Rc1/4	Rc3/8	Rc1/2	Rc3/4
		Exhaust port E	Rp1/2	Rc3/8	Rc1/2	Rc3/4	Rc3/4
		Air supplying port S					Rc1
	Individual exhaust method	Cylinder port C	Rp1/4 (08) Rp3/8 (10)	Rc1/4 (※Back porting)	Rc3/8 (※Back porting)	Rc1/2	Rc3/4
		Exhaust port E	Rc1/4 (08) Rc3/8 (10)				Rc1/2
		Air supplying port S	Rp1/2	Rc3/8	Rc1/2	Rc3/4	Rc1
	Pilot exhaust port PE		Rp1/8	Rc1/8	Rc1/8	—	—
Effective cross-section al area mm ²	2-pos.	Single	25／32 (Rp1/4 , Rp3/8)	32	47	90	160
		Double					
	3-pos.	All port closed	17／21	21	41	80	
		ABR connection	19／22	22	43		
		PAB connection	17／21	21			
Response time ※4 ms			100	120	140	400	600


※3 As for models M4F3, Rp thread is adopted so as to be built with manifold. Rp, parallel female thread, has been adopted broadly to put in tapered male thread. (It is, also, clearly specified in JIS.)

※4 The response time above is the figure on the non-lubricated type at the supply pressure of 0.5MPa, and is subject to change by pressure and or quality of lubrication.


※ Back porting is custom order.

8.2 How to Order


- Explosion proof 5 port valve




- Pilot actuator assembly




- Discrete solenoid valve of manifold (4F3)



- Discrete solenoid valve of manifold (4F4 to 7)



- Manifold



Note: Screws and gasket are also supplied together with models 4F4※9, 4F5※9, 4F6※9 & 4F7※9.

For the seal assembly, piston assembly(A) and piston assembly(B), refer to the kit number (ex.4F9-104) stated in 6.3 Internal Structure and Consumable Parts List.

a :Series		b :Solenoid position		c :Port size					
3	3	1	2-position single	08	Rp1/4	○			
4	4	2	2-position double		Rc1/4		○		
5	5	3	3-position all ports closed	10	Rp3/8	○			
6	6	4	3-position ABR connection		Rc3/8		○	○	
7	7	5	3-position PAB connection	15	Rc1/2			○	○
		8	Mix. manifold	20	Rc3/4				○
				25	Rc1				○
				15	Rc1/2			○	MF
				20	Rc3/4				○

- As for models 4F3, Rp thread is adopted so as to be built with manifold.
Rp, parallel female thread, has been adopted broadly to put in tapered male thread. (It is, also, clearly specified in JIS.)

d :Junction box		e :Option	
G9	Pressure proof packing protection tube screw in type (cable sizeφ7.5~9.5)	Blank	None option
G10	Pressure proof packing protection tube screw in type (cable sizeφ9.5~10.5)	P	Mounting bracket attached (4F31 * E – L type), (4F4 to 7 – U type)
G11	Pressure proof packing protection tube screw in type (cable sizeφ10.5~11.5)	P1	Mounting bracket attached (4F32 * E to 4F35 * E – U type)
G13	Pressure proof packing protection tube screw in type (cable sizeφ11.5~13.5)	H	Check valve attached (Only 3-position all ports closed)
		N	Plug attached (3 port valve)
		NC	Plug assembly (C1 : A, E1 : R1)
		NO	Plug assembly (C2 : B, E2 : R2)
		R	Position change of manual override

f :Station number	
2	2
to	to
10	10

g :Exhaust method		h :Mounting bracket	
C	Common exhaust type	L	L model bracket (Single only) attached (Note)
I	Individual exhaust type	U	U shaped bracket attached (Note)

(Note) Tightening torque for mounting bracket assembly screws : 5.0~5.5 N・m

i :Rated voltage	
AC100V	100 VAC (50/60Hz) , 110 VAC 60Hz
AC200V	200 ACV (50/60Hz) , 220 VAC 60Hz
DC24V	24 VDC
DC12V	12 VDC
AC110V	110 VAC (50/60Hz)
AC220V	220 VAC (50/60Hz)

AC (V) 50/60Hz	12, 24, 48, 115, 120, 125, 127, 210, 230, 240, 250, 380
DC (V)	45, 48, 80, 100, 110, 125, (220)

※1:As custom order, following voltages are available.

- When building a system using one kind of manifold

M4F310EX-08-G9-N-7-CL-AC100V

- Explosion proof 5 port pilot operated valve manifold
- Solenoid position : 2-position single
- Port size : Rp1/4
- Junction box : Pressure proof packing protection tube screw in type
(cable size ϕ 7.5~9.5)
- Option : Plug attached
- Station No. : 7 station
- Exhaust method : Common exhaust type
- Mounting bracket : L model bracket
- Rated voltage : 100 VAC

- Mix manifold

- How to indicate mix manifold description

When selecting mix manifold [indicate (b) as 8.], indicate model No., function symbol (A table reference) and allocation number (1 to station No. from left) according to the example.

A table

Symbol	Type
S1	2-position single
S2	2-position double
S3	3-position all port closed
S4	3-position ABR connection
S5	3-position PAB connection
MP	Masking plate

- Model No. mix manifold, as the B table, Port size Rp1/4, Conduit screw connection method, Pressure proof packing protection tube screw in type(cable size ϕ 7.5~9.5), U shaped bracket, Voltage AC100V.

Model No. _____

M4F380EX-08-G9-7-CU-AC100V-

2	2	1	1	1	0
----------	----------	----------	----------	----------	----------

S1 S2 S3 S4 S5 MP

Quantity of
mix manifold

Remarks: S1=1,6, S2=2,5, S3=3, S4=7, S5=4, MP = None

B table

Symbol	Type
1	2-position single (S1)
2	2-position double (S2)
3	3-position all port closed (S3)
4	3-position PAB connection (S5)
5	2-position double (S2)
6	2-position single (S1)
7	3-position ABR connection (S4)

9. APPENDIX

9.1 REFERENCE DATE - 1

1. Explosion proof certification model

Explosion proof certification is certificate to a whole pilot actuator assembly. Certification type and model of pilot actuator assembly is as the following table.


Model	Certification type
4F310EX to 4F350EX-TP	EX3-GP
4F410EX to 4F710EX-TP	EX4-GP
4F420EX to 4F720EX-TP	EX5-GP
4F430EX to 4F730EX-TP	
4F440EX to 4F750EX-TP	
4F450EX to 4F750EX-TP	

2. Explosive gas and type of protection

Explosive gas and its degree of risk are classified by group and temperature class. Gases with same degree of risk belong to same group, and the standard for the type of protection is determined for each group.

Explosion-protected electrical equipment must be marked with the type of protection, group, and temperature class (in this order) using symbols. The marking indicates the type of gas (group and temperature class classification) the electrical equipment was manufactured to be used for. For example, an explosion-protected solenoid valve marked “Ex d IIB T4” indicates the following

Ex d IIB T4



and any gas with risk classified as group IIB and temperature class T4 in Table 2 can be used. The marking also indicates that the equipment is suitable for use with gases with lesser risk (that is, IIB equipment is suitable for applications requiring IIA equipment).

The temperature class indicates the degree of risk of ignition. There are six temperatures classes divided by point of ignition, and the maximum surface temperature of the equipment for each class is specified (Table 1). Larger temperature class number means lower ignition temperature, and such gas is the most dangerous since it can ignite easily.

The group indicates the risk that fire can escape through small gaps and is subdivided into three based on those gaps. The symbols used are shown in Table 1. It can be said that this grouping is based on the size of explosion energy. Smaller maximum safe gap means more likely the fire will escape through small gaps, and such gas is the most dangerous since it has large explosion energy.

Table 1

Item	Marking	Description
Temperature class	T1	Maximum surface temperature
	T2	450°C
	T3	300°C
	T4	200°C
	T5	135°C
	T6	100°C
Group	II A	Maximum safe gap
	II B	0.9 mm and larger
	II C	Larger than 0.5 mm and smaller than 0.9 mm 0.5 mm and smaller

Table 2

Ignitability Flame-proof grade	T1	T2	T3	T4	T5
II A	Acetone	Ethanol	Gasoline	Acetaldehyde	
	Ammonia	Isoamyl acetate	Hexane		
	Carbon monoxide	Butane			
	Ethane	Acetic anhydride			
	Acetic acid				
	Ethyl acetate				
	Toluene				
	Propane				
	Benzene				
	Methanol				
	Methane				
II B		Ethylene		Ethyl ether	
		Ethylene oxide			
II C	Hydrogen	Acetylene			Carbon disulfide

3. Danger zone

Zone where flammable gases and air mix at a level high enough to cause an explosion or combustion are called danger zones. These zones are classified into Class 0 zones, Class I zones and Class 2 zones according to the time and frequency that the dangerous atmosphere exists. The explosion proof structure that can be used is determined according to these classes.

- Class 0 zone (4F Explosion-proof series is not applicable to be installed with in this place.)
Zone where a dangerous atmosphere is or could be continuously generated, and where the concentration of flammable gas is maintained continuously or for a long term above the lower limit for explosions.
Example
 - a. Room above liquid level in vessel or tank of flammable liquid.
 - b. Inside of a flammable gas vessel and a tank etc.
 - c. Close to liquid level of flammable liquid in a opened vessel.
- Class 1 zone
 - (1) Zone where flammable gas could accumulate to a dangerous concentration during normal operation such as during opening-closing of product take-out lid, or operation of a safety valve.
 - (2) Zone where flammable gas could accumulate to a dangerous concentration during repairs, maintenance or due to a leakage etc.
- Class 2 zone
 - (1) Zone where combustible gases or flammable fluids are always handled, but where the gases and fluid are sealed in a vessel or equipment and where the gas could leak to a dangerous concentration only if the vessel or equipment breaks by accidents or if the operation is mistaken.
 - (2) Zone where measures to prevent accumulation of flammable gas are taken with a certain mechanical ventilation device but where flammable gas could accumulate to a dangerous concentration if the ventilation device fails.
 - (3) The place around Class I zone or the room which adjacent to Class 1 zone and flammable gas that reaches hazardous concentration may enter into.