

Flow rate sensor wiring method

- · Always read the safety precautions before wiring.
- 4-conductor cabtyre cable 0.2 mm² is used.
- Option

Sensor (Analog output)

-A0; (0 to 5 [V])

-A1; (4 to 20 [mA])


-A2; (1 to 5 [V])


-P0; (PNP a-contact, 2 points)

-A3; (0 to 10 [V])

*There is one alarm output point for the sensor/switch type.


● WFK3 □ □ □ S (sensor voltage output: -A0/-A2/-A3)






^{*} When connecting two or more flow rate sensors to the upper-level input circuit (receiver), carefully prevent signal interference.

● WFK3 □ □ □ M (Switch NPN output: -N0/-N1)




■ WFK3 □ □ □ M (Switch PNP output: -P0/-P1)



Specifications of mounted devices

■ WFK3 □ □ □ C (sensor voltage output: -A0/-A2/-A3, Switch NPN output: N0/N1)



...Connect toDC power supply [+] : 12 to 24 VDC±10%


(15 to 24 VDC±10% for option A3)

...Analog output : Voltage in proportion to flow rate is output


...Switch (OUT) output : MAX. 30 VDC/50 mA

...Connect toDC power supply [-] : 0 VDC

■ WFK3 □ □ □ C (sensor current output: -A1, Switch NPM output: N0,N1)



■ WFK3 □ □ □ C (sensor voltage output: -A0/-A2/-A3, Switch PNP output: P0,P1)



...Connect toDC power supply [+] : 12 to 24 VDC±10%


(15 to 24 VDC±10% for option A3)

...Analog output : Voltage in proportion to flow rate is output

...Switch (OUT) output : MAX 30 VDC/50 mA

...Connect toDC power supply [-] : 0 VDC

lacktriangle WFK3 \Box \Box \Box C (sensor current output: -A1, Switch PNP output: P0,P1)




Functions

●Switch (WFK30□ □M)

· 2-digit digital display Indicators the instantaneous flow rate. *Less than 10 L/min: Decimal display 10 L/min and over: Integer displayed

· Rotary switch for output setting



· Output lamp: Green (OUT1) Lights when switch output is ON.

 Output lamp: Red (OUT2) Lights when switch output is ON.

* OUT1: Lead wire (black) OUT2: Lead wire (orange) supported.




Allows you to set the switch output setting in 10 steps.


- Use a precision screwdriver, etc., to set the rotary switch. Be extremely careful, since applying excessive force to the rotating part may result in contact failure. Use the cylinder by making sure that the arrow aligns with the scale. If it is
- forcibly set at an infermediate point, the output may become unstable. Turn power OFF before setting switch outputs.
- After setting switch output, close the cover to display the set flow rate

Switch output setting value [L/min]


Rotary switch	Model		
Contact number	WFK3004M	WFK3012M	WFK3032M
1	0.6	2.0	5.0
2	0.7	3.0	9.0
3	0.8	4.0	12
4	0.9	5.0	14
5	1.0	6.0	16
6	1.5	7.0	18
7	2.0	8.0	21
8	2.5	9.0	24
9	3.0	10	27
0	3.5	11	30
Hysteresis	0.1	0.5	1.0

Switch output operation





●Sensor (WFK30□ □S)



Water conduction indicator: Green

Lights when water flows within the specified range.

Power indicator: Red


Lights when the power is ON.

●Sensor/switch (WFK30□ □C)

· 2-digit digital display Indicators the instantaneous flow rate. Below 10 L/min: Decimal point display 10 L/min or more: Integer display

· Rotary switch for output setting

Switch output set value [L/min]



· Output lamp: Orange (OUT) Lights when switch output is ON.

* OUT: Lead wire (black) compatible.



Rotary switch

Allows you to set the switch output setting in 10 steps.

• Use a precision screwdriver, etc., to set the rotary switch. Be extremely


- careful, since applying excessive force to the rotating part may result in contact failure.
- Use the cylinder by making sure that the arrow aligns with the scale. If it is forcibly set at an intermediate point, the output may become unstable. Turn power OFF before setting switch outputs.

 After setting switch output, close the cover to display the set flow rate.

0.5


1.0

Switch output operation



Contact number	WFK3004C	WFK3012C	WFK3032C
1	0.6	2.0	5.0
2	0.7	3.0	9.0
3	0.8	4.0	12
4	0.9	5.0	14
5	1.0	6.0	16
6	1.5	7.0	18
7	2.0	8.0	21
8	2.5	9.0	24
9	3.0	10	27
0	3.5	11	30

0.1



Hysteresis

Specifications of mounted devices

■ Specifications of WFC flow sensor part

Item			150 (WFC-150)	600 (WFC-600)	
Rated flow range			0.5 to 15 L/min	2.0 to 60 L/min	
Available fluid conductivity			5 μS/cm or more		
Repeatability *1			±6.0% F.S		
Response time *2			0.25 s/0.5 s/1 s/2 s/5 s (default 1 s)		
Switch Output			NPN or PNP transistor output		
Max. load current		ent	50 mA		
Max. applied voltage Internal Voltage Drop		oltage	30 VDC		
		e Drop	NPN: 2.0V or less PNP: 2.4 V		
Analog Output Voltage output Current output		Voltage output	Voltage output: 1 to 5 V load impedance: 50 kΩ or more		
		Current output	Current output: 4 to 20mA, load impedance: 500 Ω or less		
Indicator			Dual screen display (top: 4-digit 7 segment green/red, bottom: 6-digit 11 segment white)		
Power Supply Voltage			24 VDC ±10% (ripple P-P ±10% or less)		
Current Consumption			65 mA or less		

^{*1:} Characteristics when the response time is 5 s.

Wiring method


· Always read the safety precautions before wiring.

Connectors used are VA connectors (model No.: TM-4DSX3HG4)


made by Correns Corporation. Specifications: For DC, 4-conductor 0.5 mm²

Cable model No.: TM-4DSX3HG4 L-type cable model No.: VA-4DLX3HG4

	Switch output	Analog Output
-NV	NPN transistor output	1 to 5 [V]
-NA		4 to 20 [mA]
-PV	PNP transistor output	1 to 5 [V]
-PA		4 to 20 [mA]



1) -NV, -NA




...Connectto DC power supply plus [+]: 24 VDC ±10%

...Switch output (NPN) : MAX.30 VDC 50 mA

Connect to [-] of DC power supply: 0 VDC

2) -PV, -PA



...Connect to DC power supply plus [+]: 24 VDC ±10%

: Voltage outputs current in proportion to

flow rate

: Analog output/switch input /Remote zero adjustment or accumulation reset

...Switch output (PNP) : MAX.50 mA


— Connect to [-] of DC power supply: 0 VDC

^{*2:} The response time to reach 63% of the value in relation to the step input.


^{*3:} Piping port and body metal part are grounded to DC (-)/blue wire. This product cannot be used in (+) ground power supply.



Functions



Output mode and output operation



Specifications of mounted devices

Measurement mode

[Normal screen]

•	1			
	Hysteresis mode	Window comparator mode	Accumulated output mode	Integrated pulse output mode
	P 1 5.0	M INGOM	0 ΩΩ 1234L	0.0 IL / P
	Analog Output	Digital input: Remote zero adjustment	Digital input: Accumulation reset	Alarm output mode
nstantaneous Flow Rate Display	0 	0 ΩΩ≥ 26Ro	0 ΩΩ RESEL	O OO B Alarm
	Flow Direction		Select any character	No sub-screen display
	O	0 <u>∏</u>		
Total accumulated flow display	0000	Jp key: ▲, Down key: Accumulate switched to "L", "kL", "ML" with ▼.		

Easy setting (shortcut mode)

By shortcut operation, settings with high frequency of use can be moved from the normal screen to the settable state.

y shortcut operation, settings with high frequency of use can be moved from the normal screen to the settable state.					
Main screen	! Normal screen	(Current screen blinks)	• :00s	☐ or ☐"Instantaneous value display", "total integrated value display" are selected and confirmed	
	<u> </u>		9888	with .	
Hysteresis mode	0 00s	or 🗸	• 00 3		
Accumulated output mode	F 1 3.0		:r.,,,,,,,u;		
Accumulated output mode	1234L	+ 🗆	0.00 € (1239£)	☐ Integrated value is reset with .	
Analog output mode	F5 100		• 00 •	□ F.S. is changed with or □ and confirmed with □ .	
Flow Direction	° 0.0e >	or 🗸		☐ Flow direction is changed with or ☑ and confirmed with ☐ .	
Total integrated value reset	°8888	+ 🗆	9888	☐ Reset by . ☐ can be canceled by or ☑.	
Setting key lock	Normal screen	+ (Hold down for 2 seconds or more) 1 second after setting	ONLOCK:	△ changed in or ☑ and confirmed □ with .	