

# INSTRUCTION MANUAL FOR










HB3,HB4

INSTRUCTION MANUAL  
FOR  
SOLENOID VALVE  
MODEL : HB3,4

This manual is your introduction to CKD HB3,4 and will give valuable information on the installation,operation and maintenance servicing of those types Solenoid Valve.

INDEX

·Cautions for use	2
·Maintenance servicing	
-1. Periodical check	3
-2. Maintenance instruction	3
Kit code for consumable parts	4
disassemble drawing	5
·Trouble shooting manual	
-1. Noise is appeared in case electric power supplies	6
-2. Fluid is not flowed	7
-3. Flowing fluid is not stopped	8

 <ul style="list-style-type: none"> <li>○ Perform flushing at 3kgf/cm<sup>2</sup> before connecting the pipe, and remove all dirt, metal powder, seal tapes and rusts.</li> </ul>	 <ul style="list-style-type: none"> <li>○ Always use the fluid temperature below 60°C. Use the specified coil (option : H type coil kit) if 60°C or higher.</li> </ul>
 <ul style="list-style-type: none"> <li>○ Don't use in the corrosive or explosive gas atmosphere. Select suitable valve materials for operation in the corrosive gas atmosphere.</li> </ul>	 <ul style="list-style-type: none"> <li>○ Always use the ambient temperature below 60°C. Use H type coil (option) if 60°C higher.</li> </ul>
 <ul style="list-style-type: none"> <li>○ Always use below the pressure rating. If the valve is used above the pressure rating, it may lead to malfunction. Also the service life may be shortened extremely.</li> </ul>	 <ul style="list-style-type: none"> <li>○ Excessive use of sealing material (seal tape, jelly like seal material, etc), when piping, may lead to entry of it into the solenoid valve which disturbs normal operation.</li> </ul>
 <ul style="list-style-type: none"> <li>○ In case the solenoid valve is equipped, use within the voltage fluctuation range, otherwise the valve may malfunction and the coil may be burned.</li> </ul>	 <ul style="list-style-type: none"> <li>○ Dusts, foreign materials, etc in the fluid may disturb normal function of the solenoid valve. In stall filter in the case of air and a strainer in the case of fluid.</li> </ul>
 <ul style="list-style-type: none"> <li>○ Solenoid coil is operable with continuous rating. Though the temperature of coil surface increases high and contacting with hand gives hot feeling it is a normal condition of operation.</li> </ul>	

## Maintenance servicing

- 1. Periodical check  
1-2 times periodical check in one year leads to its long life operation. Be cautious of obstruction of rust in the pipes, oil oxide, carbon and coaltar in the compressor, and dust, due to smooth operation and long life operation.
- 2. Maintenance instruction
  - 1) Electric power, pressure and fluid should not be supplied at disassembled.
  - 2) Disassemble method should be referred to attached disassemble drawing.
    - a) Unfasten and take off the nut ①, then ②③④⑤ can be taken off.
    - b) Unfasten and take off the core assembly ⑥, then ⑦⑧⑨ can be taken off. However, in this case, note that core assembly should not be turned while seized at the pipe of core assembly.
  - 3) Clean each parts with carbon tetrachloride, herosene or equivalent.  
Note : Rubber parts should be replaced due to possible swelling by the solvent.
  - 4) Consumable parts which are ※ marked on disassemble drawing are prepared as one kit.

5) Consumble part

	HB3	HB4
⑦⑧⑨	PLUNGER ASS'Y	

6) Reassembling is the reversal of the disassemble.

Note : Coil ④ can be rotated freely.

7) Inspection after reassembly.


a) Electrical check : By switching ON / OFF , operation sound shall be checked.

b) Leakage check : Check leakage by suppling pressure.

c) Operation check : By switching ON / OFF , correct operation shall be checked.

## Disassemble drawing

Model : HB3 HB4




## Disassemble tools


Parts name	Tool	Standard
Nut	Spanner	17mm
Core assembly	Spanner	27mm

Noise is appeared in case electric power supplies followings should be checked.

Electrical Check




Fluid Check YES




YES


Disassemble Check



Operating method and frequency Check



Judgement



Over life





Excessive temperature of fluid  
Excessive pressure of fluid

Poor quality of fluid  
Poor quality of fluid

Nonuse of strainer or fluid carelessness at piping

Fluid is not flowed  
Followings should be checked :

Electrical check





Flowing fluid is not stopped  
Followings should be checked :

Page \_\_\_\_8\_\_\_\_

### Piping check

Piping method is right

NO → Correct

### Electrical check

Electric circuit is OFF

NO → Correct

In case electrical power supplies , noise is appeared

YES

NO

Because of coil burning, exchange coil (4)

Excessive temp. of fluid

Excessive viscosity of fluid

Excessive pressure of fluid

Unusual voltage

Excessive temp. in surroundings

### Fluid check

Fluid pressure is pertinent

NO

Correct fluid pressure or change model

Fluid viscosity is within 50 cst

NO

Change model

Fluid temperature is pertinent

NO

Change model

Nonuse of strainer or filter

Carelessness at piping

### Disassemble Check

Dust and foreign object is not inside

NO

Wash inside

Poor quality of fluid

Plunger (8) is not adhered

NO

Wash the core assembly , and exchange plunger (8) and spring (7)

Intermixture of dust and foreign object

Broken spring

Excessive viscosity of fluid

Intermixture of dust and foreign object

Valve seat is not wounded

NO

Exchange body (10)

Valve sheet is not seperated

NO

Exchange plunger(8)

Valve sheet is not wounded

NO

Exchange plunger(8)

Valve sheet is not transformed

NO

Exchange plunger(8)

Spring is not broken

NO

Exchange spring(7)

Over life  
Excessive temp. of fluid

### Operating method and frequency check

Operating frequency and year

Over life

Continuous voltage is too long

YES

Surrounding temperature

Judgement

Over life

Poor operating method

Poor selection

Defective assembly