


Xeroaqua

Operation Manual



Meets to a "Specific Fleon control" Applicable models

- RD1000(A) ●RDM1000(A)
- RD2000(A) ●RDM2000(A)

series

Thank you for purchasing "Xeroaqua", refrigerated air dryer.

●Read this manual well before running the dryer.

●Carefully comply with suggestions provided because an erroneous operation may hinder its full function or cause some malfunction, sometimes hazards.

●The guarantee is valid within Japan only, as described on the Guarantee certificate.

I N D E X

| | page | | page |
|---|-------|---|-------|
| Confirm first | ...1 | Periodic inspection and maintenance | ...11 |
| Range of service and suitable compressor | ...1 | Expendable parts list | ...12 |
| Components and functions | ...2 | Storage over an extended term | ...12 |
| Specific cares required | ...3 | Trouble shooting (Digital monitor type) | ...13 |
| Installation | ...5 | Trouble shooting (Analog monitor type) | ...14 |
| Operational procedures (Digital monitor type) | ...7 | After service and guarantee | ...15 |
| To stop running | ...8 | External dimensions | ...16 |
| When halted by safety device | ...8 | Specifications | ...18 |
| Operational procedures (Analog monitor type) | ...9 | Note | ...20 |
| To stop running | ...10 | | |
| When halted by safety device | ...10 | | |

CONFIRM AT FIRST

CONFIRM
AT
FIRST

Confirm the contents on the name-plate such as model No., specification etc.


REFRIGERATED AIR DRYER

| | |
|---------------|------------|
| POWER | MAX.PRESS. |
| MAX.AIR TEMP. | AIR.FLOW |
| CURRENT | MASS |
| REFRIGERANT | SERIAL No. |

Model No.

※ Contact immediately with the supplier delivered it, should there be any questions concerning contents of description, instead of starting it.

Illustrated is Digital monitor type dryer.



Enclosed items

Save this manual after copying the contents on name plate onto Page 20.

Guarantee Certificate... 1


Operation Manual... 1

RANGE OF SERVICE AND SUITABLE COMPRESSOR

| Air flow, rated disposition (m ³ /min ,) | | ~0.1/0.11 | 0.2/0.22 | 0.31/0.35 | 0.5/0.55 | 0.74/0.81 | 1.1/1.2 | 1.65/1.8 | 2.5/2.7 |
|---|--------------------------|-----------|----------|-----------|----------|-----------|---------|----------|---------|
| Suitable compressor capacity (kW) | | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 | 11 | 15 |
| Working Pressure 0.2~1.0 MPa | Air inlet temp. (5~55°C) | RD2001 | RD2002 | RD2003 | RD2004 | RD2006 | RD2008 | RD2011 | RD2015 |
| | Air inlet temp. (5~35°C) | - | - | RD1003 | RD1004 | RD1006 | RD1008 | RD1011 | RD1015 |
| Working Pressure 0.2~1.5 MPa | Air inlet temp. (5~55°C) | RDM2001 | RDM2002 | RDM2003 | RDM2004 | RDM2006 | RDM2008 | RDM2011 | RDM2015 |
| | Air inlet temp. (5~35°C) | - | - | RDM1003 | RDM1004 | RDM1006 | RDM1008 | RDM1011 | RDM1015 |


- Model codes suffixed with "A" designate dryers of Analog monitor type.

Digital monitor



Refer to Pages 7 & 8 as for its operation.


Analog monitor



Refer to Pages 9 & 10 as for its operation.


COMPONENTS AND FUNCTIONS

XEROAQUA, DIGITAL MONITOR TYPE



COMPONENTS
AND
FUNCTIONS




XEROAQUA, ANALOG MONITOR TYPE



SPECIFIC CARES REQUIRED




DURING TRANSPORTATION

- To lift the dryer, use grip ears provided on both sides of frame.
Make use of room for forks on the base to lift such large models as RD1008, 2006 or over.
- No stepping on a dryer.
- Avoid laying on its side or up side down.



AMBIENT CONDITION



- Prevent to install it where corrosive gas exists or rain falls over it.
- Prevent to install it exposing to direct sun ray or where heat generates. Add an exhaust fan or cool air outlet where heat accumulation is foreseen, to keep ambient temperature below 40°C.
- Dewfall may take place on the secondary pipe in humid summer days. Drape insulation over pipe if it were the case.



- Do not use the dryer for pneumatic caisson shield or respiratory medical equipment.
* It could cause an accident includes injury.
- Do not use the dryer for transportation devices such as automobile, ship etc.
* Vibration could be a cause of break down of the internal components.



INSTALLATION

- Provide enough room for ventilation as well as for maintenance service in future.
- Fix the unit with anchor metal pieces. (Refer to page 5 for detail.)



DURING TRANSPORTATION ELECTRIC




- Set a grounding wire to prevent electric shock.
- Install a circuit breaker on the main power line.



SPECIFIC
CARES
REQUIRED


OPERATION

- Operate it within the range specified.
- Hold frequency of starting/shutting off within 6 times/hour, keep it running for at least 5 minutes before shutting it off and hold restarting it for 3 minutes or longer. (Possible mechanical difficulties, otherwise.)
- Keep hands off the unit because there are high speed fan, heat accumulated compressor and copper tubes.



WHEN POWER FAILS


- It resumes running automatically upon recovery of power when intervals longer than 1 minute. By the contrary, dryer may make an emergent stop in the event of instantaneous failure.




INSTALLATION

① CONFIRM THE LOCATION

- Select horizontal and rigid plane.




- Install the unit keeping its front side facing you.




② INSTALL THE UNIT RIGIDLY

- Fix it to the floor to prevent its vibration or violent fall during operation.

Models RD(M)1003 ~ 1006(A) or 2001 ~ 2004




- ① Fix its base to floor directly.



- ② Fix it with exclusive anchor metal pieces. (Optional: Code No. F4-222916)

Models RD(M)1008 ~ 1015(A) or 2006 ~ 2015






Fix its base to floor with anchor bolts.

③ PLUMBING


- Confirm Inlet and Outlet.
- Make sure to install an air-filter (5 μ) immediately in front of dryer inlet.

| Xeroaqua | Suitable air filter (5 μ) |
|-------------------------|--------------------------------|
| RD2001~2004-RD1003~1004 | F3000-10 |
| RD1006,RD2006 | F4000-15 |
| RD1008~1011-RD2008~2011 | F8000-20 |
| RD1015,RD2015 | F8000-25 |

- Make sure to use Union type joints on Inlet and Outlet.
- In the event that air supply is required during the course of maintenance, apply by-pass plumbing. (By-pass set is optionally available.)
- Use galvanized ones, as for steel pipes.
- Make sure to give pipe system flushing before its final connection so as to prevent dusts or foreign particles from falling into air circuit.



DIRECT PLUMBING




BY-PASS PLUMBING

- The drain purge outlet diameter of dryer unit is Rc1/4. Use the tube of inner diameter $\phi 7$ or larger (Recommended tube ; F-1510) and prevent plumbing of standing up right.


④ INSTALL A CIRCUIT BREAKER

- Install it within the circuit. (Refer to the Table, on next page as for suitable models.)

Xeroaqua Single phase




Xeroaqua Three-phase




Use either
® ~ Ⓢ or Ⓢ ~ ①
combination.

⑤ WIRING


- Cut out a hole (for power line and grounding wire) to rubber busing on lower part of left side panel of unit.



- Use vinyl cabtier cord (300V, VCTF1.25mm² or more) to connect a circuit breaker with terminal block, inside of unit.



Applicable for AC100V, only.




- A cable cord (1.5m long) with a plug is provided to the unit. Plug into a socket via circuit breaker. (Make sure to connect grounding wire appropriately.)

INSTALLATION


- Use 2-core cable for single phase as well as 3-core cable for 3-phase power. Use the cable over VCT1.25mm² in the event that the power is over 300v
- When Xeroaqa dose not work at trial, event if you turn power on, change 2-wire among 3-wire of 3-phase. {RD(M)2011(A),RD(M)2015(A)}
- Put transparent cover on terminal block after electrical wiring.

⑥ GROUNDING

- Prepare a piece of grounding wire (KIV cord, over 2 5mm²)
- Connect the grounding wire to the terminal block E in the unit as well as to the grounding terminal in a control panel.



Example of wiring




CAUTION : Never connect the grounding to neither water supply tube, gas tube nor lightning conductor.

Table of capacity circuit breaker

| MODEL No. | | CAPACITY |
|---------------------------|---------------------------|----------|
| RD1003(A)~1004(A)-AC100V | RD2001(A)~2002(A)-AC100V | 5A |
| RDM1003(A)~1004(A)-AC100V | RDM2001(A)~2002(A)-AC100V | |
| RD1003(A)~1008(A)-AC200V | RD2001(A)~2004(A)-AC200V | |
| RDM1003(A)~1008(A)-AC200V | RDM2001(A)~2004(A)-AC200V | |
| RD1006(A)~1015(A)-AC100V | RD2003(A)~2008(A)-AC100V | 10A |
| RDM1006(A)~1015(A)-AC100V | RDM2003(A)~2008(A)-AC100V | |
| RD1011(A)~1015(A)-AC200V | RD2006(A)~2008(A)-AC200V | |
| RDM1011(A)~1015(A)-AC200V | RDM2006(A)~2008(A)-AC200V | |
| RD2011(A)~2015(A)-AC200V | | 10A |
| RDM2011(A)~2015(A)-AC200V | | |

The sensing current of the earth leakage breaker is 30mA




OPERATIONAL PROCEDURES (Digital monitor type)


① TURN POWER ON

① Unit is set for "Automatic running" at ex-factory shipment. Confirm it by opening front panel of the unit.

② Simply slide the power switch knob on the unit to the ON marking.




In order to open the front panel, insert nominated size 5 or 3/16 hexagonal bar spanner into hexagonal hole in the center, and turn the spanner clockwise until triangle mark moved to 「UNLOCK」 from 「LOCK」.
When closing it, turn the spanner reversely to 「LOCK」 position.



② CONFIRM MONITOR LAMPS

● DEW POINT AUTO LAMP is lit.
(The lamp this time indicates ambient temperature.)

● It starts running automatically when air pressure exceeds 0.17MPa and RUN LAMP is lit, then. DEW POINT LAMP moves into Green zone indicating Dew point in relation with the air pressure.




**NORMAL
OPERATION**

Note : Fan sometimes repeats "Run and stop" but this is normal.

<<WHEN MANUAL OPERATION IS PREFERRED>>


① TURN POWER SWITCH OFF.

● Be sure to shut power OFF before doing any adjustment.




② SET THE SHIFTING SWITCH TO MANUAL SIDE.

● Open the front panel and shift the switch.



③ TURN THE POWER SWITCH ON.


● Close the front panel and turn the power switch ON.



CAUTION : Once the unit is started, keep it running for at least 5 minutes before turning it OFF and hold restarting for 3 minutes or longer.

④ CONFIRM THE MONITOR LAMP


● RUN LAMP is lit and the unit starts running immediately after the power switch turned ON, DEW POINT LAMP then steps into green zone indicating dewpoint in relation with the air pressure.



**NORMAL
OPERATION**


Note : Fan sometimes repeats "Run and stop" but this is normal.

STOPPING OPERATION




- Under "Automatic operation" mode, the unit automatically stops its running when air pressure drops below 0.07MPa.

STOP!!



Turn the power switch in the unit or power line switch OFF when to make the unit stop regardless the air pressure.




STOPPING
OPERATION

WHEN HALTED BY SAFETY DEVICE


POSSIBLE CAUSES BY AN ELECTRIC CIRCUIT

- Motor protector shuts off the unit when either refrigerator is overheated or overcurrent is charged.
In this event, **MONITOR ALARM LAMP** is lit.




POSSIBLE CAUSES BY A REFRIGERANT CIRCUIT

- Temperature sensor shuts off the unit when it detects an abnormal rise of refrigerant temperature.
In this event, **MONITOR ALARM LAMP** is lit.




HOW TO RESET IT


1. Turn the main power line and power switch in the unit OFF. It is, then ready to be reset.
2. Give remedy of abnormal stop. (Refer to the Table of "Trouble shooting", page 13.)
3. Turn main power line switch and unit power switch ON once again.



Page
P13



In case when motor protector functioned, it may, sometimes, not restart immediately. (ALARM LAMP is lit in this case, when power switch is turned ON.) Wait till refrigerator cools off while keeping power OFF.




Discontinue


OPERATIONAL PROCEDURES (Analog monitor type)

① TURN POWER ON

- ① Unit is set for "Automatic running" at ex-factory shipment. Confirm it by opening front panel of the unit.
- ② Simply slide the power switch knob on the unit to the ON marking.




In order to open the front panel, insert nominated size 5 or 3/16 hexagonal bar spanner into hexagonal hole in the center, and turn the spanner clockwise until triangle mark moved to 「UNLOCK」 from 「LOCK」.
When closing it, turn the spanner reversely to 「LOCK」 position.



② CONFIRM MONITOR LAMP

- it starts running automatically when air pressure exceeds 0.17MPa and RUN LAMP is lit, then.
- Indicator needle of DEW POINT GAGE, after 3~5 minutes elapse, moves into Green zone indicating Dew point in relation with the air pressure.



**NORMAL
OPERATION**


Note : Fan sometimes repeats "Run and stop" but this is normal.

<<WHEN MANUAL OPERATION IS PREFERRED>>

(Forced operation)


① TURN POWER SWITCH OFF.

- Be sure to shut power OFF before doing any adjustment.




② SET THE SHIFTING SWITCH TO MANUAL SIDE.

- Open the front panel and shift the switch.



③ TURN THE POWER SWITCH ON.


- Close the front panel and turn the power switch ON.



CAUTION :
Once the unit is started, keep it running for at least 5 minutes before turning it OFF and hold restarting for 3 minutes or longer.


④ CONFIRM THE MONITOR LAMP

- RUN LAMP is lit and it starts running immediately after the power switch is turned ON.
- INDICATOR NEEDLE OF DEW POINT GAGE, after 3~5 minutes elapse, moves into Green zone indicating Dew point in relation with the air pressure.



**NORMAL
OPERATION**


Note : Fan sometimes repeats "Run and stop" but this is normal.




- Under "Automatic operation" mode, it automatically stops its running when air pressure drops below 0.07MPa.



STOP!!



- Turn the power switch on the unit or power line OFF when to stop it regardless the air pressure.



STOPPING
OPERATION

WHEN HALTED BY SAFETY DEVICE

POSSIBLE CAUSES BY AN ELECTRIC CIRCUIT

1. Motor protector shuts off the unit when either refrigerator is overheated or overcurrent is charged.

POSSIBLE CAUSES BY A REFRIGERANT CIRCUIT



2. High pressure switch shuts off the unit when it detects an abnormal rise of refrigerant pressure.

Applicable


RD1015A-RD2008A-RD2011A-RD2015A
RDM1015A-RDM2008A-RDM2011A-RDM2015A

HOW TO RESET IT

- It resumes running automatically when refrigerator cools off or overcurrent is removed after emergent stop.
 - In case of emergent stop due to the cause of refrigerant circuit, push the red button of high pressure switch by opening front panel.
- ① Turn main line switch and unit power switch OFF.
 - ② As for the model with high pressure switch, push its red button after opening the front panel of the unit.
 - ③ Give a remedy to the cause of emergent stop. (Refer to the Table of Trouble shooting, page 14.)
 - ④ Turn main power line switch and unit power switch ON once again. In case when motor protector functioned, it may, sometimes, not restart immediately. Wait till refrigerator cools off. It restarts automatically then.



Page
14




In case high pressure switch functioned, it starts immediately when power switch is turned ON.

INSPECTION AND MAINTENANCE


SNAP DRAIN, ITS INSPECTION AND MAINTENANCE

● Carry out a weekly inspection of drain purger (Snap drain) by opening the front panel of unit.


① Turn the power OFF.



② Lift the finger ring on front panel and turn it clockwise



③ Inspect purger for abnormalities.



Abnormality is such as follows.

- Float is completely covered with accumulated drain.
- Float does not come down even after purging the drain.
- Drain drips in drop.
- Air continually exhausts through drain port.

④ Close the front panel when no abnormality is disclosed.

Clean the purger complying with the following procedures if there is any abnormality or replace it with new set otherwise.

● Cleaning procedures of drain purger (Snap drain)

① Shut off the air supply.
(In case it is the model with by-passing set, open the by-pass valve and close both the primary as well as the secondary valve of the unit.)

② Open the front panel. Discharge accumulated air within the unit.


•RD1000/2000 series

Turn the drain cock of purger counterclockwise to purge drain as well as air.




•RDM1003~1006 or 2001~2004

Discharge air by turning pet cock counterclockwise. It is located underneath of air inlet to purger.




•RDM1008~1015 or 2006 ~ 2015


Discharge air by turning pet cock counterclockwise. It is located upper part of purger.




④ Bowl assembly comes down when it is pulled after turning it clockwise for approx. 45 degrees while holding latch of bowl guard pressed.



⑤ Remove the screen atop of bowl ass'y and clean it.



⑥ Pour a little bit of water into the bowl and shake bowl well to let dirt over float come out.




⑦ Place the washed screen back to the original place and assemble purger back complying with the reversed sequences as disassembled.

⑧ Close drain cock as well as pet cock.

⑨ Replace the cleaned ass'y with new set if the former set, by any reasons, does not function right.

STRUCTURE OF PURGER (SNAP DRAIN)




Drain water may spout out at the moment of opening pet cock if water is full in purger. Carefully prevent water from splashing over electric equipments.


DUSTS FILTER

● Blow dusts away from screen with air gun once a month.


① Turn the power OFF.



② Open the front panel.




③ Take out the dust filter



Peel off the filter by pulling its edge as it is mounted by means of a set of magic tapes.

④ Blow dusts off the screen using an air gun.







Note : Wash the screen if it is filthier or replace it with new one.

⑤ To mount filter back, press the reverse face of magic tape well.



④ Close the front panel.

EXPENDABLE PARTS LIST


| No. | Expendable parts | Model code | Drawing No. (Parts No.) | Quantity | General appearance | Remarks |
|-----|---------------------------|---|----------------------------|----------|--|------------------------------|
| 1 | Drain purger | RD1003(A),2001A(A) | F4-221058 | 1 |  | |
| | | RD1004(A)~1015(A) | F4-205611 | 1 | | |
| | | RD2002(A)~2015(A) | | | | |
| | | RDM1003(A),2001A(A) | F4-221060 | 1 |  | |
| | | RDM1004(A),1015(A) | | | | |
| | | RDM2002(A)~2015A | F4-218470 | 1 | | |
| 2 | Condenser filter | RD(M)1003(A),2001(A) | F3-217238 | 1 |  | |
| | | RD(M)1004(A),1006(A) | | 1 | | |
| | | RD(M)2002(A),~2004(A) | F3-217239 | | | |
| | | RD(M)1008,(A),1011(A) | | 1 | | |
| | | RD(M)2006(A) | F3-217240 | | | |
| | | RD(M)1015(A),2008(A) | F3-217241 | 1 | | |
| | | RD(M)2011(A) | F3-217242 | 1 | | |
| | | RD(M)2015(A) | F3-217243 | 1 | | |
| 3 | Sealed fuse in glass fuse | RD(M)1003~1015 RD(M)2001~2015 RD(M)2011A, RD(M)2015A | 1ampere | 1 |  JIS MF-60-NR type | An equivalent is acceptable. |

RD (M) ※※※※ in this table designates that it is commonly applicable to either models RD※※※※ or RDM ※※※※.(A) designates that it is commonly applicable to either Digital monitor type (without A) or Analog monitor type (with A).

STORAGE OVER AN EXTENDED TERM


- Keep the dryer in custody complying with the following procedures when to put it away from service over an extended term.

1.Shut off the circuit breaker.




2.Purge drain.

Purge it completely by turning drain cock on purger.




Note : As for model RDM (Medium pressure type), disassemble a glass bowl to purge drain as there is no drain cock provided.

3. Carefully select an appropriate location for storage.




Keep it in custody by placing a cover sheet over it in the place where trash, dust, rain, dew, humidity or direct sun beam is expected the least.

4.When to resume its service.



Upon completion of a careful inspection to every part of dryer, resume its service complying with Installation and Operation procedures of this manual.




Discontinue

TROUBLE SHOOTING (DIGITAL MONITOR TYPE)

| STATE OF MALFUNCTION | | | POSSIBLE CAUSES OF TROUBLES | REMEDIES |
|--|---|----------------------------|---|--|
| No starting when switch is turned ON | Automatic operation | Auto lamp is not lit. | <ul style="list-style-type: none"> Power is not turned ON. Abnormal voltage of power line Bad power switch | <ul style="list-style-type: none"> Turn the power ON. Regulate the voltage to specified. Replace the switch. |
| | | Dew point lamp is not lit. | <ul style="list-style-type: none"> Bad lamp Burnt out fuse | <ul style="list-style-type: none"> Replace the electronic monitor. Replace the fuse. |
| | | Run lamp is not lit. | <ul style="list-style-type: none"> Power is not turned ON. Abnormal voltage of power Bad power switch Bad lamp Burnt out fuse Insufficient air pressure | <ul style="list-style-type: none"> Turn the power ON. Regulate the voltage to specified. Replace the switch. Replace the electronic monitor. Replace the fuse. Regulate it to be over 0.17MPa. |
| | | Run lamp is not lit. | <ul style="list-style-type: none"> Protective device of refrigerating circuit in function. | <ul style="list-style-type: none"> Turn power switch OFF once and rese it. |
| | Manual operation | Run lamp is not lit. | <ul style="list-style-type: none"> Power is not turned ON. Abnormal voltage of power Bad power switch Bad lamp Burnt out fuse | <ul style="list-style-type: none"> Turn the power ON. Regulate the voltage to specified. Replace the switch. Replace the electronic monitor. Replace the fuse. |
| | | Dew point lamp is not lit. | <ul style="list-style-type: none"> Power is not turned ON. Abnormal voltage of power Bad power switch Bad lamp Burnt out fuse | <ul style="list-style-type: none"> Turn the power ON. Regulate the voltage to specified. Replace the switch. Replace the electronic monitor. Replace the fuse. |
| | | Alarm lamp is lit. | <ul style="list-style-type: none"> Protective device of refrigerating circuit in function. | <ul style="list-style-type: none"> Remove the causes of protector functioning and reset it. |
| | | | | |
| Abnor-mal dew point | Amber lamp in high temperature side of Dew point lamp is lit. | | <ul style="list-style-type: none"> Refer to the Article (※) Water comes out, left column. | |
| | Amber lamp in low temperature side (below 0) of Dew point lamp is lit. | | <ul style="list-style-type: none"> Improper adjustment of dryer. | <ul style="list-style-type: none"> Adjust the dryer. |
| Water comes out of the systm end during operation. | Water comes out of the system end while dew point is normal. | | <ul style="list-style-type: none"> Malfunction of drain purger. Purger is fozen. Ambient temperature is below 0 °C. Improper adjustment of dryer. | <ul style="list-style-type: none"> Disassemble purger to clean or replace it with a new one. Halt the dryer and give some remedies to prevent tube from freezing. Readjust the dryer. |
| | (※) Water comes out of the system end while dew point lamp is either yellow or amber. | | <ul style="list-style-type: none"> Refrigerant gas leaked. Ambient temperature is excessively high. High temperature air at inlet Excessive consumption of air flow Clogged filter of condenser Insufficient ventilation Bad fan motor | <ul style="list-style-type: none"> Refill the gas. Provide a ventilation to keep ambient temperature below 40 °C. Cool off the inlet temperature brlow specified. Regulate to operate it within specified velocity. Clean the condenser filter. Improve the ventilation. Replace the fan motor. |
| Stops unexpectedly. | Run lamp is not lit while Auto lamp (auto run) is lit. | | <ul style="list-style-type: none"> Air pressure is low. | <ul style="list-style-type: none"> Adjust the air pressure to be more than 0.17MPa. |
| | Alarm lamp is lit. | | <ul style="list-style-type: none"> Protective device of refrigerating circuit in function. | <ul style="list-style-type: none"> Remove the causes of protector functioning and reset it. Refer to the Article (※) Water comes out, left column. |
| | All lamps are extinguished. | | <ul style="list-style-type: none"> Power was cut OFF. Abnormal voltage of power Bad power switch Bad digital monitor Burnt out fuse | <ul style="list-style-type: none"> Turn power line ON. (Inspect for cutwire and bad conduction.) Regulate to specified voltge. Replace the switch. Replace the digital monitor. Replace the fuse. |

TROUBLE SHOOTING (ANALOG MONITOR TYPE)



| STATE OF MALFUNCTION | | | POSSIBLE CAUSES OF TROUBLES | REMEDIES |
|---|---|----------------------|---|--|
| No starting when switch is turned ON | Automatic operation | Run lamp is not lit. | <ul style="list-style-type: none"> Power is not turned ON. Bad lamp Low air pressure Protective device of refrigerating circuit in function. | <ul style="list-style-type: none"> Turn the power ON. Replace the lamp. Adjust the pressure to be over 0.17MPa. Wait till the refrigerator cools off. Reset it by pushing back the button, in case the high pressure switch button has popped out. |
| | Manual operation | Run lamp is not lit. | <ul style="list-style-type: none"> Bad lamp Protective device of refrigerating circuit in function. | <ul style="list-style-type: none"> Replace the lamp. Wait till the refrigerator cools off. Reset it by pushing back the button, in case the high pressure switch button has popped out. |
| Water comes out of the system end during operation. | Water comes out of the system end while dew point is normal. | | <ul style="list-style-type: none"> Malfunction of drain purger. Purger is frozen. Ambient temperature is below 0°C. Improper adjustment of dryer. | <ul style="list-style-type: none"> Disassemble purger to clean or replace it with a new one. Halt the dryer and give some remedies to prevent tube from freezing. Halt the dryer and give some remedies to prevent tube from freezing. Readjust the dryer. |
| | (※) Water comes out of the system end while dew point indicator needle is above green zone. | | <ul style="list-style-type: none"> Refrigerant gas leaked. Ambient temperature is excessively high. High temperature air at inlet Excessive consumption of air flow Clogged filter of condenser Insufficient ventilation Bad fan motor | <ul style="list-style-type: none"> Recharge the gas. Provide a ventilation to keep ambient temperature below 40 °C. Cool off the inlet temperature below specified. Regulate to operate it within specified velocity. Clean the condenser filter. Improve the ventilation. Replace the fan motor. |
| Stops unexpectedly. | Run lamp is extinguished. | | <ul style="list-style-type: none"> Power was shut off. Abnormal power voltage Bad power switch Protective device of refrigerating circuit in function. Low air pressure (This is the case of automatic operation.) | <ul style="list-style-type: none"> Turn power ON. (Inspect for cut wire and bad conduction.) Regulate to specified voltage. Replace the switch. Remove the causes of protector functioning. <p>Refer to the Article (※) Water comes out, left column.</p> <ul style="list-style-type: none"> Adjust the air pressure to be higher than 0.17MPa. |

TROUBLE SHOOTING (ANALOG MONITOR TYPE)

AFTER SERVICE AND GUARANTEE

GUARANTEE CERTIFICATE

- There is a guarantee certificate attached to XEROAQUA, refrigeration type air dryer, products of CKD Co., Ltd.

After confirming the entries to the certificate such as "Date of purchase, Name of supplier, etc.", keep it in custody upon reading the extent of guarantee, well.

Should there be any difficulties, repair services will be provided in accordance with provisions on guarantee.

VALIDITY TERM IS ONE YEAR FROM THE DATE OF PURCHASE.

REPAIR SERVICE

- Contact with the supplier concerning with repair service. Consult with CKD's business office nearby you, in the event that the supplier is unable to provide service.

(Refer to the rear cover of this manual as for our business offices.)

- Inform the followings when requesting repair service.



- Model No.
- Serial No.
- Date of Installation
- Name of Supplier
- General States of malfunction

REPAIR SERVICE AFTER EXPIRATION OF GUARANTEE TERM

- Repair services after the term will also be carried out to your satisfaction recognizing our responsibility. Contact supplier, please.

Repair service will be rendered with nominal charge complying upon your demand. Service parts will be availed for 5 years after discontinuation of production.

EXTERNAL DIMENSIONS




EXTERNAL
DIMENSIONS

RD2000 · RDM2000
SERIES


EXTERNAL DIMENSIONS

This drawing is for Digital monitor type.



| Markings | A | B | C | D | E | F | G | H | I |
|------------|-----|-----|-----|-----|-----|-----|----|-----|-------|
| RD1003(A) | 460 | 430 | 440 | 430 | 150 | 240 | 80 | 303 | Rc3/8 |
| RD1004(A) | 550 | 520 | 440 | 430 | 150 | 240 | 80 | 303 | Rc3/8 |
| RD1006(A) | 550 | 520 | 440 | 430 | 150 | 240 | 80 | 303 | Rc1/2 |
| RDM1003(A) | 460 | 430 | 440 | 430 | 150 | 240 | 80 | 303 | Rc3/8 |
| RDM1004(A) | 550 | 520 | 440 | 430 | 150 | 240 | 80 | 303 | Rc3/8 |
| RDM1006(A) | 550 | 520 | 440 | 430 | 150 | 240 | 80 | 303 | Rc1/2 |

This drawing is for Digital monitor type.



| Markings | A | B | C | D | E | G | H | I | J | K | L | M | N |
|------------|-----|-----|-----|-----|-----|-----|-----|-----|------|-----|-------|----|----|
| RD1008(A) | 750 | 690 | 570 | 560 | 380 | 90 | 195 | 155 | 97.5 | 155 | Rc3/4 | 60 | 75 |
| RD1011(A) | 750 | 690 | 570 | 560 | 380 | 90 | 195 | 155 | 97.5 | 155 | Rc3/4 | 60 | 75 |
| RD1015(A) | 810 | 750 | 630 | 620 | 440 | 120 | 195 | 155 | 97.5 | 155 | Rc1 | 60 | 75 |
| RDM1008(A) | 750 | 690 | 570 | 560 | 380 | 90 | 195 | 155 | 97.5 | 155 | Rc3/4 | 60 | 75 |
| RDM1011(A) | 750 | 690 | 570 | 560 | 380 | 90 | 195 | 155 | 97.5 | 155 | Rc3/4 | 60 | 75 |
| RDM1015(A) | 810 | 750 | 630 | 620 | 440 | 120 | 195 | 155 | 97.5 | 155 | Rc1 | 60 | 75 |

SPECIFICATIONS

■ RD2000 Series

| Model No | | RD 2001(A) | RD 2002(A) | RD 2003(A) | RD 2004(A) | RD 2006(A) | RD 2008(A) | RD 2011(A) | RD 2015(A) | |
|---|-----------------------------------|--|---------------|---------------|---------------|---------------|---------------|----------------------|---------------|---------|
| Applicable air compressor (kW) | | ~0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 | 11 | 15 | |
| Rating | Volume of disposed (m³/min A.N.R) | ~0.1/0.11 | 0.2/0.22 | 0.31/0.35 | 0.5/0.55 | 0.74/0.81 | 1.1/1.2 | 1.65/1.8 | 2.5/2.7 | |
| | Air pressure at inlet (MPa) | 0.7 | | | | | | | | |
| | Air temperature at inlet (°C) | 55 | | | | | | | | |
| | Ambient temperature (°C) | 32 | | | | | | | | |
| | Air dew point at outlet (°C) | 10(with pressure) | | | | | | | | |
| Working range | Working media | Compressed air | | | | | | | | |
| | Air temperature at inlet (°C) | 5~80 | | | | | | | | |
| | Ambient temperature (°C) | 2~40 | | | | | | | | |
| | Ambient humidity | 40~80%RH | | | | | | | | |
| | Working pressure (MPa) | 0.2~10 | | | | | | | | |
| Electric Specs. | Main power line | 100/200V single phase, 50/60Hz | | | | | | 200V 3-phase,50/60Hz | | |
| | Electricity consumption (kW) | 0.16/0.17 | 0.16/0.17 | 0.22/0.24 | 0.29/0.32 | 0.39/0.44 | 0.53/0.62 | 0.66/0.80 | 0.97/1.19 | |
| | Operating current | AC100V(A) | 2.0/2.1 | 2.0/2.1 | 2.6/2.8 | 3.4/3.6 | 4.6/4.8 | 5.8/6.4 | — | — |
| | | AC200V(A) | 1.0/1.0 | 1.0/1.0 | 1.3/1.4 | 1.7/1.8 | 2.3/2.4 | 2.9/3.2 | 2.6/2.8 | 3.8/4.2 |
| Details of apparatus | Operation type | Automatic operation by sensing air pressure (0.17MPa:ON,0.07MPa:OFF)and manual operation | | | | | | | | |
| | Condenser | Fin and tube type, forced air cooling method | | | | | | | | |
| | Refrigerant control method | Capillary tube | | | | | | | | |
| | Temperature control method | Hot gas by-pass type with capacitor valve | | | | | | | | |
| | Refrigerant | R22 | | | | | | | | |
| Port diameter of air inlet and outlet(Rc) | | 3/8 | | | | 1/2 | 3/4 | | 1 | |
| Port diameter of drain discharging(Rc) | | 1/4 | | | | | | | | |
| Mass (kg) | | 16 | 18 | 18 | 23 | 45 | 49 | 58 | 60 | |
| Calorie of heat emission (kW) | | 0.27 | 0.37 | 0.55 | 0.82 | 1.19 | 1.73 | 2.47 | 3.82 | |

■ RDM2000 Series

| Model No | | RDM 2001(A) | RDM 2002(A) | RDM 2003(A) | RDM 2004(A) | RDM 2006(A) | RDM 2008(A) | RDM 2011(A) | RDM 2015(A) | |
|---|--|-------------------|--|----------------|----------------|----------------|----------------|----------------------|----------------|-----------|
| Items | | | | | | | | | | |
| Applicable air compressor (kW) | | ~0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 | 11 | 15 | |
| Rating | Volume of disposed (m ³ /min A.N.R) | ~0.1/0.11 | 0.2/0.22 | 0.31/0.35 | 0.5/0.55 | 0.74/0.81 | 1.1/1.2 | 1.65/1.8 | 2.5/2.7 | |
| | Air pressure at inlet (MPa) | 0.7 | | | | | | | | |
| | Air temperature at inlet (°C) | 55 | | | | | | | | |
| | Ambient temperature (°C) | 32 | | | | | | | | |
| | Air dew point at outlet (°C) | 10(with pressure) | | | | | | | | |
| Working range | Working media | Compressed air | | | | | | | | |
| | Air temperature at inlet (°C) | 5~80 | | | | | | | | |
| | Ambient temperature (°C) | 2~40 | | | | | | | | |
| | Ambient humidity | 40~80%RH | | | | | | | | |
| | Working pressure (MPa) | 0.2~15 | | | | | | | | |
| Electric Specs. | Main power line | | 100/200V single phase, 50/60Hz | | | | | 200V 3-phase,50/60Hz | | |
| | Electricity consumption (kW) | | 0.16/0.17 | 0.16/0.17 | 0.22/0.24 | 0.29/0.32 | 0.39/0.44 | 0.53/0.62 | 0.66/0.80 | 0.97/1.19 |
| | Operating current | AC100V(A) | 2.0/2.1 | 2.0/2.1 | 2.6/2.8 | 3.4/3.6 | 4.6/4.8 | 5.8/6.4 | — | — |
| | | AC200V(A) | 1.0/1.0 | 1.0/1.0 | 1.3/1.4 | 1.7/1.8 | 2.3/2.4 | 2.9/3.2 | 2.6/2.8 | 3.8/4.2 |
| Details of apparatuses | Operation type | | Automatic operation by sensing air pressure (0.17MPa:ON,0.07MPa:OFF)and manual operation | | | | | | | |
| | Condenser | | Fin and tube type, forced air cooling method | | | | | | | |
| | Refrigerant control method | | Capillary tube | | | | | | | |
| | Temperature control method | | Hot gas by-pass type with capacitor valve | | | | | | | |
| | Refrigerant | | R22 | | | | | | | |
| Port diameter of air inlet and outlet(Rc) | | 3/8 | | | | 1/2 | 3/4 | | 1 | |
| Port diameter of drain discharging(Rc) | | 1/4 | | | | | | | | |
| Mass (kg) | | 16 | 18 | 18 | 23 | 45 | 49 | 58 | 60 | |
| Calorie of heat emission (kW) | | 0.27 | 0.37 | 0.55 | 0.82 | 1.19 | 1.73 | 2.47 | 3.82 | |

SPECIFICATIONS

RDM2000 Series

SPECIFICATIONS

■ RD1000 Series

| Model No | | RD 1003(A) | RD 1004(A) | RD 1006(A) | RD 1008(A) | RD 1011(A) | RD 1015(A) | |
|---|--|-------------------|--|------------|------------|------------|------------|---------|
| Items | | | | | | | | |
| Applicable air compressor (kW) | | ~2.2 | 3.7 | 5.5 | 7.5 | 11 | 15 | |
| Rating | Volume of disposed (m ³ /min A.N.R) | ~0.31/0.35 | 0.5/0.55 | 0.74/0.81 | 1.1/1.2 | 1.65/1.8 | 2.5/2.7 | |
| | Air pressure at inlet (MPa) | 0.7 | | | | | | |
| | Air temperature at inlet (°C) | 35 | | | | | | |
| | Ambient temperature (°C) | 32 | | | | | | |
| | Air dew point at outlet (°C) | 10(with pressure) | | | | | | |
| Working range | Working media | Compressed air | | | | | | |
| | Air temperature at inlet (°C) | 5~50 | | | | | | |
| | Ambient temperature (°C) | 2~40 | | | | | | |
| | Ambient humidity | 40~80%RH | | | | | | |
| | Working pressure (MPa) | 0.2~10 | | | | | | |
| Electric Specs. | Main power line | | 100/200V single phase, 50/60Hz | | | | | |
| | Electricity consumption (kW) | 0.16/0.17 | 0.16/0.17 | 0.22/0.24 | 0.29/0.32 | 0.39/0.44 | 0.53/0.62 | |
| | Operating current | AC100V(A) | 2.0/2.1 | 2.0/2.1 | 2.6/2.8 | 3.4/3.6 | 4.6/4.8 | 5.8/6.4 |
| | | AC200V(A) | 1.0/1.0 | 1.0/1.0 | 1.3/1.4 | 1.7/1.8 | 2.3/2.4 | 2.9/3.2 |
| Details of apparatuses | Operation type | | Automatic operation by sensing air pressure (0.17MPa:ON,0.07MPa:OFF)and manual operation | | | | | |
| | Condenser | | Fin and tube type, forced air cooling method | | | | | |
| | Refrigerant control method | | Capillary tube | | | | | |
| | Temperature control method | | Hot gas by-pass type with capacitor valve | | | | | |
| | Refrigerant | | R22 | | | | | |
| Port diameter of air inlet and outlet(Rc) | | 3/8 | | 1/2 | 3/4 | | 1 | |
| Port diameter of drain discharging(Rc) | | 1/4 | | | | | | |
| Mass (kg) | | 16 | 18 | 18 | 45 | 45 | 49 | |
| Calorie of heat emission (kW) | | 0.3 | 0.4 | 0.58 | 0.86 | 1.2 | 1.8 | |


■ RDM1000 Series

| Model No | | RDM 1003(A) | RDM 1004(A) | RDM 1006(A) | RDM 1008(A) | RDM 1011(A) | RDM 1015(A) | |
|---|--|--|----------------|----------------|----------------|----------------|----------------|-----------|
| Items | | | | | | | | |
| Applicable air compressor (kW) | | ~2. 2 | 3. 7 | 5. 5 | 7. 5 | 11 | 15 | |
| Rating | Volume of disposed (m ³ /min A.N.R) | ~0. 31/0. 35 | 0. 5/0. 55 | 0. 74/0. 81 | 1. 1/1. 2 | 1. 65/1. 8 | 2. 5/2. 7 | |
| | Air pressure at inlet (MPa) | 0. 7 | | | | | | |
| | Air temperature at inlet (°C) | 35 | | | | | | |
| | Ambient temperature (°C) | 32 | | | | | | |
| | Air dew point at outlet (°C) | 10(with pressure) | | | | | | |
| Working range | Working media | Compressed air | | | | | | |
| | Air temperature at inlet (°C) | 5~50 | | | | | | |
| | Ambient temperature (°C) | 2~40 | | | | | | |
| | Ambient humidity | 40~80%RH | | | | | | |
| | Working pressure (MPa) | 0. 2~15 | | | | | | |
| Electric Specs. | Main power line | 100/200V single phase, 50/60Hz | | | | | | |
| | Electricity consumption (kW) | 0. 16/0. 17 | 0. 16/0. 17 | 0. 22/0. 24 | 0. 29/0. 32 | 0. 39/0. 44 | 0. 53/0. 62 | |
| | Operating current | AC100V(A) | 2. 0/2. 1 | 2. 0/2. 1 | 2. 6/2. 8 | 3. 4/3. 6 | 4. 6/4. 8 | 5. 8/6. 4 |
| | | AC200V(A) | 1. 0/1. 0 | 1. 0/1. 0 | 1. 3/1. 4 | 1. 7/1. 8 | 2. 3/2. 4 | 2. 9/3. 2 |
| Details of apparatuses | Operation type | Automatic operation by sensing air pressure (0. 17MPa:ON, 0. 07MPa:OFF) and manual operation | | | | | | |
| | Condenser | Fin and tube type, forced air cooling method | | | | | | |
| | Refrigerant control method | Capillary tube | | | | | | |
| | Temperature control method | Hot gas by-pass type with capacitor valve | | | | | | |
| | Refrigerant | R22 | | | | | | |
| Port diameter of air inlet and outlet(Rc) | | 3/8 | | 1/2 | 3/4 | | 1 | |
| Port diameter of drain discharging(Rc) | | 1/4 | | | | | | |
| Mass (kg) | | 16 | 18 | 18 | 45 | 45 | 49 | |
| Calorie of heat emission (kW) | | 0. 3 | 0. 4 | 0. 58 | 0. 86 | 1. 2 | 1. 8 | |

SPECIFICATIONS

RD1000-RDM1000series

Keep the following notes in custody upon entering contents on the name plate of XEROAQUA you purchased and the name of supplier.

| REFRIGERATED AIR DRYER | |
|--|-------------------------------|
| POWER | MAX.PRESS. |
| MAX.AIR TEMP. | AIR FLOW |
| CURRENT | MASS |
| REFRIGERANT | SERIAL No. |
|  | CKD Corporation MADE IN JAPAN |

| | | | | |
|------------------|--|-----|---|---|
| NAME OF SUPPLIER | | TEL | - | - |
| DATE OF PURCHASE | | | | |

Discontinue



FOR SAFETY USE

The product is intended for use solely in industrial systems and NOT intended for consumer use or application.

Do not attempt to use, apply, install and repair the product unless you are trained in the proper techniques for working on electric, fluid power and refrigeration systems.

Inappropriate or improper use, application, installation and servicing of the product may or could create a danger or hazard to personnel and/or equipment.

PRODUCT SAFETY SIGN

SIGNAL WORD : The word or words that designate a degree or level of safety alerting.



WARNING : Indicates a potentially hazardous situation, if not avoided, could result in death or serious injury.




CAUTION : Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury or property damage.



WARNING

★ Hazardous fan will cause severe injury.


- Keep hands away from moving parts.
- Turn off power before servicing.



WARNING

★ Hazardous voltage can shock, burn or cause death.

- Turn off power before opening cover.



CAUTION

★ Hot surface can cause burn.

- Turn off power and cool down before servicing.



CAUTION

★ Fall points can cause severe injury.

- Do not ride on here.



CKD株式会社

北海道

●札幌営業所

〒060-0032 札幌市中央区北2条東14-26(苗穂駅前ビル1階)

TEL(011)232-1760 FAX(011)232-9050

東北

●北上営業所

〒024-0034 岩手県北上市諏訪町2-4-26

TEL(0197)63-4147 FAX(0197)63-4186

●仙台営業所

〒984-0015 仙台市若林区卸町2-2-1(バックス2・1階)

TEL(022)239-1851 FAX(022)239-1856

●山形営業所

〒990-0834 山形県山形市清住町2-6-24

TEL(023)644-6391 FAX(023)644-7273

●郡山営業所

〒963-8034 福島県郡山市島1-16-9

TEL(0249)23-6348 FAX(0249)24-0862

北関東

●大宮営業所

〒330-0812 さいたま市北区宮原町3-429-1(第一清水ビル2階)

TEL(048)652-3811 FAX(048)652-3816

●茨城営業所

〒300-0847 茨城県土浦市卸町1-1-1(関鉄つくばビル4階C)

TEL(029)841-7490 FAX(029)841-7495

●宇都宮営業所

〒321-0953 栃木県宇都宮市東宿郷3-1-7(NBF宇都宮ビル3階)

TEL(028)638-5770 FAX(028)638-5790

●太田営業所

〒373-0813 群馬県太田市内ヶ島町946-2(大観総合ビル1階)

TEL(0276)45-8935 FAX(0276)46-5628

南関東

●東京営業所

〒105-0013 東京都港区浜松1-31-1(文化放送メディアプラス4階)

TEL(03)5402-3628 FAX(03)5402-0122

●立川営業所

〒190-0022 東京都立川市錦町3-2-30(朝日生命立川錦町ビル3階)

TEL(042)527-3773 FAX(042)527-3782

●千葉営業所

〒260-0021 千葉市中央区新宿2-5-19(千葉南ビル3階)

TEL(043)248-2815 FAX(043)248-2818

●横浜営業所

〒222-0033 横浜市港北区新横浜2-17-19(日経第15ビル4階)

TEL(045)475-3471 FAX(045)475-3470

●厚木営業所

〒243-0035 神奈川県厚木市愛甲1212-3

TEL(046)226-5201 FAX(046)226-5208

●甲府営業所

〒409-3867 山梨県中巨摩郡昭和町清水新居1509

TEL(055)224-5256 FAX(055)224-3540

●東京支店

〒105-0013 東京都港区浜松1-31-1(文化放送メディアプラス4階)

TEL(03)5402-3620 FAX(03)5402-0120

北陸・信越

●長岡営業所

〒940-0088 新潟県長岡市柏町1-4-33(高野不動産ビル2階)

TEL(0258)33-5446 FAX(0258)33-5381

●上田営業所

〒386-0034 長野県上田市大字中之条323-6(NFビル103号)

TEL(0268)24-2392 FAX(0268)24-2394

●松本営業所

〒399-0033 長野県松本市大字笹賀5945

TEL(0263)25-0711 FAX(0263)25-1334

●富山営業所

〒939-8064 富山県富山市赤田中町494-1

TEL(076)421-7828 FAX(076)421-8402

●金沢営業所

〒920-0025 石川県金沢市駅西本町3-16-8

TEL(076)262-8491 FAX(076)262-8493

東海

●名古屋営業所

〒485-8551 愛知県小牧市応時2-250

TEL(0568)74-1371 FAX(0568)77-3291

●豊田営業所

〒473-0912 愛知県豊田市広田町広田103

TEL(0565)54-4771 FAX(0565)54-4755

●静岡営業所

〒422-8035 静岡県静岡市駿河区宮竹1-3-5

TEL(054)237-4424 FAX(054)237-1945

●浜松営業所

〒453-0016 静岡県浜松市和田町438

TEL(053)463-3021 FAX(053)463-4910

●四日市営業所

〒510-0064 三重県四日市市新正5-3-20

TEL(0593)51-3151 FAX(0593)51-6788

●名古屋支店

〒485-8551 愛知県小牧市応時2-250

TEL(0568)74-1356 FAX(0568)77-3317

関西

●大阪営業所

〒542-0073 大阪府中央区日本橋1-17-17(銀泉日本一ビル)

TEL(06)6635-2773 FAX(06)6643-5950

●大阪東営業所

〒577-0083 大阪府守口市京阪本通1-2-3

(横保ジャパン守口ビル6階)

TEL(06)4250-6333 FAX(06)6991-7477

●堺営業所

〒591-8021 大阪府堺市新金岡町5-5-6(泉マンション1階)

TEL(072)253-0071 FAX(072)253-0054

●滋賀営業所

〒524-0033 滋賀県守山市浮気町字中ノ町300-21(第2小島ビル4階)

TEL(077)514-2650 FAX(077)583-4198

●京都営業所

〒612-8414 京都市伏見区竹田段川原町35-3

TEL(075)645-1130 FAX(075)645-4747

●奈良営業所

〒639-1123 奈良県大和郡山形町460-15(オアシス・ロジナ1階)

TEL(0743)57-6831 FAX(0743)57-6821

●神戸営業所

〒673-0016 兵庫県明石市松の内2-6-8(西明石スポーツビル3階)

TEL(078)923-2121 FAX(078)923-0212

●大阪支店

〒542-0073 大阪府中央区日本橋1-17-17(銀泉日本一ビル)

TEL(06)6635-2765 FAX(06)6643-5015

中国

●広島営業所

〒730-0022 広島市中区銀山町3-1(ひろしまハイビル2112階)

TEL(082)545-5125 FAX(082)244-2010

●岡山営業所

〒700-0916 岡山県岡山市西之町10-104

TEL(086)244-3433 FAX(086)241-8872

●山口営業所

〒747-0034 山口県防府市天神2-2-2

TEL(0835)38-3556 FAX(0835)22-6371

四国

●高松営業所

〒760-0055 香川県高松市観光通2-2-15(ダイヤビル)

TEL(087)834-9640 FAX(087)834-9633

●松山営業所

〒790-0053 愛媛県松山市竹原2-1-33(サンライト竹原1階)

TEL(089)931-6135 FAX(089)931-6139

九州

●北九州営業所

〒802-0976 北九州市小倉南区南方5-13-34

TEL(093)964-0785 FAX(093)964-0910

●福岡営業所

〒812-0013 福岡市博多区博多駅東1-10-27(アステシア博多ビル5階)

TEL(092)473-7136 FAX(092)473-5540

●大分営業所

〒871-0015 大分県中津市牛神町1-11-1

TEL(0979)26-0725 FAX(0979)23-6866

●熊本営業所

〒869-1103 熊本県菊池郡菊陽町久保田2799-13

TEL(096)340-2580 FAX(096)340-2584

本社

●本社・工場

〒485-8551 愛知県小牧市応時2-250

TEL(0568)77-1111 FAX(0568)77-1123

●営業本部

〒485-8551 愛知県小牧市応時2-250

TEL(0568)74-1303 FAX(0568)77-3410

●海外営業部

〒485-8551 愛知県小牧市応時2-250

TEL(0568)74-1338 FAX(0568)77-3461

CKD Corporation

- 2-250 Ouji Komaki, Aichi 485-8551, Japan
 □ PHONE +81-(0)568-74-1336 FAX +81-(0)568-77-3412

USA

CKD USA CORPORATION

●HEADQUARTERS

4080 Winnetka Avenue, Rolling Meadows, IL 60008 USA

PHONE +1-847-368-0539 FAX +1-847-788-0575

●CINCINNATI OFFICE

●SAN ANTONIO OFFICE

●SAN JOSE OFFICE

Europe

CKD EUROPE BRANCH

De Fruittuinen 28 Hoofddorp 2132NZ The Netherlands

PHONE +31-(0)23-5541490 FAX +31-(0)23-5541491

Malaysia

M-CKD PRECISION SDN.BHD.

●HEADQUARTERS

Lot No.6, Jalan Modal 23/2, Seksyen 23, Kawasan, MIEL,

Fasa 8, 40300 Shah Alam, Selangor Darul Ehsan, Malaysia

PHONE +60-(0)3-5541-1468 FAX +60-(0)3-5541-1533

●JOHOR BAHRU OFFICE

●MELAKA OFFICE

●PENANG OFFICE

Thailand

CKD THAI CORPORATION LTD.

●SALES HEADQUARTERS-BANGKOK OFFICE

Suwan Tower, 14/1 Soi Saladaeng 1, North Sathorn Rd., Bangkok,

Bangkok 10500 Thailand

PHONE +66-(0)2-267-6300 FAX +66-(0)2-267-6305

●LAEMCHABANG OFFICE

●NAVANAKORN OFFICE

●RAYONG OFFICE

●LAMPHUN OFFICE

●KORAT OFFICE

●AMATANAKORN OFFICE

Singapore

CKD SINGAPORE PTE LTD.

705 Sims Drive #03-01/02, Shun Li Industrial Complex,

387384 Singapore

PHONE +65-6744-2623 FAX +65-6744-2486

Taiwan

日商喜開理股 有限公司台湾分公司

CKD CORPORATION TAIWAN BRANCH

中華民國台灣省台北市中山北路二段96號嘉新大樓第14樓1405室

Rm.1405, 14F, No.96, Sec.2, Chung Shan N.Rd., Taipei, Taiwan, R.O.C

PHONE +886-(0)2-2523-0374 FAX +886-(0)2-2523-5081

China

喜開理(上海)機器有限公司

CKD(SHANGHAI) CORPORATION

●営業部/上海事務所

(SALES HEADQUARTERS / SHANGHAI OFFICE)

中国上海市黄浦区九江路333号金融廣場19樓1903室

Room 1903, 333 Jiujiang Road, Shanghai, 200001, China

PHONE +86-(0)21-63602277 FAX +86-(0)21-63511661

●無錫事務所(WUXI OFFICE)

●南京事務所(NANJING OFFICE)

●杭州事務所(HANGZHOU OFFICE)

●武漢事務所(WUHAN OFFICE)

●青島事務所(QINGDAO OFFICE)

●蘇州事務所(SUZHOU OFFICE)

●北京事務所(BEIJING OFFICE)

●天津事務所(TIANJING OFFICE)

●長春事務所(CHANG CHUN OFFICE)

●大連事務所(DALIAN OFFICE)

●瀋陽事務所(SHENYANG OFFICE)

●西安事務所(XIAN OFFICE)

●重慶事務所(CHONGQING OFFICE)

●成都事務所(CHENGDU OFFICE)

●広州事務所(GUANGZHOU OFFICE)

●深圳事務所(SHENZHEN OFFICE)

Korea

CKD KOREA CORPORATION

Room No.1105, 11th FL, The Korea Teachers Pension B/L 27-2,

Yoido-Dong, Youngdeungpo-Gu, Seoul, 150-742, Korea

PHONE +82-(0)2-783-5201~5203 FAX +82-(0)2-783-5204