


## How to connect terminal box

Refer to the figure below for the connection method to a DIN terminal box or T-type terminal box.

### DIN terminal box (Pg9), DIN terminal box with lamp (Pg9)

- Use the following cabtyre cable.
  - Cable O.D.:  $\phi 4.5$  to  $\phi 7$
  - Nominal section area:  $0.75 \text{ mm}^2$
- Put the crimp terminal for copper wire on the cabtyre cable's lead wire and crimp the terminal. The terminal box thread size is M3.
- thread size is M3.
  - Tighten the screws with the following tightening torque.
    - Set screw tightening torque... $0.5 \text{ Nm}$
    - Terminal screw tightening torque... $0.5 \text{ Nm}$




Wire with steps ① to ④.

\*The orientation of the cord can be changed by removing the terminal block from the case, rotating it by  $180^\circ$ , and then replacing the block into the case.

### T-type terminal box (G1/2), T-type terminal box with lamp (G1/2)

- Use the following cabtyre cable.
  - Nominal section area:  $0.75 \text{ mm}^2$
- Put the crimp terminal for copper wire on the cabtyre cable's lead wire and crimp the terminal. The terminal box thread size is M3.
- Tighten the screws with the following tightening torque.
  - Mounting screw tightening torque... $0.5 \text{ Nm}$
  - Terminal screw tightening torque... $0.5 \text{ Nm}$



\*Parts marked with an asterisk are not included with CKD products.

### \*Changing the direction of the T-type terminal boxes

If you wish to change the orientation of the T-type terminal box as shipped, please follow the procedure below.

- Clamp the two side widths (25 widths) of the T-type terminal box with a tool (monkey wrench, spanner, etc.) and turn counterclockwise to loosen.
- Loosen the lock nut.
- Rotate the T-type terminal box in the tightening direction (clockwise) until it is about  $15^\circ$  before the desired position.
- Tighten the lock nut to the coil side by hand until it is lightly tightened.
- Clip the two side widths of the T-type terminal box with a tool and rotate to the desired position (about  $15^\circ$ ) to tighten.

Note: When changing the orientation by further tightening the terminal box from the shipping position, do so within  $1/2$  turn.



# Safety Precautions

Be sure to read this section before use.

Refer to Intro Page 29 for general valve precautions.

Product-specific cautions: Pilot operated 3-port valve NP / NAP / NVP Series

## Design / Selection

### WARNING

#### Ambient environment

- NP / NVP Series cannot be used in an explosive gas atmosphere. When using in an explosive gas atmosphere, change to the NAP Series, and provide a separate explosion-proof solenoid valve on the pilot air circuit.
- If there are high levels of dust in the area, install a silencer or fitting on the exhaust port so that dust does not enter.

#### This product cannot be used as an emergency shut-off valve.

It is not designed to function as a safety valve, such as an emergency shut-off valve. When using in such a system, always take separate measures that will ensure safety.

#### Fluid temperature

Be sure to use the coolant check valve within the specified fluid temperature range.

#### Ambient environment

- Do not use this product in a corrosive gas atmosphere or an atmosphere that could affect the component materials.
- Do not use this product near a heat generating source or in a location where it may be exposed to radiant heat.
- Use this product within the operating ambient temperature.
- When you use the products in a cold climate, take necessary measures to prevent freezing.
- Take appropriate safeguards according to the degree of protection listed in the catalog specifications. Consult with CKD when using outdoors.
- Take appropriate measures when using this product in places where oil or welding spatter, etc., could come in contact with it.


### CAUTION

#### Ultra-dry Air

The inside of the valve is pre-lubricated with grease. This valve may not be appropriate if ultra dry air quality is required at the end of the circuit.

#### Leakage current from other fluid control components

When operating the solenoid valve with a programmable controller, etc., check that the output leakage current from the programmable controller is within the following specifications. Failure to observe this could lead to malfunctions.



| 100 VAC        | 200 VAC        | 24 VDC         |
|----------------|----------------|----------------|
| 3.0 mA or less | 1.5 mA or less | 1.8 mA or less |

#### Notes for external pilot air

- Draining: Compressed air contains a large amount of drainage (water, oil oxides, tar, foreign matter). This is a factor that significantly reduces the reliability of the pneumatic components. For drainage measures, improve air quality by dehumidifying with an after cooler or dryer, removing foreign matter with a filter, and removing tar with a tar removal filter, etc.
- Pre-lubrication: This series is pre-lubricated, so no lubricator is required. However, once lubrication has been started, it must be continued so that the lubricant does not run out. Use turbine oil Class 1 ISO VG32 (#90) or equivalent for lubrication.
- Filter: Install a filter with a  $5 \mu\text{m}$  or less filter element.
- If pilot air is supplied, the valve may operate even if the pressure is less than the working pressure range.

#### Min. working pressure

The pressure must be  $0.2 \text{ MPa}$  and over to operate the NP Series. If the piping cross-section area on the fluid inlet is reduced, the operation may become unstable due to a pressure drop during valve operation.

#### Securing maintenance space


Secure sufficient space for maintenance and inspection.

#### Vibration

Install this product in a place not subject to vibration.

#### Refer to the technical data (on page 244) for connection methods to a DIN terminal box or T-type terminal box.

#### The thread size for the junction box outlets of the DIN terminal box can be changed from Pg9 to G1/2 using the optional connector below.



#### Recommended fittings for NP, NVP Series exhaust port

When mounting a fitting to the exhaust port (Rc1/8), use "GWS/-6-S single straight (round)".

\*For some parts of the NP and NVP Series, piping connection using a wrench may not be easy, and fittings are tightened with an Allen wrench. Use "SLW-6A or SLW-6S" when mounting the silencer.

For cautions for mounting, installation, adjustment, use and maintenance, refer to the CKD components Product Site (<https://www.ckd.co.jp/kiki/jp/en/>) → "Model No. → [Instruction manual] for details.