Related products

Related products 4GA/B

M4GA/B

MN4GA/B 4GA/B (master)

4GB With sensor

4GD/E

M4GD/E

MN4GD/E

MN3E MN4E

W4GB4 MN3S0

4KA/B

4KA/B (master)

4F (master) **GMF**

PV5S-0

3MA/B0

P/M/B

NP/NAP

4F*0EX

4F*0E

2QV 3QV

TotAirSys (Total Air)

(Gammá)

4GA4/B4

W4GA/B2

MN4S0

4SA/B0

4F

PV5G PV5 GMF

3Q

MV3QR

3PA/B

4G*0EJ

HMV HSV

SKH Silencer

TotAirSys

Ending

In-stop valve spacer

Specifications

Model	P→A/B		A/B	Woight a	
No.	C[dm³/(s-bar)]	b	C[dm³/(s-bar)]	b	Weight g
4G1	0.54	0.03	0.82	0.27	17
4G2	1.5	0.17	1.6	0.20	63
4G3	1.9	0.09	2.8	0.16	80

- *1: Values with base piping and 2-position valve mounted.
- *2: The effective cross-sectional area when discharging residual pressure is 1.0 mm² (reference value).
- *3: Effective cross-sectional area S and sonic conductance C are converted as S \approx 5.0 x C.

Attachments: PR check valve 2, body gasket 1

Push to cut off air supply and turn to lock


How to order discrete units

4G1R IS

4G2R IS

4G3R IS

In-stop valve spacer




Precautions for model No. selection

- *1: Specify the spacer mounting position and quantity in manifold specifications sheet.
- *2: When retrofitting to the reduced wiring manifold, the existing electric wire may be too short. Contact CKD for details.


Dimensions

JIS symbol




Dimensions when mounted

Dimensions when mounted



Related products

Air supply spacer




Specifications

Model	P→	A/B	A/B→R		Woight a
No.	C[dm³/(s-bar)]	b	C[dm³/(s-bar)]	b	Weight g
4G1	0.70	0.23	0.93	0.16	8
4G2	1.6	0.17	1.8	0.16	35
4G3	2.6	0.22	3.1	0.14	56

^{*1:} Values are when a valve is mounted.

How to order discrete units



Attachments: Mounting screw 2, PR check valve 2, body gasket 1

A Precautions for model No. selection

- *1: Specify the air supply spacer mounting position and quantity in manifold specifications sheet of each catalog.
- *2: If the A/B port fitting is the elbow (upward), turn the air supply port of the air supply spacer toward the reverse side ("a" solenoid side).
- *3: If the elbow (upward) A/B port fitting is used for the reduced wiring manifold, the air supply spacer cannot be selected.
- *4: Combination with the masking plate is not supported.

4GA/B

M4GA/B

MN4GA/B

4GA/B

(master) 4GB With sensor

4GD/E

M4GD/E

MN4GD/E

4GA4/B4

MN3E MN4E

W4GA/B2

W4GB4

MN3S0 MN4S0

4SA/B0

4KA/B 4KA/B

(master)

4F 4F

(master) PV5G **GMF** PV5 **GMF**

PV5S-0

3Q

MV3QR

3MA/B0

3PA/B

P/M/B

NVP

4G*0EJ

4F*0EX

4F*0E

HMV HSV

2QV 3QV

SKH

Silencer

TotAirSys (Total Air) TotAirSys (Gamma)


^{*2:} Effective cross-sectional area S and sonic conductance C are converted as S ≈ 5.0 x C.

Related products

4F

4F


578



Related products

Related products

Exhaust spacer




Specifications

Model	P→	A/B	A/E	Woight a	
No.	C(dm³/(s·bar))	b	C(dm³/(s·bar))	b	Weight g
4G1	0.94	0.28	0.68	0.33	7
4G2	1.5	0.24	1.9	0.24	34
4G3	3.4	0.21	2.9	0.27	58

^{*1:} Values are when a valve is mounted.

How to order discrete units



is not available.

Accessories: Mounting screw 2, PR check valve 2, body gasket 1

A Precautions for model No. selection

4GA/B

M4GA/B

MN4GA/B

4GA/B (master)

4GB With sensor

4GD/E

MN4GD/E

4GA4/B4

MN3E MN4E

W4GA/B2

W4GB4 MN3S0

MN4S0 4SA/B0

4KA/B

4KA/B (master)

4F

(master) PV5G GMF PV5

GMF PV5S-0

3Q MV3QR

3MA/B0

3PA/B

P/M/B NP/NAP

NVP 4G*0EJ

4F*0EX

4F*0E

HMV HSV

HSV 2QV 3QV

SKH Silencer

TotAirSys (Total Air) TotAirSys (Gamma)

^{*2:} Effective cross-sectional area S and sonic conductance C are converted as $S \approx 5.0 \text{ x C}$.

^{*1:} Specify the exhaust spacer mounting position and quantity on the manifold specifications sheet of each catalog.

^{*2:} If the port A/B fitting is elbow (upward), turn the exhaust port of the exhaust spacer toward the reverse side ("a" solenoid side).

^{*3:} If the elbow (upward) port A/B fitting is used for the reduced wiring manifold, the exhaust spacer cannot be selected.

^{*4:} Combination with the masking plate is not supported.

Related products

Related products 4GA/B

Exhaust spacer

Dimensions

M4GA/B

MN4GA/B 4GA/B

(master) 4GB With sensor

4GD/E M4GD/E

MN4GD/E 4GA4/B4

MN3E MN4E

W4GA/B2

W4GB4 MN3S0 MN4S0

4SA/B0

4KA/B

4KA/B

(master) 4F

4F (master) PV5G **GMF** PV5 GMF PV5S-0 3Q

NVP


HMV HSV


2QV 3QV


SKH

Silencer TotAirSys (Total Air)

TotAirSys (Gamma)











72.7





Dimensions when mounted








3/5(R) port

10.3















Dimensions when mounted






Note: For A and B dimensions, check the dimensions of respective specifications.

Ending

580






JIS symbol (Position locking)

(P)1 (R2)3

(R1)5



How to order Discrete model No.

Manifold model No.

M4G2R

Model No

Pilot

4G2R - PCS -

Specifications

Item	4G2R-PCS-*-*	
Effective cross-sectional area	${\rm mm}^2$	11
Weight	g	200

R-PCS-(C4)-()	- (5) _			
1 00 04		Code	Description	
		A Poi	rt size	
D. A Port size (*1)			Valve side port	Cylinder side port
` '		C4	ø4 push-in fitting	ø4 push-in fitting
t check valve		C6	ø6 push-in fitting	ø6 push-in fitting
		C8	ø8 push-in fitting	ø8 push-in fitting
		CL6	ø6 push-in fitting	ø6 push-in L-fitting (upward)
		CL8	ø8 push-in fitting	ø8 push-in L-fitting (upward)
		B Op	tion	

B Option Blank None (*2) A/B-port filter built in M Manual non-locking DIN rail mount D

Station No. Station 2 stations No. to to 10 10 stations

Depending on usage conditions, the pilot check valve body may emit resonance noise due to the air flow when the cylinder operates, but this is not an abnormality. Adjust the pipe length and bore size in that case.


Precautions for model No. selection

- *1: Contact CKD for information on mixing port sizes.
- *2: The following applies when blank is selected as an option. Manual override: Non-locking/locking common, Mounting method: Direct mounting.

All ports closed (solenoid) valve 10 cm³/min or less Pilot check valve (4G2R-PCS)

Example of leak comparison

Dimensions



4GA/B

M4GA/B

MN4GA/B

4GA/B (master) 4GB With sensor

4GD/E

M4GD/E

MN4GD/E

4GA4/B4 MN3E MN4E

W4GA/B2

W4GB4 MN3S0

MN4S0 4SA/B0

4KA/B 4KA/B

(master 4F

> 4F (master) PV5G GMF PV5

GMF

PV5S-0

3Q MV3QR

3MA/B0

3PA/B

P/M/B

NVP 4G*0EJ

4F*0EX

4F*0E

HMV HSV

2QV 3QV

SKH Silencer

<u>TotAirSys</u> (Total Aîr) TotAirSys (Gamma)

Related products

4GA/B Rela

M4GA/B

MN4GA/B 4GA/B (master)

(master) 4GB With sensor

4GD/E

MN4GD/E 4GA4/B4

MN3E MN4E W4GA/B2

W4GB4 MN3S0 MN4S0

4SA/B0

4KA/B 4KA/B (master)

4F (master) PV5G GMF

4F

PV5 GMF PV5S-0

3Q

MV3QR

3MA/B0

3PA/B P/M/B

NP/NAP

NVP 4G*0EJ

4F*0EX

4F*0E HMV HSV

HSV 2QV 3QV

SKH

TotAirSys (Total Air) TotAirSys (Gamma)

Ending

Related products

Tie rod kit (for pilot check valve)
 (For manifold connection and expansion)






A Type	
V1	For 1 station
V2	For 2 stations
V3	For 3 stations
V4	For 4 stations
V5	For 5 stations


A Precautions for model No. selection


*1: Select the V1 to V5 combination when using six or more stations.

DIN rail adaptor kit (for pilot check valve)
 (The DIN rail adaptor kit is required for the following reassembly)

A Type







A Type (*1)

A	Туре	DIN rail adaptor	kit selection list b			
	Description	Change from moun	ting plate to DIN rail	Add/remove stations	with DIN rail mount	Content
Cod	le	For 1 station	2 or more stations	≥2 stations → 1 station	1 station → ≥2 stations	Content
	For right				• (*2)	DIN rail adaptor (right) 1, thread 2
D2	Right + left		•			DIN rail adaptor (right) 1, DIN rail adaptor (left) 1, thread 4
D3	For single unit	•		•		DIN rail adaptor (single unit) 1, thread 2

^{*2:} When changing from 1 station to 2 or more stations, purchase the DIN rail adaptor for right (D1), and remove the retainer on one side of the current DIN rail adaptor kit (D3).


ø4L/ø6L/ø8L/ø10L (long elbow)

4G1R-JOINT-CLL4/CLL6

 Push-in cartridge fitting ø4L/ø6L/ø8L/ø10L type (short elbow) 4G1R-JOINT-CL4/CL6

4G2R-JOINT-CL6/CL8 4G3R-JOINT-CL8/CL10 4G2R-JOINT-CLL6/CLL8 4G3R-JOINT-CLL8/CLL10






SLW-6S, 8S

Related products


Related products

Silencer

● SLM-M5



● SLW-6A, 8A, 10A, 10L



- *1: Select the silencer mounting after confirming the dimensions.
- * SLW-8S for the 2:M4GD2 DIN rail mount. Interference occurs if SLW-8A is used.

Code Model No.	Noise reduction effect dB (A)	Eff. X-sectional area mm²	A	В	С	D	E	Port size
SLW-6A	30 or more	10	34.5	28	16.5	10	7	R1/8
SLW-8A	30 or more	20	44.5	36	20	13	8.5	R1/4
SLW-10A	30 or more	30	58.5	48.5	25.5	17	12	R3/8
SLW-10L	30 or more	60	68.2	58.4	28	19	12	R3/8


Port size A B

Cross-section A-A-A

Model No.	Port size	Α	В	С	D	E
SLW-6S	R 1/8	22	13.3	10.5	6	10.5
SLW-8S	R 1/4	28	19	14.8	9	15.4


Blanking plug

Ω



Model No.	D	L	l	d
GWP 4-B	ø4	27	16	6
GWP 6-B	ø6	29	11.5	8
GWP 8-B	ø8	33	14	10
GWP 10-B	ø10	40	18.5	12

PG-P2-B (for Ø1.8)



Plug type

Part name	Model No.	Compatible bore size	Appearance
Threaded	4G1R-M5P	M5	(FPL-M5)
plug	4G2R-06P	Rc1/8	\bigcirc
	4G3R-08P	Rc1/4	
	4G3R-10P	Rc3/8	Hexagon socket plug

 Push-in fitting tube remover For ø1.8/ø4 push-in fitting 4GR-EOT18-4




For ø4/ø6 push-in fittings 4GR-EOT4-6

DIN rail

N4GR-BAA





*1:Rail lengths not included in the list are made to order products.

L1: Man	ifold length	L2: Rail length	A: Mounting pitch
35 47.5 or less		87.5	75
Over 47.5 to 60		100	87.5
60	72.5	112.5	100
72.5	85	125	112.5
85	97.5	137.5	125
97.5	110	150	137.5
110	122.5	162.5	150
122.5	135	175	162.5
135	147.5	187.5	175
147.5	160	200	187.5
160	172.5	212.5	200
172.5	185	225	212.5
185	197.5	237.5	225
197.5	210	250	237.5
210	222.5	262.5	250
222.5	235	275	262.5
235	247.5	287.5	275
247.5	260	300	287.5
260	272.5	312.5	300
272.5	285	325	312.5
285	297.5	337.5	325
297.5	310	350	337.5
310	322.5	362.5	350
322.5	335	375	362.5
335	347.5	387.5	375
347.5	360	400	387.5
360	372.5	412.5	400
372.5	385	425	412.5
385	397.5	437.5	425
397.5	410	450	437.5
410	422.5	462.5	450
422.5	435	475	462.5
435	447.5	487.5	475
447.5	460	500	487.5
460	472.5	512.5	500
472.5	485	525	512.5
485	497.5	537.5	525
497.5	510	550	537.5

If the length exceeds 510, calculate using a multiple of 12.5.

4GA/B

M4GA/B

MN4GA/B

4GA/B (master)

4GB With sensor

4GD/E

M4GD/E

MN4GD/E

4GA4/B4

MN3E MN4E W4GA/B2

W4GB4

MN3S0 MN4S0

4SA/B0

4KA/B

(master) 4F

4F (master) PV5G GMF

PV5 GMF

PV5S-0

3Q

MV3QR 3MA/B0

3PA/B

P/M/B

NP/NAP NVP

4G*0EJ 4F*0EX

4F UEA

4F*0E

HMV HSV

2QV 3QV

SKH

Silencer TotAirSys (Total Air)

TotAirSys (Gamma) Ending

Related parts

4GA/B

M4GA/B

MN4GA/B

4GA/B (master) 4GB With sensor

4GD/E

M4GD/E

MN4GD/E

4GA4/B4

MN3E MN4E

W4GA/B2

W4GB4

MN3S0 MN4S0

4SA/B0

4KA/B

4KA/B (master)

4F

4F (master) PV5G GMF

PV5 GMF

PV5S-0 3Q

MV3QR

3MA/B0

3PA/B

P/M/B

NP/NAP NVP

4G*0EJ

4F*0EX

4F*0E

HMV HSV

2QV 3QV

SKH Silencer


TotAirSys (Total Air)

TotAirSys (Gamma)

Ending

Related parts


(1) Mounting plate (P) kit



Mounting (P) kit

Model	Kit model No.	Set parts
3GD1/4GD1	4G1R-MOUNT-PLATE-KIT	Mounting plate, set screw 2, nut 2
3GD2/4GD2	4G2R-MOUNT-PLATE-KIT	Mounting plate, set screw 2
3GD3/4GD3	4G3R-MOUNT-PLATE-KIT	Mounting plate, set screw 2

(2) Single cartridge push-in fitting related part




Fitting stopper plate kit

Model	Kit model No.	
M4G1	4G1R-JNT-STP-PLATE-KIT	
M4G2	4G2R-JNT-STP-PLATE-KIT	
M4G3	4G3R-JNT-STP-PLATE-KIT	

Related parts

Related parts

(4) Manifold related parts



Masking plate kit

Model	Model No.	Content	Remarks
M3G1/M4G1	4G1R-MP		
M3G1/M4G1	4G1R-MPC (*)	Masking plate Gasket	4G3R-MP has two PR check valves
M3G2/M4G2	4G2R-MP	Mounting screws 2 includ	included.
M3G3/M4G3	4G3R-MP		

^{*} For pilot exhaust atmosphere release

Gasket

Model	Part model No.
3G1/4G1	4G1R-GASKET
3G1/4G1 (For masking plate)	4G1R-MP-GASKET
3G2/4G2	4G2R-GASKET
3G2/4G2 (For masking plate)	4G2R-MP-GASKET
3G3/4G3	4G3R-GASKET

Gasket with exhaust check valve

Model	Part model No.	
3G1/4G1	4G1R-CHECK-VALVE	
3G2/4G2	4G2R-CHECK-VALVE	
3G3/4G3	4G3R-CHECK-VALVE	

PR check valve kit (2 per set)

Model	Kit model No.
3G1/4G1	4G1R-PR
3G2/4G2	4G2R-PR
3G3/4G3	4G3R-PR

Mounting screw (10 per set)

Model	Part model No.
3G1/4G1	4G1R-SET-SCREW
3G2/4G2	4G2R-SET-SCREW
3G3/4G3	4G3R-SET-SCREW

DIN rail kit

Model	Model No.	Content	
M4G1	4GA1R-BAAlength - D	DIN rail, mounting screw 2	
IVI4G I	4GB1R-BAAlength - D	Lock nut 2	
M4G2	4GA2R-BAA length - D		
	4GB2R-BAA length - D	DIN rail/holder 2	
M4G3	4GA3R-BAA length - D	Tapping screw 2, mounting screw 4	
1014G3	4GB3R-BAA length - D	mounting corow i	

Specify the length "0" when the DIN rail is not required. Set the DIN rail length, referring to the working manifold dimensions and DIN rail length quick reference list (page 583).

M4GA/B

4GA/B

MN4GA/B 4GA/B (master)

4GB With sensor 4GD/E

M4GD/E

MN4GD/E

4GA4/B4

MN3E MN4E W4GA/B2

W4GB4 MN4S0

4SA/B0 4KA/B

4KA/B (master

4F 4F (master) PV5G GMF PV5 **GMF**

PV5S-0

3Q MV3QR

3MA/B0 3PA/B

P/M/B NP/NAP NVP

4G*0EJ 4F*0EX

4F*0E


HM\ HSV 2QV 3QV SKH

Silencer

TotAirSys (Total Air) TotAirSys (Gamma)

Related parts Related parts 4GA/B (5) Sub-plate M4GA/B How to order MN4GA/B A Model No. 4GA/B 4GD piping adapter (master) 4**G**1 **4**G2 5 4GB 4G1) R - ADAPTOR - (M5) - (With sensor Description Code 4GD/E B Port size (P/R1/R2 port) B Port size A Model No. M4GD/E Rc1/8 06 08 Rc1/4 MN4GD/E 4GA4/B4 © Option **C** Option MN3E With mounting plate (attachment) MN4E W4GA/B2 D Pilot exhaust method Pilot exhaust method Common exhaust W4GB4 (Pilot exhaust check valve built-in) MN3S0 Atmosphere release C MN4S0 is not available. 4SA/B0 Oindicates a custom order. 4KA/B 4KA/B (master) 4F A Model No. 4GE single sub-plate 4F (master) 463 4**G**2 <u>4</u> PV5G) R -SUB-BASE - (**06**) -**GMF** Description Code PV₅ B Port size (A/B/P/RI/R2-port) **GMF** B Port size • A Model No. 06 Rc1/8 PV5S-0 80 Rc1/4 10 Rc3/8 3Q MV3QR **©** Option **O**ption A/B port filter integrated *1 3MA/B0 D Pilot exhaust method 3PA/B Pilot exhaust method Common exhaust P/M/B (Pilot exhaust check valve built-in) NP/NAP Atmosphere release *1: A filter is built into the P-port as standard. 4G*0EJ is not available. Oindicates a custom order. 4F*0EX 4F*0E HMV HSV 2QV 3QV SKH Silencer TotAirSys (Total Air) **TotAirSys** (Gammá)

Related parts



(6) Manifold sub-plate kit individual wiring

B Port size

Option

D Pilot exhaust

Station

No.

method

Related parts

4GA/B Related parts

M4GA/B

M4GA/B MN4GA/B

4GA/B (master) 4GB With sensor

4GD/E

M4GD/E

4GA4/B4

MN3E MN4E W4GA/B2

W4GB4

MN3S0 MN4S0

4SA/B0

4KA/B 4KA/B (master)

4F

4F (master) PV5G GMF PV5 GMF

PV5S-0

3Q

MV3QR

3MA/B0

3PA/B

P/M/B NP/NAP

4G*0EJ

4F*0EX

4F*0E

HMV HSV


2QV 3QV

SKH Silencer

TotAirSys (Total Air)

TotAirSys (Gamma)

Ending



Code	Description		
A Model	No.		
M4GE2	Metal base 4G2 size base piping		<u>س</u>
M4GE3	Metal base 4G3 size base piping	M4GE2	M4GE3
B Port s	ize	₩ 4	₹
Port	4(A), 2(B) port		R2 port (2) = Rc3/8
C4	ø4 push-in fitting	(1)	
C6	ø6 push-in fitting	(1)	(2)
C8	ø8 push-in fitting	(1)	(2)
C10	ø10 push-in fitting		(2)
CL6	ø6 push-in L-fitting (upward)	(1)	
CL8	ø8 push-in L-fitting (upward)	(1)	(2)
CL10	ø10 push-in L-fitting (upward)		(2)
CD6	ø6 push-in L-fitting (downward)	(1)	
CD8	ø8 push-in L-fitting (downward)	(1)	(2)
CD10	ø10 push-in L-fitting (downward)		(2)
06	Rc1/8	(1)	
08	Rc1/4		(3)
© Option	1		
Blank			
F	A/B port filter built in (*1)		
Pilot e	xhaust method		
Blank	Common exhaust		

(*2)

A Model No.

2 stations

Atmosphere release

Blank

С

2

to 20

Station No.

(Pilot exhaust check valve built-in)

Refer to the specifications page for the max. station number.


^{*1:} A filter is built into the P-port as standard.

^{*2:} Available as custom order.

^{*3:} Direct mount/DIN rail mount are common.

^{*4:} The DIN rail kit must be prepared separately.

Related parts



Related parts Related parts 4GA/B (7) Manifold sub-plate kit reduced wiring M4GA/B M4GE sub-plate MN4GA/B A Model No. M4GE1) R - CL4-(T10)-4GA/B (master) 4GB Code Description With sensor A Model 4GD/E A Model No. M4GE1 Metal base 4G1 size base piping M4GE2 Metal base 4G2 size base piping M4GD/E M4GE1 M4GE3 M4GE2 M4GE3 Metal base 4G3 size base piping MN4GD/E B Port size B Port size P/R1/R2 port 4GA4/B4 4(A), 2(B) port **Port** (1) = Rc1/8 (2) = Rc1/4 (3) = Rc3/8 MN3E C4 ø4 push-in fitting (2) MN4E C6 ø6 push-in fitting (1) (2) (3) W4GA/B2 C8 ø8 push-in fitting (2) (3) C10 ø10 push-in fitting (3) W4GB4 CL4 ø4 push-in L-fitting (upward) (1) MN3S0 CL6 ø6 push-in L-fitting (upward) (2) (1) MN4S0 ø8 push-in L-fitting (upward) CL8 (3) (2)ø10 push-in L-fitting (upward) CL10 (3) 4SA/B0 CD4 ø4 push-in L-fitting (downward) (1) 4KA/B CD6 ø6 push-in L-fitting (downward) (1) (2) ø8 push-in L-fitting (downward) (3) CD8 (2) 4KA/B CD10 ø10 push-in L-fitting (downward) (3) (master) М5 M5 (1) 4F Rc1/8 06 (2) 4F 08 Rc1/4 (3) (master) PV5G © Reduced wiring connection Reduced wiring connection GMF T10 Left-side spe Common terminal block (M3 thread) PV5 **T10R** Right-side spe **GMF** T11 Left-side spe Common terminal block (clamping) PV5S-0 T11R Right-side spe T30 Left-side spe D sub-connector 3Q T30R Right-side spe T50 Left-side spe 20-pin flat cable connector MV3QR T50R (with power supply terminal) Right-side spe T51 Left-side spe 20-pin flat cable connector 3MA/B0 (without power supply terminal) T51R Right-side spe T52 Left-side spe 3PA/B 10-pin flat cable connector (without power supply terminal) T52R Right-side spe P/M/B T53 Left-side spe 26-pin flat cable connector (without power supply terminal) T53R Right-side spe NP/NAP 20-pin flat cable connector T56 (without power supply terminal) For serial 4G*0EJ transmission device unit OPP3 connection T81 For serial transmission device (adapter) station OPP7 connection (16-point output) Left-side spe 4F*0EX T82 For serial transmission device (adapter) station OPP7 connection (32-point output) Left-side sper Option 4F*0E Option Blank HMV HSV A/B port filter integrated Mount Mount Blank Direct mount D DIN rail mount (*3) SKH Station No. Station Silencer 2 2 stations Nο TotAirSys (Total Air) to to 20 Refer to the specifications page for the max. station number TotAirSys 1: A filter is built into the P-port as standard. (Gamma)


*3: The DIN rail kit must be prepared separately.

^{*2:} For T8*, select one mounting.

The only alternative to T8* is blank.

Related parts

(8) Coil assembly




Coil assembly


No.	Part name	Model No.
1	Coil assembly	4GR - electrical connections COIL - voltage Blank: Standard A: Ozone proof E* : E-connector E*J : Socket with cover B* : DIN terminal box Blank: Grommet lead wire B includes the DIN terminal box. BN does not include the DIN terminal box.

Coil parts

No.	Part name	Part model No.
2	Coil gasket	4GR-COIL-GASKET
3	Mounting screw	4GR-COIL-SET-SCREW

(9) Lead wire related parts





Socket assembly, DIN terminal box assembly

No.	Part name	Model No.
4	E-connector socket assembly	4GR-SOCKET-ASSY-E **- Voltage
5	Socket assembly with cover	4GR-SOCKET-ASSY-E**J
6	DIN terminal box assembly	4GR-TERMINAL-BOX-Voltage

Socket set

No.	Part model No.
7	4GR-SOCKET-SET

A-connector socket assembly

No.	Part model No.
8	4G[*1]R-SOCKET-ASSY-A[*2][*3]-[*4]

^{*1} Series flow rate size

Note: Refer to "Selection of model No. of socket assembly for expansion" (page 837) for selection.

4GA/B

M4GA/B

MN4GA/B

4GA/B (master)

4GB With sensor

4GD/E

M4GD/E

MN4GD/E

4GA4/B4

MN3E MN4E

W4GA/B2

W4GB4

MN3S0 MN4S0 4SA/B0

4KA/B

4KA/B (master

4F (master) PV5G GMF

PV5 GMF PV5S-0

3Q

MV3QR 3MA/B0

3PA/B

P/M/B

NP/NAP NVP

4G*0EJ

4F*0EX

4F*0E

HM\ HSV

SKH

Silencer

TotAirSys (Total Air)

TotAirSys (Gamma) **Ending**

^{*2} Blank: Left side, R: Right side *3 A: aSOL side, B: bSOL side

^{*4} Row No.