

INSTRUCTION MANUAL

REFRIGERATED COMPRESSED AIR DRYER

Xeroaqua GX Series

GX3108, GX3111, GX3115, GX3122,
GX3137

GX5103, GX5104, GX5106, GX5108,
GX5111, GX5115, GX5122, GX5137



- This product is "industrial use." Be careful of handling enough.
- Be sure to read this manual before installing and operating your dryer.
- The end of a book serves as a CKD WARRANTY. Please save carefully.

Discontinue



Safety instructions

This dryer must be operated by a person who has basic knowledge of electric, compressed air, liquid, piping, refrigerant, etc. We are not responsible for any accidents caused when a person who does not have the basic knowledge or who is not well trained installation, operation, repair, etc.

Improper operation may cause poor performance of the dryer or may cause accidents. We applied a variety of safety measures to our dryers, but improper handling of dryers could cause accidents. Thus, be sure to read and fully understand this manual before using them. "Keep this manual together with the dryer".

Caution for safety

Cautions at operation are indicated in the following two ways.



WARNING



CAUTION



WARNING

used when improper handling could kill or seriously harm operators



CAUTION

used when improper handling could harm operators or damage objects




WARNING: ROTATION

- ★The fan may start rotating suddenly and may be harmful. Do not put your hands or objects into the fan area.
- Be sure to turn off the power before inspection.



WARNING: ELECTRICAL SHOCK

- ★Power supply terminal box, switches, etc. may cause you electrical shock.
- Be sure to turn off the power before inspection. Do not operate the dryer with your wet hands.



CAUTION: HIGH TEMPERATURE

- ★The dryer is hot for a while after shut down the dryer.
- Be sure to turn off the power and to confirm that dryer becomes cool before inspection.



CAUTION: FOOT HOLD

- ★You could fall if you climb on the panel.
- Do not climb on the panel.



EARTH CONNECTION

- ★Be sure to connect earth to prevent electrical shock.



This dryer is industrials. Be sure to fully attend to using the dryer.

Discontinue

Table of Contents

| | |
|--|----|
| Safety instructions | 1 |
| 1. Introduction | 3 |
| 2. Cautions | 3 |
| 2.1 Transportation | 3 |
| 2.2 Operation environment | 4 |
| 2.3 Cautions at operation | 4 |
| 3. Installation | 5 |
| 3.1 Confirm the following | 5 |
| 3.2 The name of each part | 7 |
| 3.3 Operation panel | 14 |
| 3.4 Electric component | 15 |
| 3.5 Installation features | 17 |
| 3.6 Fixixation | 17 |
| 3.7 Air piping | 18 |
| 3.8 Drain piping | 19 |
| 3.9 Electrical wiring | 20 |
| 4. Functional explanation | 22 |
| 4.1 Functional explanation | 22 |
| 4.2 System diagram | 23 |
| 5. Preparation for operation & Operation | 25 |
| 5.1 Preparation for operation | 25 |
| 5.2 How to start and stop the dryer (GX3108 GX5103,5104,5106,5108) | 25 |
| 5.3 How to start and stop the dryer (GX3111,3115,3122,3137 GX5111,5115,5122,5137) | 26 |
| 5.4 When safety device turns on and the dryer stops running | 27 |
| 5.4.1 Safety device | 27 |
| 5.4.2 How to reset | 28 |
| 6. Maintenance and check point | 29 |
| 6.1 Items of maintenance and check point | 29 |
| 6.2 Consumables and maintenance parts | 30 |
| 6.3 Storage | 31 |
| 7. After sales service | 31 |
| 8. Trouble shooting | 32 |
| 9. Specifications | 36 |
| 10. Dimensions | 38 |
| 11. Electrical circuit | 41 |
| 12. CKD WARRANTY | 43 |

1. Introduction


Thank you very much for purchasing CKD Product.

This manual explains basic points of installation, operation, etc. to have our refrigerated air dryer, Xeroaqua GX Series perform at their best. Be sure to read this manual before using your dryer. Keep this manual together with the dryer.


2. Cautions

2.1 Transportation

- 1) Do not fall down the dryer. Also do not give vibration or impact to the dryer.
*Internal parts could get damaged.
- 2) Do not climb up on the dryer or put objects on the dryer.
*Workers could get hurt.
- 3) Move the product with a fork lift as shown in the drawing.
(GX3111,3115,3122,3137,GX5111,5115,5122,5137)



- 4) Move the product with a crane.



2. 2 Operation Environment

- 1) Do not install the dryer outdoor.
*This product dose not have water-proof structure. Water or rain splashing to its electrical system could result in leak or fire.
- 2) Operating ambient temperature should be 2 to 43 ° C (no condensation).
*Drain freezes under the temperature of 2°C or below, and this could cause break-down
Operation under the temperature of 43 ° C or above could stop the operation abnormally or could shorten the service life of the product.
- 3) Do not use the dryer in a place with direct sun light, powder dust, heat producing objects, corrosive gas, explosive gas, ignitable gas or combustible gas.
*Break-down, explosion, or fire may result.


2. 3 Cautions at operation

- 1) Do not use the dryer to remove humidity of except compressed air.
Break-down, explosion, or fire may result.
- 2) Install an earth leakage breaker at power supply.
*Electric shock may result.
- 3) Ground to earth.
*Causes of an electric shock or a fire.
- 4) Use the dryer within specifications.
*Operation may stop abnormally, or the product' s service life may be shortened.
- 5) Do not frequent start and stop the dryer.
Hold frequency of starting/shutting off within 6 times/hour, keep it running for at least 5 minutes before shutting it off and hold restarting it for 3 minutes or longer.
*Break-down or shorter service life of the product may result.
- 6) Do not turn on the power supply without the panel on.
*Electric shock or heat injury may result, or rotation parts could hurt workers.
- 7) Remove drain before it enters the dryer when drain flows into the dryer with compressed air.
*Drain could leak to the secondary side of the dryer.
- 8) Don't carry out reconstruction of this machine.
*It becomes an unexpected accident and the cause of a life fall.
- 9) Check the dew point gauge or dew point lamps during operation.
*If dew point temp. does not show the green belt, it will become the cause of an unusual stop or it will become the cause which shortens the life of a compressor etc.
- 1 0) If emergency stop occurs during operation, remove the cause of abnormal conditions referring to the trouble shooting.
*If the emergency stop occurs repeatedly, this may cause the dryer to malfunction.
- 1 1) Do not use the dryer for pneumatic caisson shield or respiratory medical equipment.
*It could cause an accident includes injury.
- 1 2) Do not use the dryer for transportation devices such as automobile, ship etc.
* Vibration could be a cause of break down of the internal components.

3. Installation

3. 1 Confirm the following.

1) Confirm the contents on the label. (Model No., Spec. etc.)



| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|---------------|-------------------|------|----------|---------------|--------|----------------------|-------|
| GX3108-AC100V | 1 φ AC100V50/60Hz | 50°C | 4.5/4.9A | R-407C, 470g | 1.6MPa | 1.2/1.3 m³/min ANR | 40kg |
| GX3108-AC200V | 1 φ AC200V50/60Hz | 50°C | 2.4/2.5A | R-407C, 470g | 1.6MPa | 1.2/1.3 m³/min ANR | 40kg |
| GX3111-AC200V | 1 φ AC200V50/60Hz | 50°C | 6.5/6.7A | R-407C, 405g | 1.6MPa | 1.65/1.82 m³/min ANR | 65kg |
| GX3115-AC200V | 1 φ AC200V50/60Hz | 50°C | 6.6/6.8A | R-407C, 405g | 1.6MPa | 2.8/3.1 m³/min ANR | 65kg |
| GX3122-AC200V | 1 φ AC200V50/60Hz | 50°C | 6.7/7.0A | R-407C, 440g | 1.6MPa | 3.9/4.3 m³/min ANR | 83kg |
| GX3137-AC200V | 3 φ AC200V50/60Hz | 50°C | 5.4/6.0A | R-407C, 1050g | 1.6MPa | 6.6/7.3 m³/min ANR | 102kg |

| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|---------------|-------------------|------|-----------|---------------|--------|----------------------|-------|
| GX5103-AC100V | 1 φ AC100V50/60Hz | 80°C | 3.2/2.7A | R-407C, 220g | 1.6MPa | 0.31/0.35 m³/min ANR | 28kg |
| GX5103-AC200V | 1 φ AC200V50/60Hz | 80°C | 1.4/1.3A | R-407C, 220g | 1.6MPa | 0.31/0.35 m³/min ANR | 28kg |
| GX5104-AC100V | 1 φ AC100V50/60Hz | 80°C | 3.2/2.8A | R-407C, 220g | 1.6MPa | 0.5/0.55 m³/min ANR | 28kg |
| GX5104-AC200V | 1 φ AC200V50/60Hz | 80°C | 1.4/1.4A | R-407C, 220g | 1.6MPa | 0.5/0.55 m³/min ANR | 28kg |
| GX5106-AC100V | 1 φ AC100V50/60Hz | 80°C | 4.7/5.0A | R-407C, 470g | 1.6MPa | 0.74/0.81 m³/min ANR | 40kg |
| GX5106-AC200V | 1 φ AC200V50/60Hz | 80°C | 2.4/2.4A | R-407C, 470g | 1.6MPa | 0.74/0.81 m³/min ANR | 40kg |
| GX5108-AC100V | 1 φ AC100V50/60Hz | 80°C | 4.7/5.0A | R-407C, 470g | 1.6MPa | 1.2/1.3 m³/min ANR | 40kg |
| GX5108-AC200V | 1 φ AC200V50/60Hz | 80°C | 2.4/2.5A | R-407C, 470g | 1.6MPa | 1.2/1.3 m³/min ANR | 40kg |
| GX5111-AC200V | 1 φ AC200V50/60Hz | 80°C | 6.7/7.0A | R-407C, 405g | 1.6MPa | 1.65/1.82 m³/min ANR | 65kg |
| GX5115-AC200V | 3 φ AC200V50/60Hz | 80°C | 5.9/6.5A | R-407C, 620g | 1.6MPa | 2.8/3.1 m³/min ANR | 76kg |
| GX5122-AC200V | 3 φ AC200V50/60Hz | 80°C | 5.6/6.2A | R-407C, 1050g | 1.6MPa | 3.9/4.3 m³/min ANR | 102kg |
| GX5137-AC200V | 3 φ AC200V50/60Hz | 80°C | 9.0/10.2A | R-407C, 1480g | 1.6MPa | 6.6/7.3 m³/min ANR | 128kg |


⚠【Caution】 If the contents are not clear or there are any questions, please contact CKD or distributors before using the dryer.

- 2) Confirm damage or transformation that is made during the transportation.
- 3) Check whether there are all accessories.

Instruction Manual..... 1
Y-type strainer..... 1 Note1)
Both screw nipple..... 1 Note1)
Tightening joint 1
Insert ring..... 1
Drain tube 1
Note1) Only GX3108,GX5103,5104,5106,5108


3. 2 The name of each part

1) GX3108-AC100, 200V




| | | |
|-----|--|------|
| 20 | High pressure switch | 1 |
| 19 | Dust filter | 1 |
| 18 | Capillary tube | 1 |
| 17 | Strainer | 1 |
| 16 | Thermo sensor(fan control) | 1 |
| 15 | Power source inlet | 1 |
| 14 | Service valve | 2 |
| 13 | Electric box | 1 |
| 12 | Capacity control valve | 1 |
| 11 | Fan blade | 1 |
| 10 | Fan motor | 1 |
| 9 | Condenser | 1 |
| 8 | Compressor | 1 |
| 7 | Heat exchanger | 1 |
| 6 | Dew point gauge | 1 |
| 5 | Solenoid valve(drain discharge) | 1 |
| 4 | Drain outlet(drain cock,normally closed) | 1 |
| 3 | Drain outlet | 1 |
| 2 | Air outlet | 1 |
| 1 | Air inlet | 1 |
| No. | Parts name | Q'ty |

2) GX3111-AC200V




| | | |
|-----|--|------|
| 21 | Dust filter | 1 |
| 20 | Capillary tube | 1 |
| 19 | Strainer | 1 |
| 18 | Thermo sensor(dew point) | 1 |
| 17 | Thermo sensor(fan control) | 1 |
| 16 | Thermo sensor(inlet air temp.) | 1 |
| 15 | Controller | 1 |
| 14 | Power source inlet | 1 |
| 13 | Service valve | 2 |
| 12 | Electric box | 1 |
| 11 | Capacity control valve | 1 |
| 10 | Fan blade | 1 |
| 9 | Fan motor | 1 |
| 8 | Condenser | 1 |
| 7 | Compressor | 1 |
| 6 | Heat exchanger | 1 |
| 5 | Drain purger ass'y | 1 |
| 4 | Drain outlet(drain cock,normally closed) | 1 |
| 3 | Drain outlet | 1 |
| 2 | Air outlet | 1 |
| 1 | Air inlet | 1 |
| No. | Parts name | Q'ty |

3) GX3115-AC200V




| | | |
|-----|--|------|
| 21 | Dust filter | 1 |
| 20 | Capillary tube | 1 |
| 19 | Strainer | 1 |
| 18 | Thermo sensor(dew point) | 1 |
| 17 | Thermo sensor(fan control) | 1 |
| 16 | Thermo sensor(inlet air temp.) | 1 |
| 15 | Controller | 1 |
| 14 | Power source inlet | 1 |
| 13 | Service valve | 2 |
| 12 | Electric box | 1 |
| 11 | Capacity control valve | 1 |
| 10 | Fan blade | 1 |
| 9 | Fan motor | 1 |
| 8 | Condenser | 1 |
| 7 | Compressor | 1 |
| 6 | Heat exchanger | 1 |
| 5 | Drain purger ass'y | 1 |
| 4 | Drain outlet(drain cock,normally closed) | 1 |
| 3 | Drain outlet | 1 |
| 2 | Air outlet | 1 |
| 1 | Air inlet | 1 |
| No. | Parts name | Q'ty |

4) GX3122-AC200V




| | | |
|-----|--|------|
| 21 | Dust filter | 1 |
| 20 | Capillary tube | 1 |
| 19 | Strainer | 1 |
| 18 | Thermo sensor(dew point) | 1 |
| 17 | Thermo sensor(fan control) | 1 |
| 16 | Thermo sensor(inlet air temp.) | 1 |
| 15 | Controller | 1 |
| 14 | Power source inlet | 1 |
| 13 | Service valve | 2 |
| 12 | Electric box | 1 |
| 11 | Capacity control valve | 1 |
| 10 | Fan blade | 1 |
| 9 | Fan motor | 1 |
| 8 | Condenser | 1 |
| 7 | Compressor | 1 |
| 6 | Heat exchanger | 1 |
| 5 | Drain purger ass'y | 1 |
| 4 | Drain outlet(drain cock,normally closed) | 1 |
| 3 | Drain outlet | 1 |
| 2 | Air outlet | 1 |
| 1 | Air inlet | 1 |
| No. | Parts name | Q'ty |

5) GX3137-AC200V




| | | |
|-----|--|------|
| 21 | Dust filter | 1 |
| 20 | Capillary tube | 1 |
| 19 | Strainer | 1 |
| 18 | Thermo sensor(dew point) | 1 |
| 17 | Thermo sensor(fan control) | 1 |
| 16 | Thermo sensor(inlet air temp.) | 1 |
| 15 | Controller | 1 |
| 14 | Power source inlet | 1 |
| 13 | Service valve | 2 |
| 12 | Electric box | 1 |
| 11 | Capacity control valve | 1 |
| 10 | Fan blade | 1 |
| 9 | Fan motor | 1 |
| 8 | Condenser | 1 |
| 7 | Compressor | 1 |
| 6 | Heat exchanger | 1 |
| 5 | Drain purger ass'y | 1 |
| 4 | Drain outlet(drain cock,normally closed) | 1 |
| 3 | Drain outlet | 1 |
| 2 | Air outlet | 1 |
| 1 | Air inlet | 1 |
| No. | Parts name | Q'ty |

6) GX5103-AC100, 200V




| | | |
|-----|--|------|
| 19 | High pressure switch | 1 |
| 18 | Dust filter | 1 |
| 17 | Capillary tube | 1 |
| 16 | Strainer | 1 |
| 15 | Thermo sensor(fan control) | 1 |
| 14 | Power source inlet | 1 |
| 13 | Service valve | 2 |
| 12 | Electric box | 1 |
| 11 | Capacity control valve | 1 |
| 10 | Fan motor | 2 |
| 9 | Condenser | 1 |
| 8 | Compressor | 1 |
| 7 | Heat exchanger | 1 |
| 6 | Dew point gauge | 1 |
| 5 | Solenoid valve(drain discharge) | 1 |
| 4 | Drain outlet(drain cock,normally closed) | 1 |
| 3 | Drain outlet | 1 |
| 2 | Air outlet | 1 |
| 1 | Air inlet | 1 |
| No. | Parts name | Q'ty |

7) GX5104-AC100, 200V




| | | |
|-----|--|------|
| 19 | High pressure switch | 1 |
| 18 | Dust filter | 1 |
| 17 | Capillary tube | 1 |
| 16 | Strainer | 1 |
| 15 | Thermo sensor(fan control) | 1 |
| 14 | Power source inlet | 1 |
| 13 | Service valve | 2 |
| 12 | Electric box | 1 |
| 11 | Capacity control valve | 1 |
| 10 | Fan motor | 2 |
| 9 | Condenser | 1 |
| 8 | Compressor | 1 |
| 7 | Heat exchanger | 1 |
| 6 | Dew point gauge | 1 |
| 5 | Solenoid valve(drain discharge) | 1 |
| 4 | Drain outlet(drain cock,normally closed) | 1 |
| 3 | Drain outlet | 1 |
| 2 | Air outlet | 1 |
| 1 | Air inlet | 1 |
| No. | Parts name | Q'ty |

8) GX5106-AC100, 200V




| | | |
|-----|--|------|
| 20 | High pressure switch | 1 |
| 19 | Dust filter | 1 |
| 18 | Capillary tube | 1 |
| 17 | Strainer | 1 |
| 16 | Thermo sensor(fan control) | 1 |
| 15 | Power source inlet | 1 |
| 14 | Service valve | 2 |
| 13 | Electric box | 1 |
| 12 | Capacity control valve | 1 |
| 11 | Fan blade | 1 |
| 10 | Fan motor | 1 |
| 9 | Condenser | 1 |
| 8 | Compressor | 1 |
| 7 | Heat exchanger | 1 |
| 6 | Dew point gauge | 1 |
| 5 | Solenoid valve(drain discharge) | 1 |
| 4 | Drain outlet(drain cock,normally closed) | 1 |
| 3 | Drain outlet | 1 |
| 2 | Air outlet | 1 |
| 1 | Air inlet | 1 |
| No. | Parts name | Q'ty |

9) GX5108-AC100, 200V




| | | |
|-----|--|------|
| 20 | High pressure switch | 1 |
| 19 | Dust filter | 1 |
| 18 | Capillary tube | 1 |
| 17 | Strainer | 1 |
| 16 | Thermo sensor(fan control) | 1 |
| 15 | Power source inlet | 1 |
| 14 | Service valve | 2 |
| 13 | Electric box | 1 |
| 12 | Capacity control valve | 1 |
| 11 | Fan blade | 1 |
| 10 | Fan motor | 1 |
| 9 | Condenser | 1 |
| 8 | Compressor | 1 |
| 7 | Heat exchanger | 1 |
| 6 | Dew point gauge | 1 |
| 5 | Solenoid valve(drain discharge) | 1 |
| 4 | Drain outlet(drain cock,normally closed) | 1 |
| 3 | Drain outlet | 1 |
| 2 | Air outlet | 1 |
| 1 | Air inlet | 1 |
| No. | Parts name | Q'ty |

1 0) GX5111-AC200V




| | | |
|-----|--|------|
| 21 | Dust filter | 1 |
| 20 | Capillary tube | 1 |
| 19 | Strainer | 1 |
| 18 | Thermo sensor(dew point) | 1 |
| 17 | Thermo sensor(fan control) | 1 |
| 16 | Thermo sensor(inlet air temp.) | 1 |
| 15 | Controller | 1 |
| 14 | Power source inlet | 1 |
| 13 | Service valve | 2 |
| 12 | Electric box | 1 |
| 11 | Capacity control valve | 1 |
| 10 | Fan blade | 1 |
| 9 | Fan motor | 1 |
| 8 | Condenser | 1 |
| 7 | Compressor | 1 |
| 6 | Heat exchanger | 1 |
| 5 | Drain purger ass'y | 1 |
| 4 | Drain outlet(drain cock,normally closed) | 1 |
| 3 | Drain outlet | 1 |
| 2 | Air outlet | 1 |
| 1 | Air inlet | 1 |
| No. | Parts name | Q'ty |

1 1) GX5115-AC200V




| | | |
|-----|--|------|
| 21 | Dust filter | 1 |
| 20 | Capillary tube | 1 |
| 19 | Strainer | 1 |
| 18 | Thermo sensor(dew point) | 1 |
| 17 | Thermo sensor(fan control) | 1 |
| 16 | Thermo sensor(inlet air temp.) | 1 |
| 15 | Controller | 1 |
| 14 | Power source inlet | 1 |
| 13 | Service valve | 2 |
| 12 | Electric box | 1 |
| 11 | Capacity control valve | 1 |
| 10 | Fan blade | 1 |
| 9 | Fan motor | 1 |
| 8 | Condenser | 1 |
| 7 | Compressor | 1 |
| 6 | Heat exchanger | 1 |
| 5 | Drain purger ass'y | 1 |
| 4 | Drain outlet(drain cock,normally closed) | 1 |
| 3 | Drain outlet | 1 |
| 2 | Air outlet | 1 |
| 1 | Air inlet | 1 |
| No. | Parts name | Q'ty |

1 2) GX5122-AC200V



| | | |
|-----|--|------|
| 21 | Dust filter | 1 |
| 20 | Capillary tube | 1 |
| 19 | Strainer | 1 |
| 18 | Thermo sensor(dew point) | 1 |
| 17 | Thermo sensor(fan control) | 1 |
| 16 | Thermo sensor(inlet air temp.) | 1 |
| 15 | Controller | 1 |
| 14 | Power source inlet | 1 |
| 13 | Service valve | 2 |
| 12 | Electric box | 1 |
| 11 | Capacity control valve | 1 |
| 10 | Fan blade | 1 |
| 9 | Fan motor | 1 |
| 8 | Condenser | 1 |
| 7 | Compressor | 1 |
| 6 | Heat exchanger | 1 |
| 5 | Drain purger ass'y | 1 |
| 4 | Drain outlet(drain cock,normally closed) | 1 |
| 3 | Drain outlet | 1 |
| 2 | Air outlet | 1 |
| 1 | Air inlet | 1 |
| No. | Parts name | Q'ty |

1 3) GX5137-AC200V




| | | |
|-----|--|------|
| 21 | Dust filter | 1 |
| 20 | Capillary tube | 1 |
| 19 | Strainer | 1 |
| 18 | Thermo sensor(dew point) | 1 |
| 17 | Thermo sensor(fan control) | 1 |
| 16 | Thermo sensor(inlet air temp.) | 1 |
| 15 | Controller | 1 |
| 14 | Power source inlet | 1 |
| 13 | Service valve | 2 |
| 12 | Electric box | 1 |
| 11 | Capacity control valve | 1 |
| 10 | Fan blade | 1 |
| 9 | Fan motor | 1 |
| 8 | Condenser | 1 |
| 7 | Compressor | 1 |
| 6 | Heat exchanger | 1 |
| 5 | Drain purger ass'y | 1 |
| 4 | Drain outlet(drain cock,normally closed) | 1 |
| 3 | Drain outlet | 1 |
| 2 | Air outlet | 1 |
| 1 | Air inlet | 1 |
| No. | Parts name | Q'ty |

3. 3 Operation panel

1) GX3108

GX5103, 5104, 5106, 5108




Note1) It may differ from the actual pressure dew point.
Use it as a reference value.

Operation part detail

2) GX3111, 3115, 3122, 3137

GX5111, 5115, 5122, 5137




Note1) It may differ from the actual pressure dew point.
Use it as a reference value.

Operation part detail

3.4 Electric component

1) GX3108


GX5103, 5104, 5106, 5108




Note1) Power cord (with plug) is attached to AC100V model.

2) GX3111, 3115, 3122

GX5111



3) GX3137
GX5115, 5122, 5137



3. 5 Installation features



- 1) Do not install the dryer outdoor or high humidity place.

*This product does not have waterproof structure.

Water or rain splashing, high humidity (=85% RH or over) could cause leak or fire to electrical systems.



- 2) Operating ambient temperature should be 2 to 43°C with no condensation.

*Drain freeze under the temperature of 2°C or below, and this could cause breakdown.

Operation under the temperature of 43°C or above could stop the operation abnormally or could shorten the service life of the product.



- 3) Install the dryer without direct sunlight, powder dust, heating elements, corrosive gas, explosive gas, inflammable gas or combustibles.

*Breakdown, explosion or ignition may result.




- 4) The installation floor should have a solid concrete foundation with level and flat surface.

*Weak or inclin foundation may cause noise and vibration.




- 5) Need to keep spaces as a following figure for maintenance.

*Do not enter the exhaust air to suction part.



3. 6 Fixixation

Fix the dryer body by anchor bolts to avoid the dryer falling due to earthquake or impact.



| | ※1 | ※2 |
|--------|-----------------|-----------|
| GX3108 | M8× ℓ 70 | ϕ 10 |
| GX3111 | | |
| GX3115 | | |
| GX5103 | | |
| GX5104 | | |
| GX5106 | | |
| GX5108 | | |
| GX5111 | | |
| GX5115 | | |
| GX3122 | M10× ℓ 100 | ϕ 13 |
| GX3137 | | |
| GX5122 | | |
| GX5137 | | |

3. 7 Air piping


- 1) Confirm which is Air inlet or Air outlet before piping.
- 2) Mount the attached Y-type strainer by nipple or by other pipes.
(GX3108, GX5103, 5104, 5106, 5108)



【CAUTION】

- If use is carried out without attaching Y type strainer in an air inlet, it will become failure and the cause of garbage clogging.
- Do not mistake direction of Y type strainer.

Rear side



Rear side


Pipe size

| | |
|--------|--------------------------------|
| GX3108 | Rc ³ / ₄ |
| GX5103 | Rc ³ / ₈ |
| GX5104 | Rc ³ / ₈ |
| GX5106 | Rc ³ / ₄ |
| GX5108 | Rc ³ / ₄ |

- 3) Recommend a by-pass circuit in the air circuit.

〈On and off operation〉


Installation of by-pass piping is recommended.



CAUTION By-pass piping is normally closed. Water comes out at the end if air flows when it is open.

〈24 hours operation〉

Installation of two dryers is recommended. One is used regularly, and the other is for emergency.




CAUTION Gate valve which isn't used the dryer is normally closed. Water comes out at the end if air flows when it is open.

- 4) Design the piping in the way not to apply the piping weight to the dryer body.
- 5) Vibration of the air compressor should not be transmitted.
- 6) Piping must be able to endure the operating pressure and temperature. No air leakage is allowed from connection parts.
- 7) Use zinc plated steel pipe or stainless pipe.
- 8) Flash air circuit before connecting pipes to remove dust, etc.


3. 8 Drain Piping

- 1) Confirm the drain outlet location before piping.

Rear side



GX3108
GX5103, 5104, 5106, 5108



GX3111, 3115, 3122, 3137
GX5111, 5115, 5122, 5137

Connect the drain pipe to the drain outlet (Rc1/4) using enclosed items.


Have its end open atmosphere.

Fit a nut and a sleeve to the transparent vinyl tube as shown in figure below. Insert a insert-ring in the drain tube until it hits the drain tube (end). Then tighten the nut by hand. Finally, tighten the nut one and one-fourth to one half by some tool such as a spanner etc.

Enclosed items : Tightening joint($\phi 10 \times R1/4$)

Insert-ring($\phi 10$)

Drain tube (O.D $\phi 10 \times$ I.D $\phi 7 \times 1.5$ m)




- 2) When connecting the items on sale as the drain pipe, take the following into consideration.
The inside diameter of drain pipe must be $\phi 7$ or larger and the length must be 2m or less.
Have its end open to atmosphere.
- 3) Drain may not be discharged due to back pressure if pipe rises in part or if pipe is too long.
Use down-slope piping to let drain flow smoothly.
- 4) Drain is regularly discharged compulsorily by air pressure. Fix drain discharge tube, etc. firmly.
- 5) Drain must be treated if oil is mixed in it. Consult industrial waste treatment companies for treatment.
- 6) Use the drain cock at the time of a maintenance.

3. 9 Electrical wiring

- 1) Use proper voltage.
 - * Voltage must be within $\pm 10\%$ of rated voltage.
- 2) Mount an earth leakage breaker with over-load protection (sensitivity current 30mA or less) to power supply.
- 3) How to connect power supply code


- Make a hole for wiring on the rubber bushing at the upper back part of the dryer.




- Remove the front panel.

Procedure

- ① The front panel is lifted upwards.
- ② The attachment guide is removed from the right-and-left side panel.
- ③ The front panel is lifted upwards and it extracts from the plug part of the base.



- Connect the terminal block L1, L2,(L1,L2,L3 if three phase type), and the earth leakage breaker by wire.



- Use round ring-style terminal.
- Two cores required for single phase type, and three cored required for three phase type.
- Power cord (with plug) is attached to AC100V model.

⚠【CAUTION】

- Insert a power cable, an output signal cable, a remote operation cable and a ground cable to wire each terminals firmly without looseness or coming off.
- ※Looseness or coming off wiring could causes of a fire.
- Refer to operation manual for option about wiring method when specifying voltage.

4) How to connect earth wire

- As power supply code connection, connect the earth wire to the terminal box PE and the earth terminal in the panel. (The D sort grounding construction by the electric construction contractor is required.)

⚠ 【CAUTION】 Do not connect the earth wire to a water pipe, gas pipe, lightning conductor, etc.

5) Wiring capacity (A power cable and a ground cable)

| | Recommendation breaker capacity (A) | Cable size | | | |
|---------------|--|------------|------------|------------|------------|
| | | Length 10m | Length 20m | Length 30m | Length 50m |
| GX3108-AC100V | 10 | 2.0 | 2.0 | 2.0 | 3.5 |
| GX3108-AC200V | 5 | 2.0 | 2.0 | 2.0 | 2.0 |
| GX3111-AC200V | 15 | 2.0 | 2.0 | 3.5 | 3.5 |
| GX3115-AC200V | 15 | 2.0 | 2.0 | 3.5 | 3.5 |
| GX3122-AC200V | 15 | 2.0 | 2.0 | 3.5 | 3.5 |
| GX3137-AC200V | 15 | 2.0 | 3.5 | 5.5 | 14.0 |
| | | | | | |
| GX5103-AC100V | 5 | 2.0 | 2.0 | 2.0 | 2.0 |
| GX5104-AC100V | 5 | 2.0 | 2.0 | 2.0 | 2.0 |
| GX5106-AC100V | 10 | 2.0 | 2.0 | 2.0 | 3.5 |
| GX5108-AC100V | 10 | 2.0 | 2.0 | 2.0 | 3.5 |
| GX5103-AC200V | 5 | 2.0 | 2.0 | 2.0 | 2.0 |
| GX5104-AC200V | 5 | 2.0 | 2.0 | 2.0 | 2.0 |
| GX5106-AC200V | 5 | 2.0 | 2.0 | 2.0 | 2.0 |
| GX5108-AC200V | 5 | 2.0 | 2.0 | 2.0 | 2.0 |
| GX5111-AC200V | 15 | 2.0 | 2.0 | 3.5 | 5.5 |
| GX5115-AC200V | 15 | 2.0 | 3.5 | 5.5 | 14.0 |
| GX5122-AC200V | 15 | 2.0 | 3.5 | 5.5 | 14.0 |
| GX5137-AC200V | 15 | 5.5 | 8.0 | 14.0 | 22.0 |

• Power cable is type VCT(600V vinyl cab tire cable), and ground cable is type IV (600V vinyl insulated wire) as shown by the above chart.

4. Functional explanation

4.1 Functional explanation

1) Air circuit

The compressed air which became wet warmly is beforehand cooled by precooler, and then, it goes into an evaporator, heat exchange is carried out with cold freon gas, and it is cooled to the dew point. Reheat of the compressed air cooled and dehumidified is carried out by reheater, and it turns into warm dry air.

2) Refrigerant circuit


It is, and the freon gas which became high temperature high pressure with the compressor (refrigerant compressor) is cooled and condensed with a condenser, and serves as high-pressure refrigerant liquid. And by decompressing in a capillary tube, it becomes the liquid of low-temperature low pressure. Using an evaporator, by carrying out heat exchange with the warm damp compressed air, coolant liquid evaporates and cools compressed air by the evaporation heat. The gasified refrigerant returns to a compressor again.

3) Drain circuit


The steam in compressed air is cooled and condensed with an evaporator, and it is serves as drain (moisture). The drain tank is covered with drain. The drain collected in the drain tank is discharged periodically when a valve operates, and also the drain cock has clung so that discharge may be manually possible, please use it a maintenance or in an emergency.

4. 2 System diagram


- 1) GX3108
GX5103, 5104, 5106, 5108




- 2) GX3111, 3115
GX5111



3) GX5115



4) GX3122, 3137 GX5122, 5137



5. Preparation for operation & Operation

5.1 Preparation for operation

- 1) Confirm that air piping, electrical wiring and drain piping are properly connected.
- 2) Confirm that the gate valves next to the dryer and the gate valve of by-pass piping are closed. Confirm that the air pressure in the pipes is zero.

5.2 How to start and stop the dryer (GX3108, 5103, 5104, 5106, 5108)

- 1) Turn on the power supply.
- 2) "POWER" lamp on the operation panel turns on.
- 3) Push "START-STOP" button ("I" mark) on the operation panel. "RUN" lamp turns on, and the dryer starts running. After a while, "DEW POINT" gauge enters the green area and indicates air pressure dew point.



【CAUTION】

- During the dryer is running, the fan turns on and off repeatedly. This is normal.
- The value of dew point gauge may differ from the actual pressure dew point. Use it as a reference value.

- 4) Open the gate valve on the dryer inlet side gradually.



【CAUTION】

Pass compressed air after about 5 minutes from starting. If compressed air is passed in time shorter than this, damp air may flow in piping and drain may occur within piping.

- 5) Open the gate valve on the dryer outlet side gradually.
- 6) The drain removed by the dryer is regularly discharged compulsorily by air pressure when solenoid valve is on.



【CAUTION】

The drain outlet with a drain cock mounted is for emergency. Normally, it needs to be closed.

- 7) Push "START-STOP" button ("O" mark) on the operation panel. "RUN" lamp turns off, and the dryer stops running.



【CAUTION】

- ① Frequent turning on and off is causes of trouble. The frequency of starting/stop is carried out in 6 or less times/o'clock, and please do not let me stop for 5 minutes after starting, and also give stop time as the above for 3 minutes

※It becomes the cause of failure or a life fall.

- ② Stop an air compressor and extract residual pressure, before stopping this machine.

※The air which is not dehumidified may flow to a secondary side of this machine

5.3 How to start and stop the dryer (GX3111, 3115, 3122, 3137, GX5111, 5115, 5122, 5137)

- 1) Turn on the power supply.
- 2) "DEW POINT" lamp on the operation panel turns on. At this time, the lamp indicates about ambient temperature.
- 3) Push "START" button ("I" mark) on the operation panel. "RUN" lamp turns on, and the dryer starts running. After a while, "DEW POINT" lamp enters the green area and indicates air pressure dew point.



【CAUTION】

- During the dryer is running, the fan turns on and off repeatedly. This is normal.
- The value of dew point gauge may differ from the actual pressure dew point. Use it as a reference value.

- 4) Open the gate valve on the dryer inlet side gradually.



【CAUTION】

Pass compressed air after about 5 minutes from starting. If compressed air is passed in time shorter than this, damp air may flow in piping and drain may occur within piping.

- 5) Open the gate valve on the dryer outlet side gradually.
- 6) The drain removed by the dryer is regularly discharged compulsorily by air pressure when solenoid valve is on.



【CAUTION】

The drain outlet with a drain cock mounted is for emergency. Normally, it needs to be closed.

- 7) Push "STOP" button on the operation panel. "RUN" lamp turns off, and the dryer stops running.



【CAUTION】

- ① Frequent turning on and off is causes of trouble. The frequency of starting/stop is carried out in 6 or less times/o'clock, and please do not let me stop for 5 minutes after starting, and also give stop time as the above for 3 minutes

※It becomes the cause of failure or a life fall.

- ② In three phase type, It does not start, even if it will push the "START" button, if the order of a power supply is different. Something should replace two (L1 and L3) among three phase.

※Do not start in the state where the order to unite is different (electromagnetic contactor is compulsorily operated with a finger). A compressor breaks down.

- ③ Stop an air compressor and extract residual pressure, before stopping this machine.

※The air which is not dehumidified may flow to a secondary side of this machine

5. 4 When safety device turns on and the dryer stops running

5. 4. 1 Safety device (Refer to 11 Electrical Circuit)

- 1 – 1) When a compressor becomes hot or when over current flows, safety device turns on and run lamp turns off, and the dryer stops running.
(GX3108, GX5103, 5104, 5106, 5108)
- 1 – 2) When a compressor becomes hot or when over current flows, safety device and alarm lamp turns on, and the dryer stops running.
(GX3111, 3115, 3122, 3137, GX5111, 5115, 5122, 5137)
- 2 – 1) When a refrigerant high-pressure rises abnormally, a high-pressure switch will work and run lamp turns off, and a dryer will stop.
(GX3108, GX5103, 5104, 5106, 5108)
- 2 – 2) When a refrigerant high-pressure rises abnormally, a thermo sensor will work and alarm lamp turns on, and a dryer will stop.
(GX3111, 3115, 3122, 3137, GX5111, 5115, 5122, 5137)

3) Setting value list

| Mark | Model | Parts list | Applications | Setting value | Reset method |
|------|--------------------|------------------------|--|---------------|--------------------------------|
| FR01 | GX3108-AC100V | Overload protector | Temperature of the compressor upper part & current | 6A (100°C) | Automatic reset (Thermal type) |
| | GX3108-AC200V | | | 3A (100°C) | |
| | GX3111-AC200V | | | 9.6A (100°C) | |
| | GX3115-AC200V | | | 9.6A (100°C) | |
| | GX3122-AC200V | | | 9.6A (100°C) | |
| | GX3137-AC200V | Electromagnetic switch | Compressor current | 9A | Manual reset |
| | GX5103-AC100V | Overload protector | Temperature of the compressor upper part & current | 3A (100°C) | Automatic reset (Thermal type) |
| | GX5104-AC100V | | | 3A (100°C) | |
| | GX5106-AC100V | | | 6A (100°C) | |
| | GX5108-AC100V | | | 6A (100°C) | |
| | GX5103-AC200V | | | 1.6A (100°C) | |
| | GX5104-AC200V | | | 1.6A (100°C) | |
| | GX5106-AC200V | | | 3A (100°C) | |
| | GX5108-AC200V | | | 3A (100°C) | |
| | GX5111-AC200V | | | 9.6A (100°C) | |
| | GX5115-AC200V | Electromagnetic switch | Compressor current | 9A | Manual reset |
| | GX5122-AC200V | | | 9A | |
| | GX5137-AC200V | | | 12A | |
| SP01 | GX3108-AC100V,200V | High pressure switch | Refrigerant circuit | 2.75MPa OFF | Manual reset |
| | GX5103-AC100V,200V | | | | |
| | GX5104-AC100V,200V | | | | |
| | GX5106-AC100V,200V | | | | |
| | GX5108-AC100V,200V | | | | |
| RT02 | GX3111-AC200V | Thermo sensor | Refrigerant circuit | 63°C | Automatic reset |
| | GX3115-AC200V | | | | |
| | GX3122-AC200V | | | | |
| | GX3137-AC200V | | | | |
| | GX5111-AC200V | | | | |
| | GX5115-AC200V | | | | |
| | GX5122-AC200V | | | | |
| ST01 | GX3137-AC200V | Internal thermostat | Temperature of the compressor inside | 130°C OFF | Automatic reset (Thermal type) |
| | GX5115-AC200V | | | 130°C OFF | |
| | GX5122-AC200V | | | 130°C OFF | |
| | GX5137-AC200V | Thermal switch | Temperature of the compressor upper part | 115°C OFF | |
| FU01 | Common | Fuse | Electric circuit harness | 5A | Exchange |

5. 4. 2 How to reset

- 1) Push "STOP" button("O" mark) on the operation panel and turn off the power supply.
- 2) Remove causes that stopped the dryer abnormally.
(Refer to trouble shooting on "8.Trouble shooting")
- 3) Reset the safety device. (Refer to "3.2 The name of each part", "3.4 Elwctric component" and "5.4.1 Safety device")
- 4) Turn on the power supply.



【CAUTION】

- Be sure to turns off the power supply when remove causes of problems.
 - The product carried thermal type safety device, you may not be able to restart the dryer even though removing the causes. In this case, turn off the power supply and wait till the compressor becomes cool. (normally 10 to 15 minutes)
 - Thermal type safety device is Automatic reset (normally 10 to 15 minutes). If "START·STOP" button turns on, it may be repeated running and stopping.
- ※Power source and "START·STOP" button turns off, when dryer becomes abnormal stop.
(GX3108, GX5103, 5104, 5106, 5108)

6 . Maintenance and check point

6. 1 Items of maintenance and check point

Check following items for full performance and longer service life of the dryer.

| Checking item | Model | Contents | Checking cycle | | |
|----------------------------------|--|--|----------------|--------|-----------------|
| | | | Daily | Weekly | Monthly |
| "POWER" lamp | GX3108 GX5103, GX5104 GX5106, GX5108 | "POWER" lamp is on. | ○ | | |
| "START-STOP" switch | GX3108 GX5103, GX5104 GX5106, GX5108 | "START-STOP" switch lamp is on. | ○ | | |
| "RUN" lamp | GX3111, GX3115 GX3122, GX3137 GX5111, GX5115 GX5122, GX5137 | "RUN" lamp is on. | ○ | | |
| Dew point gauge | GX3108 GX5103, GX5104 GX5106, GX5108 | Before operation: About ambient temp. is displayed. Under operation: Enter the green area | ○ | | |
| Dew point lamp | GX3111, GX3115 GX3122, GX3137 GX5111, GX5115 GX5122, GX5137 | Before operation: Ambient temp. is displayed. Under operation: Enter the green area | ○ | | |
| Screen for inlet Y-type strainer | GX3108 GX5103, GX5104 GX5106, GX5108 | Remove the screen for Y-type strainer mounted to the inlet and clean it. | | | ○ (Cleaning) |
| Dust filter for Condenser | Common | Dust filter is not dirty. | | | ○ (Cleaning) |
| Drain discharge | | Drain is discharged periodically. | ○ | | |
| Compressor | | No abnormal noise is generated. | ○ | | |
| Fan motor | | No abnormal noise is generated. | ○ | | |
| Air leak | | No air leaks. | | | ○ |

1) Cleaning methods

•Dust filter for condenser


Dirt is blown away using air gun. wash in water, when dirt condition is severe.

•Screen for inlet Y-type strainer

Disassembling & A assembling procedures.

Remove the strainer ③ by loosening the cap ②. Clean the strainer and remove foreignmatter, dust, etc. attached to the strainer.

Mount the strainer with the packing ④ being fitted in and tighten them.



【CAUTION】

If cleaning of a dust filter is neglected, it will become a cause of failures, such as a compressor and a fan motor.

6. 2 Consumables and maintenance parts

(Note: pcs/set is use quantity per 1 set of these devices.)

●Consumables (The parts which will be exchanged if the state exhausting was checked periodically and it has exhausted.)

Inspect the following parts periodically, and exchange it based on Exchange judgment standard

| Parts name | pcs/set | Inspection frequency | Exchange judgment standard※ |
|----------------------------|---------|----------------------|---|
| Dust filter | 1 | Monthly | When it damages and dirt. When it does not come off. |
| Fuse | 1 | Each time | When being cut off. |
| Screen for Y-type strainer | *a | Monthly | When dirt does not come off. |

※Be careful that it is not a guarantee value since the operation time (years) indicated changes with operating conditions (ambient temperature, installation environment, etc.). Years are a standard at the time of considering as 12 hours/day (Japan Electrical Manufacturer's Association (JEMA)) x 300 days of operating ratios.

※We recommend you to keep a fuse as spare parts.

Maker : Fuji terminal industry co., ltd.

Model : FGB0

Specification : AC250V , 5A class B (standard melted type)

●Periodic maintenance parts (The main parts for which exchange is needed with a use situation)

Check the following parts periodically and exchange them based on standard exchange time.

| Parts name | pcs /set | How to exchange | Standard exchange time ※ |
|---------------------------|----------|-----------------|--------------------------|
| Compressor | 1 | B | 20,000 hours (6 years) |
| Fan motor | *b | A | 20,000 hours (6 years) |
| Electromagnetic switch | *c | A | 20,000 hours (6 years) |
| Electromagnetic contactor | *d | A | 20,000 hours (6 years) |
| Solenoid valve | *a | A | 20,000 hours (6 years) |
| Drain discharger (Note 1) | *e | A | 20,000 hours (6 years) |
| Power lamp | *a | A | 20,000 hours (6 years) |
| Start-stop switch | *a | A | 15,000 hours (4 years) |

※Keep in mind that it is not a guarantee value since the operation time (years) indicated above changes with operating conditions (ambient temperature, installation environment, etc.). Years are a standard at the time of considering as 12 hours/day (Japan Electrical Manufacturers' Association (JEMA)) x 300 days of operating ratios. Moreover, since time for the rate of failure in the case where you use it above this time to increase is shown, although it is not necessary to necessarily exchange, this exchange time is exchanged when the case where there are abnormalities at the time of check, and preventive maintenance are performed

・How to exchange

A : Those who have the knowledge and experience of piping, electricity, etc. Need to perform exchange of parts.

(When there are not these knowledge and experiences, ask our company or a special contractor.)

B : Before part exchange, refrigerant recovery is required. Moreover, since technical knowledge is needed for exchange work, ask our company or a special contractor.

*a: 1 pc/set (GX3108, GX5103, 5104, 5106, 5108)

*b: 1 pc/set (GX3108, 3111, 3115, 3122, 3137, GX5106, 5108, 5111, 5115, 5122, 5137)

2 pcs/set (GX5103, 5104)

*c: 1 pc/set (GX3137, GX5115, 5122, 5137)

*d: 1 pc/set (GX3111, 3115, GX5111)

*e: 1 pc/set (GX3111, 3115, 3122, 3137, GX5111, 5115, 5122, 5137)


Note1) Drain discharger and solenoid valve must exchange by the set.

However, solenoid valve coil only is exchangeable


6.3 Storage (When not using for a long time)

If you do not use the dryer for a long time, do the following.

- ① Turn off the power supply(breaker).
- ② Discharge drain.



GX3108
GX5103, 5104, 5106, 5108



GX3111, 3115, 3122, 3137
GX5111, 5115, 5122, 5137

Open the pet cock to discharge drain; then, close the pet cock.

- ③ Put sheet, etc. over the dryer. Keep the dryer in a place where environment is the same as the operating environment.
- ④ When you run the dryer again, inspect each part of the dryer and run it as instructed in this manual.

7. After sales service

- 1) Contact your distributor or CKD to request the repair service.
- 2) Provide the following information when requesting the repair service.
 - * model number of the dryer
 - * serial number
 - * date of installation
 - * name of the store where you purchased the dryer
 - * conditions of your dryer
- 3) We will repair your dryer even after the warranty period expires (charged). We will supply parts for 7 years after production of your dryer is terminated.

8. Trouble shooting

GX3108, GX5103, 5104, 5106, 5108

| Condition | | Causes | Measures |
|---|---|--|---|
| Main power line "short circuit breaker" falls. | | Electric parts have leaked. | Insulation resistance measurement of electric parts (10MΩ or more) |
| | | | Check whether there is any adhesion of waterdrop in an electric wire drawing-in terminal part, if it is, Remove or exchange. |
| | | | Check whether covering of electric wire is torn and touched sheet metal etc., if it is touched, Fix it. (rebanding, electric wire and terminal exchange). |
| "POWER" lamp does not turn on. | | Power supply did not turn on. | Turn on the power supply. |
| | | Power supply voltage is abnormal. | Adjust the voltage. |
| | | Connection of harness is bad. | Repair the harness. |
| | | "POWER" lamp is off. | Replace "POWER" lamp. |
| The dryer does not start, when "START" switch turns on. | "RUN" lamp does not turn on. | "START" switch was failed. | Replace the "START" switch |
| | | Safety device is on. | Reset the safety device. Turn off the former power supply, reset safety device after removing causes. (Refer 5.4 When safety device turns on and the dryer stops running) |
| | | | |
| | | Safety device is bad. | Replace the safety device. |
| | | Power supply voltage is abnormal. | Adjust the voltage. |
| | | Connection of harness is bad. | Repair the harness |
| | "RUN" lamp turns on. | Compressor is bad starting. | Start it after stopping 3 minutes or more. |
| Water comes out at the time of using. | Direction of "dew point gauge" does not point out the green, and water comes from a secondary side. | Solenoid valve for drain discharge is bad. | Solenoid valve is decomposed and cleaned. Replace the solenoid valve. |
| | | Excess water drips come in from the air inlet. | Install filter in front of the dryer to remove water drips. |
| | | The pipe coming out of the dryer is lower than the dew point. | Cover the pipe coming out of the dryer with heat insulation material. |
| | | The bypass circuit before and behind the drier is open. | Close the bypass circuit. |
| | | Flow treated by the dryer is too much | Adjust the flow (1.3 × rated flow rate or less) |
| | | Drain piping is too long or too small | Replace bore size ϕ 7mm or more and length 2m or less, and the discharge end released to air. |
| | Although direction of "dew point gauge" points out the green, water comes from a secondary side. | Load over • Ambient temperature is high. • Inlet temperature is high. • Inlet pressure is low. • Treated flow rate is large. | Lower the load to the level. • Lower the ambient temperature. • Lower the inlet temperature. • Raise the inlet pressure. • Lower the treated flow rate. |
| | | Dust filter is clogged. | Clean the dust filter. When dirt is severe, it exchanges for a new one. |
| | | Fan motor is bad. | Replace the fan motor. |
| | | Ventilation is bad. (Supply/exhaust part of condenser is closed.) | Improve the ventilation. (Move something on the supply/exhaust part of the condenser.) |
| | | Refrigerant gas leak | Refrigerant gas leak part is fixed and coolant filling is carried out. |
| | | | |

| Condition | | Causes | Measures |
|--|--------------------------|---|--|
| Pressure drop before/after the dryer is too large. | | Screen for Y-type strainer at the dryer inlet is closed. | Clean the screen. |
| | | Stop valve before/after the dryer is closed. | Fully open the valve. |
| | | Treated flow rate is too large. | Make 1.3 times or less of rated flow |
| | | Congelation in the dryer. • Ambient temperature is low. • Inlet temperature is low. • Cooling wind directly blow to the dryer. • Thermo sensor (RT01) is bad. (Short circuit state) | Prevent congelation. • Raise the ambient temperature. • Raise the inlet temperature. • Do not let cooling wind directly blow to the dryer • Replace sensor. |
| The dryer suddenly stops. | All the lamps turn off. | Power supply is turned off. | Turn on the power supply. |
| | | Power supply voltage is abnormal. | Adjust the voltage. |
| | Only "POWER" lamp is on. | Safety device is on. • Ambient temperature is high. • Inlet temperature is high. • Inlet pressure is low. • Treated flow rate is large. • Dust filter is clogged. • Fan motor is bad. • Refrigerant gas leak | Turn off the main power supply, reset safety device after removing causes. (Refer 5.4 When safety device turns on and the dryer stops running) • Lower the ambient temperature. • Lower the inlet temperature. • Raise the inlet pressure. • Lower the treated flow rate. • Clean the dust filter. • Replace the fan motor. • Refrigerant gas leak part is fixed and coolant filling is carried out. |
| | | | |

GX3111, 3115, 3122, 3137, GX5111, 5115, 5122, 5137

| Condition | | Causes | Measures |
|---|---|---|---|
| Main power line "short circuit breaker" falls. | | Electric parts have leaked. | Insulation resistance measurement of electric parts (10MΩ or more) |
| | | | Check whether there is any adhesion of waterdrop in an electric wire drawing-in terminal part, if it is, Remove or exchange. |
| | | | Check whether covering of electric wire is torn and touched sheet metal etc., if it is touched, Fix it. (rebanding, electric wire and terminal exchange). |
| "DEW POINT" lamp does not turn on. | | Power supply did not turn on. | Turn on the power supply. |
| | | Power supply voltage is abnormal. | Adjust the voltage. |
| | | Different power supply phase pattern.(three phase type) | Adjust the phase. (Replace two lines.) |
| | | Connection of harness and terminal in controller is bad.(Or the connector is not connect) | Check and repair the harness and terminal in controller. (Or connect the connector) |
| | | Lamp is bad. | Exchange controller. |
| | | Fuse (in controller) is bad. | Exchange controller. |
| | | Fuse (in harness) is bad. | Exchange fuse. |
| "ALARM" lamp is on when the power supply is turned on. | | Safety device is on. | Turn off the former power supply, reset safety device after removing causes. (Refer 5.4 When safety device turns on and the dryer stops running) |
| | | Safety device is bad. | Exchange safety device. |
| | | Thermo sensor (RT02) is bad. (Short circuit state) | Exchange sensor. |
| The dryer does not start, when "START" switch turns on. | "RUN" lamp does not turn on. | "START" switch is bad. | Exchange controller. |
| | | Lamp is bad. | Exchange controller. |
| | | Fuse (in controller) is bad. | Exchange controller. |
| | | Fuse (in harness) is bad. | Exchange fuse. |
| | "RUN" lamp turns on. | Electromagnetic contactor and electromagnetic switch (KM01) is bad. | Replace the electromagnetic contactor and the electromagnetic switch. |
| | "ALARM" lamp turns on. | Compressor is bad starting. | Stopping 3 minutes or more, and start it after reset safety device. (Refer 5.4 When safety device turns on and the dryer stops running) |
| Yellow lamp (DEW POINT) turns on. | Yellow lamp (high temp. side) turns on. | Refer to 「Water comes out at the time of use.」. | |
| | | Thermo sensor (RT01) is bad. (Short circuit state) | Exchange sensor. |
| | Yellow lamp (low temp. side) turns on. | Ambient temperature is low. | Adjust the temperature (2 ° C or higher). |
| | | Inlet air temperature is low. | Adjust the temperature (5 ° C or higher). |
| | | Cooling wind directly blows to the dryer. | Do not let cooling wind directly blow to the suction side of the condenser. |
| | | Thermo sensor(RT01) is bad. (Disconnection state) | Exchange sensor. |

| Condition | | Causes | Measures | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|---|---|--|---|----|----|----|----|----|----|--|---|--------|--|--|--|--|--|----|--------|--|--|--|--|--|----|--------|----|----|----|----|----|----|--------|--|--|--|--|--|----|--------|--|--|--|--|--|----|--------|--|--|--|--|--|----|--------|----|----|----|----|----|----|--------|--|--|--|--|--|----|--|----|----|----|----|----|----|
| Water comes out at the time of use. | Direction of "dew point gauge" does not point out the green, and water comes from a secondary side. | Solenoid valve for drain discharge is bad. | Solenoid valve is decomposed and cleaned. Exchange drain purger ass'y or solenoid valve. (If drain discharge switch ("TEST" switch) on operation panel is pushed, operation of valve can be checked.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Excess water drips come in from the air inlet. | Install filter in front of the dryer to remove water drips. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | The pipe coming out of the dryer is lower than the dew point. | Cover the pipe coming out of the dryer with heat insulation material. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | The bypass circuit before and behind the drier is open. | Close the bypass circuit. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Flow treated by the dryer is too much. | Adjust the flow (1.3× rated flow rate or less) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Drain piping is too long or too small. | Replace bore size ϕ 7mm or more and length 2m or less, and the discharge end released to air. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | The setting mistake of the controller (S.I) | Change the setting of the controller Note1) | Note1) setting value of controller | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Yellow lamp (high temp. side of DEW POINT) turns on, and water comes from a secondary side. | Load over • Ambient temperature is high. • Inlet temperature is high. • Inlet pressure is low. • Treated flow rate is large. | Lower the load to the level. • Lower the ambient temperature. • Lower the inlet temperature. • Raise the inlet pressure. • Lower the treated flow rate. | <table><tr><th>機種</th><th colspan="5">I</th><th>S</th></tr><tr><td>GX3111</td><td></td><td></td><td></td><td></td><td></td><td>S1</td></tr><tr><td>GX3115</td><td></td><td></td><td></td><td></td><td></td><td>S2</td></tr><tr><td>GX5111</td><td>13</td><td>12</td><td>11</td><td>S4</td><td>S3</td><td>S1</td></tr><tr><td>GX3122</td><td></td><td></td><td></td><td></td><td></td><td>S1</td></tr><tr><td>GX3137</td><td></td><td></td><td></td><td></td><td></td><td>S2</td></tr><tr><td>GX5115</td><td></td><td></td><td></td><td></td><td></td><td>S3</td></tr><tr><td>GX5122</td><td>13</td><td>12</td><td>11</td><td>S4</td><td>S3</td><td>S1</td></tr><tr><td>GX5137</td><td></td><td></td><td></td><td></td><td></td><td>S1</td></tr><tr><td></td><td>13</td><td>12</td><td>11</td><td>S4</td><td>S3</td><td>S1</td></tr></table> | | 機種 | I | | | | | S | GX3111 | | | | | | S1 | GX3115 | | | | | | S2 | GX5111 | 13 | 12 | 11 | S4 | S3 | S1 | GX3122 | | | | | | S1 | GX3137 | | | | | | S2 | GX5115 | | | | | | S3 | GX5122 | 13 | 12 | 11 | S4 | S3 | S1 | GX5137 | | | | | | S1 | | 13 | 12 | 11 | S4 | S3 | S1 |
| | | 機種 | I | | | | | S | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | GX3111 | | | | | | | | S1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| GX3115 | | | | | | | | | S2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| GX5111 | | 13 | 12 | | | 11 | S4 | S3 | S1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| GX3122 | | | | | | S1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| GX3137 | | | | | | S2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| GX5115 | | | | | | S3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| GX5122 | 13 | 12 | 11 | S4 | S3 | S1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| GX5137 | | | | | | S1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 13 | 12 | 11 | S4 | S3 | S1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Dust filter is clogged. | Clean the dust filter. When dirt is severe, it exchanges for a new one. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Fan motor is bad. | Replace the fan motor. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Ventilation is bad. (Supply/exhaust part of condenser is closed.) | Improve the ventilation. (Move something on the supply/exhaust part of the condenser.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Refrigerant gas leak | Refrigerant gas leak part is fixed and coolant filling is carried out. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pressure drop before/after the dryer is too large. | Screen for Y-type strainer at the dryer inlet is closed. | Clean the screen. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Stop valve before/after the dryer is closed. | Fully open the valve. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Treated flow rate is too large. | Make 1.3 times or less of rated flow | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Congelation in the dryer. • Ambient temperature is low. • Inlet temperature is low. • Cooling wind directly blow to the dryer. | Prevent congelation. • Raise the ambient temperature. • Raise the inlet temperature. • Do not let cooling wind directly blow to the dryer | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| The dryer suddenly stops. | "RUN" lamp turns off when "ALARM" lamp does not turn on. | Power failure momentarily | Wait three minutes, and push start button. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Low voltage momentarily | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | "ALARM" lamp turns on, and the dryer stops. | Safety device is on. • Ambient temperature is high. • Inlet temperature is high. • Inlet pressure is low. • Treated flow rate is large. • Dust filter is clogged. • Fan motor is bad. • Refrigerant gas leak. • Thermo sensor (RT02) is bad. (Short circuit state or disconnection state) | Turn off the main power supply, reset safety device after removing causes. (Refer 5.4 When safety device turns on and the dryer stops running) • Lower the ambient temperature. • Lower the inlet temperature. • Raise the inlet pressure. • Lower the treated flow rate. • Clean the dust filter. • Replace the fan motor. • Refrigerant gas leak part is fixed and coolant filling is carried out. • Exchange sensor. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

9. Specifications


| Model number | | | GX3108 | GX3111 | GX3115 | GX3122 | GX3137 |
|--------------------------------------|---------------------------------|------------------------|--------------------------------------|-----------|-----------|-----------|-------------------------------------|
| User range | Media | | Compressed air | | | | |
| | Inlet air temperature | °C | 5~50 | | | | |
| | Inlet air pressure | MPa | 0.2~1.6 | | | | |
| | Ambient temperature | °C | 2~43 | | | | |
| Rated | Treated flow rate (50/60Hz) | m ³ /minANR | 1.2/1.3 | 1.65/1.82 | 2.8/3.1 | 3.9/4.3 | 6.6/7.3 |
| | Inlet air temperature | °C | 35 | | | | |
| | Inlet air pressure | MPa | 0.7 | | | | |
| | Ambient temperature | °C | 32 | | | | |
| Rated functionality | Outlet air pressure dew point | °C | 10 | | | | |
| | Pressure drop(50Hz) | MPa | 0.023 | 0.005 | 0.014 | 0.003 | 0.007 |
| Electrical specifications 1 (AC100V) | Power supply | V | Single phase AC100V/100~110V 50/60Hz | / | | | |
| | Power consumption (50/60Hz) | kW | 0.41/0.50 | | | | |
| | Operating current (50/60Hz) | A | 4.5/4.9 | | | | |
| | Starting current (50/60Hz) | A | 17.6/16.3 | | | | |
| | Recommendation breaker capacity | A | 10 | | | | |
| Electrical specifications 2 (AC200V) | Power supply | V | Single phase AC200V/200~220V 50/60Hz | | | | Three phase AC200V/200~220V 50/60Hz |
| | Power consumption (50/60Hz) | kW | 0.41/0.50 | 1.16/1.29 | 1.17/1.32 | 1.19/1.36 | 1.53/1.89 |
| | Operating current (50/60Hz) | A | 2.4/2.5 | 6.5/6.7 | 6.6/6.8 | 6.7/7.0 | 5.4/6.0 |
| | Starting current (50/60Hz) | A | 9.6/8.9 | 26.7/24.5 | 26.7/24.5 | 26.7/24.5 | 27.8/24.7 |
| | Recommendation breaker capacity | A | 5 | 15 | 15 | 15 | 15 |
| Refrigerant | | | R-407C | | | | |
| Exhaust heat(50/60Hz) | | kW | 0.71/0.79 | 1.7/1.9 | 2.1/2.4 | 2.2/2.4 | 3.3/3.8 |
| Mass | | kg | 40 | 65 | 65 | 83 | 102 |

| Model number | | | GX5103 | GX5104 | GX5106 | GX5108 | GX5111 | GX5115 | GX5122 | GX5137 |
|---|------------------------------------|------------------------|--------------------------------------|-----------|-----------|-----------|--|-----------|-----------|-----------|
| User range Note 1) | Media | | Compressed air | | | | | | | |
| | Inlet air temperature | °C | 5~80 | | | | | | | |
| | Inlet air pressure | MPa | 0.2~1.6 | | | | | | | |
| | Ambient temperature | °C | 2~43 | | | | | | | |
| Rated | Treated flow rate (50/60Hz) | m ³ /minANR | 0.31/0.35 | 0.5/0.55 | 0.74/0.81 | 1.2/1.3 | 1.65/1.82 | 2.8/3.1 | 3.9/4.3 | 6.6/7.3 |
| | Inlet air temperature | °C | 55 | | | | | | | |
| | Inlet air pressure | MPa | 0.7 | | | | | | | |
| | Ambient temperature | °C | 32 | | | | | | | |
| Rated functionality | Outlet air pressure dew point | °C | 10 | | | | | | | |
| | Pressure drop(50Hz) | MPa | 0.009 | 0.023 | 0.009 | 0.023 | 0.005 | 0.015 | 0.0026 | 0.008 |
| Electrical specifications 1 (AC100V) | Power supply | V | Single phase AC100V/100~110V | | | | | | | |
| | Power consumption (50/60Hz) | kW | 0.25/0.26 | 0.25/0.26 | 0.42/0.49 | 0.43/0.50 | | | | |
| | Operating current (50/60Hz) | A | 3.2/2.7 | 3.2/2.8 | 4.7/5.0 | 4.7/5.0 | | | | |
| | Starting current (50/60Hz) | A | 8.6/8.1 | 8.6/8.1 | 17.6/16.3 | 17.6/16.3 | | | | |
| | Recommendation breaker capacity | A | 5 | 5 | 10 | 10 | | | | |
| | | | | | | | | | | |
| Electrical specifications 2 (AC200V) | Power supply | V | Single phase AC200V/200~220V 50/60Hz | | | | Three phase AC200V/200~220V 50/60Hz | | | |
| | Power consumption (50/60Hz) | kW | 0.25/0.26 | 0.25/0.26 | 0.42/0.49 | 0.43/0.50 | 1.20/1.35 | 1.69/2.06 | 1.61/1.98 | 2.51/3.11 |
| | Operating current (50/60Hz) | A | 1.4/1.3 | 1.4/1.4 | 2.4/2.4 | 2.4/2.5 | 6.7/7.0 | 5.9/6.5 | 5.6/6.2 | 9.0/10.2 |
| | Starting current (50/60Hz) | A | 4.1/3.8 | 4.1/3.8 | 9.6/8.9 | 9.6/8.9 | 26.7/24.5 | 27.8/24.7 | 27.8/24.7 | 68.0/60.0 |
| | Recommendation breaker capacity | A | 5 | 5 | 5 | 5 | 15 | 15 | 15 | 15 |
| Refrigerant | | | R-407C | | | | | | | |
| Exhaust heat(50/60Hz) | | kW | 0.44/0.49 | 0.59/0.64 | 0.94/1.04 | 1.3/1.4 | 2.6/2.9 | 4.0/4.7 | 4.4/5.1 | 7.2/8.3 |
| Mass | | kg | 28 | 28 | 40 | 40 | 65 | 76 | 102 | 128 |

Note1) When both inlet air temperature and ambient temperature are the maximum temperature, using rated air flow is not guaranteed. If continuation operation is carried out, the life of this machine will become short. Confirm by specifications separately about the details of the use range.


10. Dimensions

10.1 GX3108, GX5103, GX5104, GX5106, GX5108




| | A | B | C | D | E | F | G | H | I | J | K | L | M | N | O |
|--------|-----|-----|-----|-----|-----|----|-----|-----|-----|-----|-----|-----|----|------|-------|
| GX3108 | 635 | 370 | 510 | 394 | 155 | 40 | 420 | 105 | 140 | 410 | 400 | 410 | 50 | φ 10 | Rc3/4 |
| GX5103 | 610 | 300 | 435 | 369 | 115 | 40 | 395 | 75 | 120 | 340 | 325 | 385 | 50 | φ 10 | Rc3/8 |
| GX5104 | 610 | 300 | 435 | 369 | 115 | 40 | 395 | 75 | 120 | 340 | 325 | 385 | 50 | φ 10 | Rc3/8 |
| GX5106 | 635 | 370 | 510 | 394 | 155 | 40 | 420 | 105 | 140 | 410 | 400 | 410 | 50 | φ 10 | Rc3/4 |
| GX5108 | 635 | 370 | 510 | 394 | 155 | 40 | 420 | 105 | 140 | 410 | 400 | 410 | 50 | φ 10 | Rc3/4 |

10.2 GX3111, GX3115, GX5111, GX5115



| | A | B | C | D | E | F | G | H | I | J | K | L | M | N | O | P | Q |
|--------|-----|-----|-----|----|-----|-----|----|-----|-----|-----|-----|-----|-----|-----|----|------|-----|
| GX3111 | 770 | 400 | 755 | 35 | 110 | 128 | 80 | 571 | 147 | 128 | 147 | 440 | 645 | 450 | 50 | φ 10 | Rc1 |
| GX3115 | 770 | 400 | 755 | 35 | 110 | 128 | 80 | 571 | 147 | 128 | 147 | 440 | 645 | 450 | 50 | φ 10 | Rc1 |
| GX5111 | 770 | 400 | 755 | 35 | 110 | 128 | 80 | 571 | 147 | 128 | 147 | 440 | 645 | 450 | 50 | φ 10 | Rc1 |
| GX5115 | 820 | 400 | 830 | 35 | 110 | 128 | 80 | 622 | 147 | 128 | 147 | 440 | 720 | 500 | 50 | φ 10 | Rc1 |


10.3 GX3122, GX3137, GX5122, GX5137




| | A | B | C | D | E | F | G | H | I | J | K | L | M | N | O | P | Q |
|--------|------|-----|-----|----|-----|-----|----|-----|----|-----|----|-----|-----|-----|----|------|---------|
| GX3122 | 835 | 400 | 850 | 35 | 140 | 182 | 80 | 610 | 66 | 132 | 66 | 440 | 680 | 530 | 50 | φ 13 | R 1 1/2 |
| GX3137 | 935 | 450 | 850 | 35 | 140 | 200 | 80 | 713 | 66 | 160 | 66 | 490 | 680 | 630 | 50 | φ 13 | R 1 1/2 |
| GX5122 | 935 | 450 | 850 | 35 | 140 | 200 | 80 | 713 | 66 | 160 | 66 | 490 | 680 | 630 | 50 | φ 13 | R 1 1/2 |
| GX5137 | 1010 | 500 | 930 | 35 | 140 | 240 | 80 | 789 | 66 | 180 | 66 | 540 | 760 | 705 | 50 | φ 13 | R 1 1/2 |

11. Electrical circuit


11.1 GX3108-AC100V GX5103, 5104, 5106, 5108-AC100 V




11.2 GX3108-AC200V GX5103, 5104, 5106, 5108-AC200 V



11.3 GX3111, 3115, 3122-AC200V GX5111-AC200V



11.4 GX3137-AC200V GX5115, 5122, 5137-AC200V



12. CKD WARRANTY

Subject to the conditions below, CKD Corporation ("CKD") warrants the first end user (the "Buyer") that CKD's products are free from defects in material and workmanship.

CKD will, at CKD's option, either repair or replace a defective product, including lowest transportation costs but not including installation or any other similar charges, provided that (1) the buyer notifies CKD in writing of the claimed defect within one year from the date Buyer received the product, (2) provides a complete explanation of the defect, the application of the product, and such other information concerning use of the product as CKD may request, and (3) returns the product to CKD in accordance with CKD's specific written instructions and authorization obtained from CKD prior to return of the product, and CKD's inspection confirms that the product was defective.

This warranty applies only if the product was used and applied correctly under normal operating conditions and good engineering practice; was installed, operated and maintained in accordance with all instructions issued or published by CKD; was used within stated pressure, media and operating limitations published by CKD and in effect on the date of shipment; and was not subject to abuse, misuse or unauthorized modification.

THIS WARRANTY IS THE ONLY AUTHORIZED CKD WARRANTY AND IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, notwithstanding any disclosure to CKD of the use to which the product is to be put. The Buyer's SOLE AND EXCLUSIVE REMEDY on any claim of any kind for any loss or damage arising out of the manufacture, sale, delivery or use of CKD's products shall be for the repair or replacement of any defective products as provided herein.

IN NO EVENT SHALL CKD BE LIABLE FOR BUSINESS INTERRUPTIONS, LOSS OF PROFITS, PERSONAL INJURY, COSTS OF DELAY OR FOR ANY OTHER SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL LOSSES, COSTS OR DAMAGES. There are no warranties, expressed or implied, made by CKD other than the warranty against defects in material and workmanship set forth above, and CKD neither assumes nor authorizes any other person or firm to assume for it any other obligations or liability.

CKD shall not be liable for any trouble, malfunction and damages of CKD products caused, directly or indirectly, by disaster or any other causes not attributable to CKD's responsibility. CKD also shall not be responsible for any trouble, malfunction and damages of CKD Products caused by the lack or malfunction of safety circuit or structure or function that should be commonly equipped in the Buyer's equipment in which the CKD products were used.

CKD MAINTAINS A POLICY OF ONGOING PRODUCT DEVELOPMENT AND IMPROVEMENT. WE THEREFORE RESERVE THE RIGHT TO CHANGE DIMENSIONS, SPECIFICATIONS AND DESIGN WITHOUT NOTICE.

CKD corporation

〒485-8551 250, OUJI 2-CHOME, KOMAKI, AICHI 485-8551 JAPAN

PHONE 0568-77-1111

Purchased air drier

| | |
|-------------------------|--|
| Model name | |
| Manufacture number | |
| Purchase date | |
| Beginning of using date | |

Sales shop name

| | |
|--------|--|
| | |
| TEL | |
| Charge | |

Discontinue

CKD株式会社

北海道

●札幌営業所

〒060-0032 札幌市中央区北2条東 14-26(苗穂駅前ビル1階)
TEL(011)232-1760 FAX(011)232-9050

東北

●北上営業所

〒024-0034 岩手県北上市諏訪町 2-4-26
TEL(0197)63-4147 FAX(0197)63-4186

●仙台営業所

〒984-0015 仙台市若林区卸町 2-2-1(パックス 2・1 階)
TEL(022)239-1851 FAX(022)239-1856

●山形営業所

〒990-0834 山形県山形市清住町 2-6-24
TEL(023)644-6391 FAX(023)644-7273

●郡山営業所

〒963-8034 福島県郡山市島 1-16-9
TEL(0249)23-6348 FAX(0249)24-0862

北関東

●大宮営業所

〒330-0812 さいたま市北区宮原町 3-429-1(第一清水ビル 2 階)
TEL(048)652-3811 FAX(048)652-3816

●茨城営業所

〒300-0847 茨城県土浦市卸町 1-1-1(関鉄つくばビル 4 階 C)
TEL(029)841-7490 FAX(029)841-7495

●宇都宮営業所

〒321-0953 栃木県宇都宮市東宿郷 3-1-7(NBF 宇都宮ビル 3 階)
TEL(028)638-5770 FAX(028)638-5790

●太田営業所

〒373-0813 群馬県太田市内ヶ島町 946-2(大機総合ビル 1 階)
TEL(0276)45-8935 FAX(0276)46-5628

南関東

●東京営業所

〒105-0013 東京都港区浜松 1-31-1(文化放送メディアプラス4階)
TEL(03)5402-3628 FAX(03)5402-0122

●立川営業所

〒190-0022 東京都立川市錦町 3-2-30(朝日生命立川錦町ビル 3 階)
TEL(042)527-3773 FAX(042)527-3782

●千葉営業所

〒260-0021 千葉市中央区新宿 2-5-19(千葉南ビル 3 階)
TEL(043)248-2815 FAX(043)248-2818

●横浜営業所

〒222-0033 横浜市港北区新横浜 2-17-19(日総第15ビル 4 階)
TEL(045)475-3471 FAX(045)475-3470

●厚木営業所

〒243-0035 神奈川県厚木市愛甲 1212-3
TEL(046)226-5201 FAX(046)226-5208

●甲府営業所

〒409-3867 山梨県中巨摩郡昭和町清水新居 1509
TEL(055)224-5256 FAX(055)224-3540

●東京支店

〒105-0013 東京都港区浜松 1-31-1(文化放送メディアプラス4階)
TEL(03)5402-3620 FAX(03)5402-0120

北陸・信越

●長岡営業所

〒940-0088 新潟県長岡市柏町 1-4-33(高野不動産ビル 2 階)
TEL(0258)33-5446 FAX(0258)33-5381

●上田営業所

〒386-0034 長野県上田市大字中之条 323-6(NFビル 103 号)
TEL(0268)24-2392 FAX(0268)24-2394

●松本営業所

〒399-0033 長野県松本市大字笹賀 5945
TEL(0263)25-0711 FAX(0263)25-1334

●富山営業所

〒939-8064 富山県富山市赤田中町 494-1
TEL(076)421-7828 FAX(076)421-8402

●金沢営業所

〒920-0025 石川県金沢市駅西本町 3-16-8
TEL(076)262-8491 FAX(076)262-8493

東海

●名古屋営業所

〒485-8551 愛知県小牧市応時 2-250
TEL(0568)74-1371 FAX(0568)77-3291

●豊田営業所

〒473-0912 愛知県豊田市広田町広田 103
TEL(0565)54-4771 FAX(0565)54-4755

●静岡営業所

〒422-8035 静岡県静岡市駿河区宮竹 1-3-5
TEL(054)237-4424 FAX(054)237-1945

●浜松営業所

〒453-0016 静岡県浜松市和田町 438
TEL(053)463-3021 FAX(053)463-4910

●四日市営業所

〒510-0064 三重県四日市市新正 5-3-20
TEL(0593)51-3151 FAX(0593)51-6788

●名古屋支店

〒485-8551 愛知県小牧市応時 2-250
TEL(0568)74-1356 FAX(0568)77-3317

関西

●大阪営業所

〒542-0073 大阪市中央区日本橋 1-17-17(銀泉 日本一ビル)
TEL(06)6635-2773 FAX(06)6643-5950

●大阪東営業所

〒577-0083 大阪府守口市京阪本通 1-2-3
(横保ジャパン守口ビル 6 階)
TEL(06)4250-6333 FAX(06)6991-7477

●堺営業所

〒591-8021 大阪府堺市新金岡町 5-5-8(泉マンション 1 階)
TEL(072)253-0071 FAX(072)253-0054

●滋賀営業所

〒524-0033 滋賀県守山市浮気町宇中ノ町 300-21(第2小島ビル 4 階)
TEL(077)514-2650 FAX(077)583-4198

●京都営業所

〒612-8414 京都市伏見区竹田段川原町 35-3
TEL(075)645-1130 FAX(075)645-4747

●奈良営業所

〒639-1123 奈良県大和郡山田町 460-15(オックス・ロジナ 1 階)
TEL(0743)57-6831 FAX(0743)57-6821

●神戸営業所

〒673-0016 兵庫県明石市松の内 2-6-8(西明石スポーツビル 3 階)
TEL(078)923-2121 FAX(078)923-0212

●大阪支店

〒542-0073 大阪市中央区日本橋 1-17-17(銀泉 日本一ビル)
TEL(06)6635-2765 FAX(06)6643-5015

中国

●広島営業所

〒730-0022 広島市中区銀山町 3-1(ひろしまハイビル 21 12 階)
TEL(082)545-5125 FAX(082)244-2010

●岡山営業所

〒700-0916 岡山県岡山市西之町 10-104
TEL(086)244-3433 FAX(086)241-8872

●山口営業所

〒747-0034 山口県防府市天神 2-2-2
TEL(0835)38-3556 FAX(0835)22-6371

四国

●高松営業所

〒760-0055 香川県高松市観光通 2-2-15(ダイヤビル)
TEL(087)834-9640 FAX(087)834-9633

●松山営業所

〒790-0053 愛媛県松山市竹原 2-1-33(サンライト竹原 1 階)
TEL(089)931-6135 FAX(089)931-6139

九州

●北九州営業所

〒802-0976 北九州市小倉南区南方 5-13-34
TEL(093)964-0785 FAX(093)964-0910

●福岡営業所

〒812-0013 福岡市博多区博多駅東 1-10-27(アステア博多ビル 5 階)
TEL(092)473-7136 FAX(092)473-5540

●大分営業所

〒871-0015 大分県中津市牛神町 1-11-1
TEL(0979)26-0725 FAX(0979)23-6886

●熊本営業所

〒869-1103 熊本県菊池郡菊陽町久保田 2799-13
TEL(096)340-2580 FAX(096)340-2584

本社

●本社・工場

〒485-8551 愛知県小牧市応時 2-250
TEL(0568)77-1111 FAX(0568)77-1123

●営業本部

〒485-8551 愛知県小牧市応時 2-250
TEL(0568)74-1303 FAX(0568)77-3410

●海外営業部

〒485-8551 愛知県小牧市応時 2-250
TEL(0568)74-1338 FAX(0568)77-3461

CKD Corporation

□ 2-250 Ouji Komaki,Aichi 485-8551,Japan
□ PHONE +81-(0)568-74-1336 FAX +81-(0)568-77-3412

USA

CKD USA CORPORATION

●HEADQUARTERS

4080 Winnetka Avenue, Rolling Meadows, IL 60008 USA
PHONE +1-847-368-0539 FAX +1-847-788-0575

●CINCINNATI OFFICE

●SAN ANTONIO OFFICE
●SAN JOSE OFFICE

Europe

CKD EUROPE BRANCH

De Fruittuinen 28 Hoofddorp 2132NZ The Netherlands
PHONE +31-(0)23-5541490 FAX +31-(0)23-5541491

Malaysia

M-CKD PRECISION SDN.BHD.

●HEADQUARTERS

Lot No.6,Jalan Modal 23/2, Seksyen 23, Kawasan, MIEL,
Fasa 8, 40300 Shah Alam,Selangor Darul Ehsan, Malaysia

PHONE +60-(0)3-5541-1468 FAX +60-(0)3-5541-1533
●JOHOR BAHRU OFFICE

●MELAKA OFFICE

●PENANG OFFICE

Thailand

CKD THAI CORPORATION LTD.

●SALES HEADQUARTERS-BANGKOK OFFICE

Suwan Tower, 14/1 Soi Saladaeng 1, North Sathorn Rd., Bangkok,
Bangkok 10500 Thailand

PHONE +66-(0)2-267-6300 FAX +66-(0)2-267-6305

●LAEMCHABANG OFFICE

●NAVANAKORN OFFICE

●RAYONG OFFICE

●LAMPHUN OFFICE

●KORAT OFFICE

●AMATANAKORN OFFICE

Singapore

CKD SINGAPORE PTE LTD.

705 Sims Drive #03-01/02, Shun Li Industrial Complex,
387384 Singapore

PHONE +65-6744-2623 FAX +65-6744-2486

Taiwan

日商喜開理股 有限公司台湾分公司

CKD CORPORATION TAIWAN BRANCH

中華民國台灣省台北市中山北路二段 96 號嘉新大樓第 14 樓 1405 室
Rm.1405,14F,No.96,Sec.2,Chung Shan N.Rd.,Taipei, Taiwan,R.O.C

PHONE +886-(0)2-2523-0374 FAX +886-(0)2-2523-5081

China

喜開理(上海)機器有限公司

CKD(SHANGHAI)CORPORATION

●営業部/上海事務所

(SALES HEADQUARTERS / SHANGHAI OFFICE)

中国上海市黄浦区九江路 333 号金融廣場 19 樓 1903 室
Room 1903, 333 Jiujiang Road, Shanghai, 200001, China

PHONE +86-(0)21-63602277 FAX +86-(0)21-63511661

●無錫事務所(WUXI OFFICE)

●南京事務所(NANJING OFFICE)

●杭州事務所(HANGZHOU OFFICE)

●武漢事務所(WUHAN OFFICE)

●青島事務所(QINGDAO OFFICE)

●蘇州事務所(SUZHOU OFFICE)

●北京事務所(BEIJING OFFICE)

●天津事務所(TIANJING OFFICE)

●長春事務所(CHANG CHUN OFFICE)

●大連事務所(DALIAN OFFICE)

●瀋陽事務所(SHENYANG OFFICE)

●西安事務所(XIAN OFFICE)

●重慶事務所(CHONGQING OFFICE)

●成都事務所(CHENGDU OFFICE)

●広州事務所(GUANGZHOU OFFICE)

●深圳事務所(SHENZHEN OFFICE)

Korea

CKD KOREA CORPORATION

Room No.1105, 11th FL, The Korea Teachers Pension B/L 27-2,
Yoido-Dong, Youngdeungpo-Gu, Seoul, 150-742, Korea

PHONE +82-(0)2-783-5201~5203 FAX +82-(0)2-783-5204