


Setting method based on switch operation



[Zero point and span point adjustment range] * The adjustment range is not guaranteed. Regard it as a guideline.
* During adjustment, apply an input signal of 1% F.S. or more.

