

Maintenance parts

■ Maintenance parts (motor unit)

* Motor unit replacement is applicable only with ECR. ECG units are excluded.

Model No.		Compatibility	
Without brake	EBS-04ME-MOTORUNIT-N	EBR-04ME	Without brake
	EBS-04MR-MOTORUNIT-N	EBR-04MR/D/L	
	EBS-05ME-MOTORUNIT-N	EBR-05ME	
	EBS-05MR-MOTORUNIT-N	EBR-05MR/D/L	
	EBS-08ME-MOTORUNIT-N	EBR-08ME	
	EBS-08MR-MOTORUNIT-N	EBR-08MR/D/L	
With brake	EBS-04ME-MOTORUNIT-B	EBR-04ME	With brake
	EBS-04MR-MOTORUNIT-B	EBR-04MR/D/L	
	EBS-05ME-MOTORUNIT-B	EBR-05ME	
	EBS-05MR-MOTORUNIT-B	EBR-05MR/D/L	
	EBS-08ME-MOTORUNIT-B	EBR-08ME	
	EBS-08MR-MOTORUNIT-B	EBR-08MR/D/L	

■ Maintenance parts / motor mounting direction: For right/left/downward mounting (timing belt)

Model No.		Compatibility	
	EBS-04MR-BELT	EBR-04*R/D/L	
	EBS-05MR-BELT	EBR-05*R/D/L	
	EBS-08MR-BELT	EBR-08*R/D/L	

■ Maintenance parts (grease nozzle)

Model No.		Compatibility	
	EBS-NOZZLE	All models	

■ Maintenance parts (flange)

Model No.		Compatibility	
	EBR-04-FA	EBR-04*	
	EBR-05-FA	EBR-05*	
	EBR-08-FA	EBR-08*	