


Maintenance parts


■ Maintenance parts / motor mounting direction: For right/left/downward mounting (timing belt)

EBS-P4 (With motor)	Model No.	Compatibility
		
	EBS-04MR-BELT	EBS-04GR/D/L
	EBS-05MR-BELT	EBS-05GR/D/L
EBR-P4 (With motor)	EBS-08MR-BELT	EBS-08GR/D/L

■ Maintenance parts (grease nozzle)

ECG-A (Controller)	Model No.	Compatibility
		
	EBS-NOZZLE	All models

■ Maintenance parts (steel belt)

Safety precautions	Model No.	Compatibility
		
	EBS-04-STEELBELT (4-digit stroke code)	EBS-04 (applicable stroke product)
	EBS-05-STEELBELT (4-digit stroke code)	EBS-05 (applicable stroke product)
	EBS-08-STEELBELT (4-digit stroke code)	EBS-08 (applicable stroke product)

■ Fitting

Model No.	Compatibility
	
ZW-L6-6-P4	EBS-04G
ZW-L8-8-P4	EBS-05G/08G