

Maintenance parts

■ Maintenance parts / motor mounting direction: For right/left/downward mounting (timing belt)

EBS-P4
(With motor)

EBR-P4
(With motor)

Model No.	Compatibility
	
EBS-04MR-BELT	EBR-04GR/D/L
EBS-05MR-BELT	EBR-05GR/D/L
EBS-08MR-BELT	EBR-08GR/D/L


■ Maintenance parts (grease nozzle)

ECG-A
(Controller)

Model No.	Compatibility
	
EBS-NOZZLE	All models

■ Maintenance parts (flange)

Safety
precautions

Model No.	Compatibility
	
EBR-04-FA	EBR-04G
EBR-05-FA	EBR-05G
EBR-08-FA	EBR-08G

■ Fitting

Model No.	Compatibility
	
ZW-L6-6-P4	EBR-04G
ZW-L8-8-P4	EBR-05G/08G