



Pneumatic components

Safety Precautions

Be sure to read this section before use.

Refer to Intro Page 73 for general information of the cylinder, and to Intro Page 80 for general information of the cylinder switch.

Product-specific cautions: Simplified floating fitting FK Series

Mounting, installation and adjustment

WARNING

- When connecting the object being driven and the cylinder rod with a simplified floating fitting, securely fix the components by fastening the screws with a tightening torque that is appropriate for the thread size. When there are further worries of loosening during use, take measures to prevent loosening by securing the component with a pin or by applying an adhesive.
- The screw section (Bracket (1)) can be rotated but is not a rotary fitting. Do not use this for rotary purposes.

SCP*3

CMK2

CMA2

SCM

SCG

SCA2

SCS2

CKV2

CAV2/
COVP/N2

SSD2

SSG

SSD

CAT

MDC2

MVC

SMG

MSD/
MSDG

FC*

STK

SRL3

SRG3

SRM3

SRT3

MRL2

MRG2

SM-25

ShkAbs

FJ

FK

Spd
Contr

Ending