



Fluid control valves

Safety Precautions

Be sure to read this section before use.
Read safety precautions for "Fluid control valves (RJ-013AA)" as well.

Product-specific cautions: Automatic watering controller RSCSeries

When using the product

CAUTION

1. Mounting and installation

- Always read the operation procedures in each of the instruction manuals thoroughly before installation.
- With commercial power supply, be sure to use a circuit breaker such as an electrical leakage breaker to protect the controller.

2. Wiring

- With commercial power supply, be sure to establish a ground (earth) connection in order to prevent electrical shock and lightning-induced failures. (D type grounding construction)
- With commercial power supply, make sure that there are no mistakes with the power supply voltage when connecting the product.
- There are specific polarities with the output of the pulse voltage type. (Red) Reverse operation if and (Black) are connected in reverse. Do not short-circuit (contact) (Red) and (Black).
- After wiring the product, make sure that the screws of the terminal block are not loose.

For cautions for mounting, installation, adjustment, use, and maintenance, refer to the CKD Component Product Site (<https://www.ckd.co.jp/kiki/en/>)→ "Model No."→ [Instruction manual](#) for details.

MEMO