



Fluid control valves

# Safety Precautions

Be sure to read this section before use.  
Read safety precautions for "Fluid control valves (RJ-013AA)" as well.

Product-specific cautions: Rain sensor RS-6 series

## When using the product

CAUTION

1. Mounting and installation

- Always read the installation procedures on P. 17 of each section before installation.

2. Wiring

- After wiring the product, make sure that the screws of the terminal block are not loose.

## Use / maintenance

CAUTION

- Regularly (approximately twice a year) inspect and replace the felt. Refer to P. 17 for an outline of the inspection.

For cautions for mounting, installation, adjustment, use, and maintenance, refer to the CKD Component Product Site (<https://www.ckd.co.jp/kiki/en/>)→ "Model No."→ [Instruction manual](#) for details.

MEMO