

## Grippers For Collaborative Robot

OMRON, TechMan Robot Certified Grippers

**RLSH Series**

**RHLF Series**

**RCKL Series**

## INSTRUCTION MANUAL

SM-A37147-A/2



- Read this Instruction Manual before using the product.
- Read the safety notes carefully.
- Keep this Instruction Manual in a safe and convenient place for future reference.

# PREFACE

Thank you for purchasing CKD's " **RLSH Series / RHLF Series / RCKL Series** " Grippers For **Collaborative Robot**.

This Instruction Manual contains basic matters such as installation and usage instructions in order to ensure optimal performance of the product. Please read this Instruction Manual thoroughly and use the product properly.

Keep this Instruction Manual in a safe place and be careful not to lose it.

Product specifications and appearances presented in this Instruction Manual are subject to change without notice.

- The product is intended for users who have basic knowledge about materials, piping, electricity, and mechanisms of pneumatic components. CKD shall not be responsible for accidents caused by persons who selected or used the product without knowledge or sufficient training.
- Since there are a wide variety of customer applications, it is impossible for CKD to be aware of all of them. Depending on the application or usage, the product may not be able to exercise its full performance or an accident may occur due to fluid, piping, or other conditions. It is the responsibility of the customer to check the product specifications and decide how the product shall be used in accordance with the application and usage.

# SAFETY INFORMATION

When designing and manufacturing any device incorporating the product, the manufacturer has an obligation to ensure that the device is safe. To that end, make sure that the safety of the machine mechanism of the device, the fluid control circuit, and the electric system that controls such mechanism is ensured.

To ensure the safety of device design and control, observe organization standards, relevant laws and regulations, which include the following:

ISO 10218, ISO 12100, JIS B 8433 (Robots and robotic devices)  
 ISO/TS 15066 (Robots and robotic devices)  
 ISO 4414, JIS B 8370, JFPS 2008 (the latest edition)  
 The High Pressure Gas Safety Act, the Industrial Safety and Health Act, other safety rules,  
 organization standards, relevant laws and regulations




In order to use our products safely, it is important to select, use, handle, and maintain the products properly.

Observe the warnings and precautions described in this Instruction Manual to ensure device safety.

Although various safety measures have been adopted in the product, customer's improper handling may lead to an accident. To avoid this:


## **Thoroughly read and understand this Instruction Manual before using the product.**

To explicitly indicate the severity and likelihood of a potential harm or damage, precautions are classified into three categories: "DANGER", "WARNING", and "CAUTION".

|  |   |
|--|---|
|  <b>DANGER</b>  | Indicates an imminent hazard. Improper handling will cause death or serious injury to people.     |
|  <b>WARNING</b> | Indicates a potential hazard. Improper handling may cause death or serious injury to people.      |
|  <b>CAUTION</b> | Indicates a potential hazard. Improper handling may cause injury to people or damage to property. |

Precautions classified as "CAUTION" may still lead to serious results depending on the situation. All precautions are equally important and must be observed.

Other general precautions and tips on using the product are indicated by the following icon.

|   |  |
|---|--|
|  | Indicates general precautions and tips on using the product. |
|---|--|

## Precautions on Product Use

### WARNING

**The product must be handled by a qualified person who has extensive knowledge and experience.**

The product is designed and manufactured as a device or part for general industrial machinery.

**Use the product within the specifications.**

The product must not be used beyond its specifications. Also, the product must not be modified and additional work on the product must not be performed.

The product is intended for use in devices or parts for general industrial machinery. It is not intended for use outdoors or in the conditions or environment listed below.

- In applications for nuclear power, railroad system, aviation, ship, vehicle, medical equipment, and equipment that directly touches beverage or food.
- For special applications that require safety including amusement equipment, emergency shut-off circuit, press machine, brake circuit, and safety measures.
- For applications where life or properties may be adversely affected and special safety measures are required.

(Exception is made if the customer consults with CKD prior to use and understands the specifications of the product. However, even in that case, safety measures must be taken to avoid danger in case of a possible failure.)

**Do not handle the product or remove pipes and devices until confirming safety.**

- Inspect and service the machine and devices after confirming the safety of the entire system. Also, turn off the energy source (air supply or water supply) and power to the relevant facility. Release compressed air from the system and use extreme care to avoid water or electric leakage.
- Since there may be hot or live parts even after operation has stopped, use extreme care when handling the product or removing pipes and devices.
- When starting or restarting a machine or device that incorporates pneumatic components, make sure that a safety measure (such as a pop-out prevention mechanism) is in place and system safety is secured.

## Precautions on Design and Selection

### WARNING

**Install a protective cover as a safety measure if the moving workpiece can pose a risk to humans or if human fingers can get caught in the finger and/or the attachment.**

**Take proper measures to prevent the workpiece from falling so that people are not injured and machines and devices are not damaged.**

If the circuit pressure drops due to a power failure or a problem with the air source, the gripping power may decrease and the workpiece may fall.


## ⚠ CAUTION

**When using the product in a cutting, casting, or welding plant, install a cover to prevent foreign matters such as cutting fluid, chips, powder, and dust from entering.**

**Do not use the equipment in the following environments.**

- Where cutting oil can splash onto the product (abrasives and polishing powder in the oil can abrade the sliding section)
- Where organic solvents, chemicals, acids, alkalis, and kerosene are present
- Where water can splash onto the product

**When gripping a long object or large work-piece, the center of gravity must be gripper to provide stable prehension. It is also necessary to stabilize prehension by increasing the size or using multiple attachments.**




**Select a model that has sufficient power to grip the work-piece weight.**



**Select a model that has sufficient opening/closing width for the work-piece size.**

**If directly inserting the work-piece into the jig with the hand, consider clearance during design to avoid damaging the hand.**

● Press the jig by ejecting



● When using a push cylinder



Note: Since the workpiece slides on the attachment, the lifespan of the gripper may be greatly reduced. The shape of the attachment should be sufficiently considered.

**Adjust the opening and closing speeds of the chuck with the speed controller.**

When used at a high speed, backlash may occur sooner than expected. In addition, the workpiece may vibrate due to shocks from opening or closing and this may lead to erroneous chucking, erroneous insertion of workpiece, and poor repeatability.

**Condensation (water drops) may occur in the piping under certain conditions if an actuator with small bore size or short stroke is operated at high frequency.**

Use a quick exhaust valve to prevent condensation.

## Precautions on Product Disposal

---

### CAUTION

When disposing of the product, comply with laws pertaining to disposal and cleaning of wastes and have an industrial waste disposal company dispose of the product.

# CONTENTS

|   |           |
|---|-----------|
| <b>PREFACE</b> .....  | <b>i</b>  |
| <b>SAFETY INFORMATION</b> .....   | <b>ii</b> |
| Precautions on Product Use .....  | iii       |
| Precautions on Design and Selection .....                                 | iii       |
| Precautions on Product Disposal .....                                     | v         |
| <b>CONTENTS</b> .....   | <b>vi</b> |
| <b>1. PRODUCT OVERVIEW</b> .....  | <b>1</b>  |
| 1.1 Model Number Indication.....  | 1         |
| 1.1.1 RLSH Series.....  | 1         |
| 1.1.2 RHLF Series.....  | 2         |
| 1.1.3 RCKL Series.....  | 3         |
| 1.1.4 Option parts (Please contact us for single item model number.)..... | 4         |
| 1.2 Specifications.....   | 5         |
| 1.2.1 RLSH Series.....  | 5         |
| 1.2.2 RHLF Series.....  | 6         |
| 1.2.3 RCKL Series.....  | 7         |
| 1.3 Electrical Circuit .....  | 8         |
| 1.4 Dimensions .....  | 8         |
| 1.4.1 RLSH Series.....  | 8         |
| 1.4.2 RHLF Series.....  | 9         |
| 1.4.3 RCKL Series.....  | 9         |
| <b>2. INSTALLATION</b> .....  | <b>10</b> |
| 2.1 Environment.....  | 10        |
| 2.2 Unpacking .....   | 10        |
| 2.3 Mounting .....  | 11        |
| 2.3.1 Body.....   | 11        |
| 2.3.2 Sensor .....  | 12        |
| 2.4 Wiring .....  | 13        |
| 2.4.1 Wiring of Valve and Robot.....                                      | 13        |
| 2.5 Piping .....  | 13        |
| 2.5.1 Piping for gripper .....  | 13        |
| <b>3. USAGE</b> .....   | <b>14</b> |
| 3.1 Using the gripper.....  | 14        |
| 3.1.1 Usage .....   | 14        |
| 3.1.2 Starting the robot.....   | 15        |
| 3.1.3 Software installation .....   | 15        |
| 3.1.4 Adjustment of sensor.....   | 15        |
| 3.2 Program functions and operations.....                                 | 16        |
| 3.2.1 Software setup.....   | 16        |
| 3.2.2 Explanation of operation screen.....                                | 18        |
| 3.2.3 Sensor status and indicator display .....                           | 20        |
| 3.2.4 Center of gravity setting of CKD Pneumatic Gripper .....            | 21        |
| <b>4. MAINTENANCE AND INSPECTION</b> .....                                | <b>22</b> |
| 4.1 Periodic Inspection.....  | 23        |
| 4.1.1 Inspection item .....   | 23        |
| 4.1.2 Maintenance of the product.....                                     | 23        |
| 4.1.3 Maintenance of the circuit .....                                    | 23        |
| <b>5. TROUBLESHOOTING</b> .....   | <b>24</b> |
| 5.1 Problems, Causes, and Solutions .....                                 | 24        |



- 5.1.1 Finger (cylinder)..... 24
  - 5.1.2 Sensor ..... 25
- 6. WARRANTY PROVISIONS ..... 26**
  - 6.1 Warranty Conditions ..... 26
  - 6.2 Warranty Period ..... 26



# 1. PRODUCT OVERVIEW

## 1.1 Model Number Indication

### 1.1.1 RLSH Series

RLSH – A20D1N – L1 –  –  – TM

(A) Robot flange      (B) Attachment

| Code                    | Description                         |
|-------------------------|-------------------------------------|
| <b>(A) Robot Flange</b> |                                     |
| Blank                   | Without robot flange                |
| F                       | With robot flange <sup>Note 1</sup> |

| Code                   | Description                                      |
|------------------------|--|
| <b>(B) Attachments</b> |  |
| Blank                  | Without attachments                              |
| Y2                     | Attachment for testing <sup>Note 2</sup>         |
| V                      | Directional control valve/tube <sup>Note 3</sup> |



Note 1: With robot flange mounting bolts.

Note 2: Because it is made of resin, use it for gripping tests (Mass is 25g per piece).

Note 3: Directional control valve includes a  $\phi 4$  push-in fitting (air supply port and A/B port), silencer (R1/R2 port), and mounting plate. The tube has an outer diameter of  $\phi 4$  and a length of  $2.5\text{m} \times 2$  pieces.

Note 4: Standard with cylinder switch(F2H).

## 1.1.2 RHLF Series

R H L F – 1 6 C S –   – T M

(A) Robot flange

(B) Attachment

| Code                    | Description                         |
|-------------------------|-------------------------------------|
| <b>(A) Robot Flange</b> |                                     |
| Blank                   | Without robot flange                |
| F                       | With Robot flange <sup>Note 1</sup> |

| Code                   | Description                                      |
|------------------------|--|
| <b>(B) Attachments</b> |  |
| Blank                  | Without attachments                              |
| Y2                     | Attachment for testing <sup>Note 2</sup>         |
| V                      | Directional control valve/tube <sup>Note 3</sup> |


Note 1: With robot flange mounting bolts.

Note 2: Because it is made of resin, use it for gripping tests (Mass is 30g per piece).

Note 3: Directional control valve includes a  $\phi 4$  push-in fitting (air supply port and A/B port ),  
silencer (R1/R2 port), and mounting plate. The tube has an outer diameter of  $\phi 4$  and a length of 2.5m  $\times$  2 pieces.

Note 4: Standard with cylinder switch(T2H).

### 1.1.3 RCKL Series



| Code                    | Description                         |
|-------------------------|-------------------------------------|
| <b>(A) Robot flange</b> |                                     |
| Blank                   | Without Robot flange                |
| F                       | With Robot flange <sup>Note 1</sup> |

| Code                   | Description                                      |
|------------------------|--|
| <b>(B) Attachments</b> |  |
| Blank                  | Without attachments                              |
| Y3                     | Attachment <sup>Note 2</sup>                     |
| V                      | Directional control valve/tube <sup>Note 3</sup> |

Note 1: With robot flange mounting bolts.

Note 2: Built-to-order product, made of aluminum (Mass is 50g per piece).

Note 3: Directional control valve includes a  $\phi 4$  push-in fitting (air supply port and A/B port), silencer (R1/R2 port), and mounting plate. The tube has an outer diameter of  $\phi 4$  and a length of  $2.5\text{m} \times 2$  pieces.


Note 4: Standard with cylinder switch (T2H).

## 1.1.4 Option parts (Please contact us for single item model number.)

### ■ Attachment <Y2,Y3>

Attachment for testing <Y2> (RLSH,RHLF),<Y3> (RCKL)

Note: The figure on the right is for RLSH. For other models, refer to the dimensional drawings.



### < Accessory >

- Attachments 2pieces (RLSH,RHLF), 3pieces (RCKL)
- Mounting Bolts

### ■ Valve,tube < V >

#### < Accessory >

- Double solenoid valve 1pc
- Mounting plate 1pc
- $\phi 4$  push-in fitting 1pc
- Silencer 2pc
- $\phi 4$  tube 2.5m×2pc



## 1.2 Specifications

### 1.2.1 RLSH Series

#### ■ Product specifications



| Descriptions            |     | RLSH   |
|-------------------------|-----|--|
| Bore size               | mm  | φ20  |
| Actuation               |     | Double acting  |
| Working fluid           |     | Compressed air   |
| Max. working pressure   | MPa | 0.7  |
| Min. working pressure   | MPa | 0.1  |
| Port size               |     | Applicable tube outer diameter φ4 (With speed control valve) |
| Ambient temperature     | °C  | 0°C to 50°C  |
| Operating stroke length | mm  | 18   |
| Repeatability           | mm  | ±0.01  |
| Product weight          | kg  | 1  |



#### ■ Sensor specifications

| Descriptions     |         | Proximity 2-wire                      |
|------------------|---------|---------------------------------------|
|                  |         | F2H                                   |
| Applications     |         | Only for programmable controller      |
| Load voltage     |         | 10 VDC to 30 VDC                      |
| Load current     |         | 5 mA to 20 mA                         |
| Indicator        | Gripper | Yellow LED (Lights up when turned on) |
|                  | Flange  | Blue, Green                           |
| Leakage current  |         | 1 mA or less                          |
| Shock resistance |         | 980 m/s <sup>2</sup>                  |
| Product weight   | g       | 10                                    |

#### ■ Gripping power performance data

Indicates the gripping force operating in the opening and closing directions for the length(L) of the attachment of the gripper when the supply pressure is 0.3, 0.5, and 0.7 MPa (for one finger).

- Opening direction (  ) - - - - (Dashed line indication)
- Closing direction (  ) ——— (Solid line indication)



## 1.2.2 RHLF Series

### ■ Product specifications




| Descriptions            |                    | RHLF   |
|-------------------------|--------------------|--|
| Bore size               | mm                 | $\phi 16 \times 2$   |
| Actuation               |                    | Double acting  |
| Working fluid           |                    | Compressed air   |
| Max. working pressure   | MPa                | 0.7  |
| Min. working pressure   | MPa                | 0.2  |
| Port size               |                    | Applicable tube outer diameter $\phi 4$ (With speed control valve) |
| Ambient temperature     | $^{\circ}\text{C}$ | $5^{\circ}\text{C}$ to $50^{\circ}\text{C}$                        |
| Operating stroke length | mm                 | 32   |
| Repeatability           | mm                 | $\pm 0.03$   |
| Product weight          | kg                 | 1.1  |



### ■ Sensor specifications

| Descriptions        |         | Proximity 2-wire                   |
|---------------------|---------|------------------------------------|
|                     |         | T2H                                |
| Applications        |         | Only for programmable controller   |
| Load supply voltage |         | 10 VDC to 30 VDC                   |
| Load current        |         | 5 mA to 20 mA                      |
| Indicator           | Gripper | Red LED (Lights up when turned on) |
|                     | Flange  | Blue, Green                        |
| Leakage current     |         | 1 mA or less                       |
| Shock resistance    |         | $980 \text{ m/s}^2$                |
| Product weight      | g       | 18                                 |

### ■ Gripping power performance data

Indicates the gripping force operating in the opening and closing directions for the length(L) of the attachment of the gripper when the supply pressure is 0.3, 0.5, and 0.7 MPa (for one finger).

• Opening direction(  ) • Closing direction(  )  
 (Solid line indication)



## 1.2.3 RCKL Series

### ■ Product specifications



| Descriptions            |     | RCKL   |
|-------------------------|-----|--|
| Bore size               | mm  | φ40  |
| Actuation               |     | Double acting  |
| Working fluid           |     | Compressed air   |
| Max. working pressure   | MPa | 0.7  |
| Min. working pressure   | MPa | 0.3  |
| Port size               |     | Applicable tube outer diameter φ4 (With speed control valve) |
| Ambient temperature     | °C  | 5°C to 50°C  |
| Operating stroke length | mm  | 10   |
| Repeatability           | mm  | ±0.01  |
| Product weight          | kg  | 1.1  |



### ■ Sensor specifications

| Descriptions        |         | Proximity 2-wire                   |
|---------------------|---------|------------------------------------|
|                     |         | T2H                                |
| Applications        |         | Only for programmable controller   |
| Load supply voltage |         | 10 VDC to 30 VDC                   |
| Load current        |         | 5 mA to 20 mA                      |
| Indicator           | Gripper | Red LED (Lights up when turned on) |
|                     | Flange  | Blue, Green                        |
| Leakage current     |         | 1 mA or less                       |
| Shock resistance    |         | 980 m/s <sup>2</sup>               |
| Product weight      | g       | 18                                 |

### ■ Gripping power performance data


Indicates the gripping force operating in the opening and closing directions for the length(L) of the attachment of the gripper when the supply pressure is 0.3, 0.5, and 0.7 MPa (for one finger).

- Opening direction (  ) (Dashed line indication)
- Closing direction (  ) (Solid line indication)




## 1.3 Electrical Circuit

### ■ Electrical circuit diagram




## 1.4 Dimensions

### 1.4.1 RLSH Series






## 1.4.2 RHLF Series



## 1.4.3 RCKL Series



## 2. INSTALLATION


### 2.1 Environment

#### CAUTION

**When using the product in a cutting, casting, or welding plant, install a cover to prevent foreign matters such as cutting fluid, chips, powder, and dust from entering.**

**Do not use the equipment in the following environments.**

- Where cutting oil can splash onto the product (abrasives and polishing powder in the oil can abrade the sliding section)
  - Where organic solvents, chemicals, acids, alkalis, and kerosene are present
  - Where water can splash onto the product
- Use the product within the following ambient temperature range.  
RLSH 0°C to 50°C, RH 85% or less (no freezing)  
RHLF,RCKL 5°C to 50°C, RH 85% or less (no freezing)
  - For compressed air, use clean and dry air that has been passed through an air filter.  
Use an air filter in the circuit and be careful with the filtration rate (a filter that removes particles exceeding 5 µm is desirable), flow rate, and mounting position (install the filter near the directional control valve).



### 2.2 Unpacking

- Check that the model number ordered and the model number indicated on the product are the same.
- Check the exterior of the product for any damage.
- When storing the product, take proper measures to prevent foreign matters from entering the cylinder.

## 2.3 Mounting

### **⚠ WARNING**

**Install a protective cover as a safety measure if the moving workpiece can pose a risk to humans or if human fingers can get caught in the finger and/or the attachment.**

**Take proper measures to prevent the workpiece from falling so that people are not injured and machines and devices are not damaged.**

If the circuit pressure drops due to a power failure or a problem with the air source, the gripping power may decrease and the workpiece may fall.

### 2.3.1 Body

#### 1 Mounting the hand

When mounting the hand, make sure that the LED lamp is parallel to the camera.  
Attach the parallel pin to the connector side.

#### 2 Mounting the robot flange

Loosen the clamp ring and remove the robot flange from the gripper.  
After inserting the parallel pin(included) to the robot flange surface, mount the robot flange to the robot using the four hexagon socket head cap screws (included).

Note: Tightening torque=7N·m

#### 3 Mounting the gripper

Mount the gripper to the robot flange and tighten the Clamp ring.

Note: Tighten the clamp ring by hand to make sure it is not loose.

#### 4 Connector connection

Connect the gripper connector to the robot tool Connectot of the robot.

#### 5 Mounting the accessory attachments

Mounting the attachments to the fingers or table with the attached screw or bolt.

Note 1: Accessory attachments for RLSH and RHLF is made of resin.




Use for gripping test.

Note 2: Accessory attachments for RCKL is made of aluminum.

Use for gripping test.

Note 3: Use the following for the tightening torque of the accessory attachments.

| Model     | Tightening torque (N·m) |
|-----------|-------------------------|
| RLSH,RHLF | 1.4                     |
| RCKL      | 2.8                     |



## ■ Rigidity of the attachment


If the attachment is not rigid enough, sagging can result and cause the finger to twist or adversely affect operation.

## ■ Mounting the attachment


The effect on the hand body must be taken into consideration when mounting the attachment to the finger. Support the attachment with a wrench when tightening it so as not to twist the finger.

| Descriptions | Bolt size | Tightening torque(N·m) |
|--------------|-----------|------------------------|
| RLSH Series  | M4 × 0.7  | 1.4                    |
| RHLF Series  | M4 × 0.7  | 1.4                    |
| RCKL Series  | M5 × 0.8  | 2.8                    |

Do not apply load to the body



Be careful not to apply a lateral load to the finger when mounting the attachment.



Backlash or damage may occur when an excessive lateral load or an impact load is applied. Use the product so that the external force applied to the finger does not exceed the allowable load described in the catalog.

## 2.3.2 Sensor

### ■ Changing the position of the sensor

- 1 Loosen the fastening screw (set screw).
- 2 Move the switch body along the groove on the side of the body or the rail plate and then tighten the screw at the predetermined position.

| Model          | Tightening torque(N·m) |
|----------------|------------------------|
| RLSH(F2H)      | 0.03~0.08              |
| RHLF,RCKL(T2H) | 0.1~0.2                |

### ■ Replacing the sensor

The sensor has a special wiring treatment. Please contact us. Replacement procedure manual is attached to replacement sensor.


## 2.4 Wiring

### 2.4.1 Wiring of Valve and Robot

### ■ Wiring method to I/O terminal of controller

In the case of the figure below, the “Open” signal is connect to {Digital Output [0]}, and the “Close” signal is connect to {Digital Output [1]}.


To set the sink output type, connect the DO\_COM terminal to the minus side of the power supply.



## 2.5 Piping

### 2.5.1 Piping for gripper

Refer to the figure below for piping between the valve and gripper and piping to the valve.



## 3. USAGE

### 3.1 Using the gripper


#### ⚠ CAUTION

**Be sure not to apply an excessive load to the fingers and attachment when attaching and detaching or conveying workpieces.**


The linear guide rolling contact surface of the fingers may be scratched or dented, resulting in a malfunction.

#### 3.1.1 Usage

- 1** Supply air to the valve. It is recommended to check the operation from about 0.3MPa.
- 2** Open the cover of the A port of the valve and the lever will appear. When the lever is pressed, air flows to A port
- 3** Turn the speed control valve knob of the gripper "OPEN" port slowly counterclockwise with a flathead screwdriver to confirm that the gripper opens.  
Note: Please do not turn it too quickly as it is dangerous.
- 4** Open the cover of the B port of the valve and lever will appear. When the lever is pressed, air flow to the B port.
- 5** Turn the speed control valve knob of the gripper "CLOSE" port slowly counterclockwise with a flathead screwdriver to confirm that the gripper close.  
Note: Please do not turn it too quickly as it is dangerous.
- 6** After confirming that the lever is not locked, close the cover.



Valve  
Double solenoid valve



"CLOSE" port speed control valve  
Adjust the speed of the "CLOSE" direction.  
Speed increases counterclockwise.

"OPEN" port speed control valve  
Adjust the speed in the "OPEN" direction.  
Speed increases counterclockwise.

### 3.1.2 Starting the robot

Turn on the robot. (For details, see the robot manual.)

### 3.1.3 Software installation

Download the software from each manufacturer's HP, and import the software with TM flow.  
After creating the program, insert the USB memory labeled "TMROBOT" into the USB port of the control box. (For details, see the robot manual.)


Software      CLOSE: GRIPPER\_CKD\_PneumaticGripper\_V1\_CLOSE  
                  OPEN : GRIPPER\_CKD\_PneumaticGripper\_V1\_OPEN

For details , see the “Installation of 「3.2.1 Software installation 」.

### 3.1.4 Adjustment of sensor

Adjust the sensor according to the work piece referring to 「2.3.2 Sensor」.  
It is recommended to unify the display color of the gripper and the display color of the teachpendant.  
For details, see 「3.2.3 Sensor status and indicator display 」.

| Model          | Tightening torque(N·m) |
|----------------|------------------------|
| RLSH(F2H)      | 0.03~0.08              |
| RHLF,RCKL(T2H) | 0.1~0.2                |



## 3.2 Program functions and operations

### 3.2.1 Software setup


For Omron TM robots, download "CKD Pneumatic Gripper" from the following website.

<https://www.omron.co.jp/>


For Techman TM robots, download "CKD Pneumatic Gripper" from the following website.

<https://www.ckd.co.jp/>


- 1 Prepare a commercially available USB memory and change the label of the USB memory to "TMROBOT".  
Create the "TM\_Export" , "Arbitrary folder name" and "ComponentObject" folder in the USB memory, and copy the downloaded "GRIPPER\_CKD\_PneumaticGripper\_V1\_CLOSE" and "GRIPPER\_CKD\_PneumaticGripper\_V1\_OPEN".



- 2 Click the main menu icon , and then select the menu to display the "System Setting" screen.




- 3 Select the "Import/Export" and click "Import". Then select the robot from the list, then select "OK".







- 4 Click the "Component", then select the "GRIPPER\_CKD\_PneumaticGripper\_V1\_OPEN" and "GRIPPER\_CKD\_PneumaticGripper\_V1\_CLOSE" to move to "Selected files". After confirming the file moving, click "Import".



- 5 Click the main menu icon , and then select the menu to display the "Robot Setting" screen.




- 6 Click "Component", then "GRIPPER\_CKD\_PneumaticGripper\_V1\_OPEN" and "GRIPPER\_CKD\_PneumaticGripper\_V1\_CLOSE" are displayed in the Component List. Click the "Enable " for selecting, and then click the "Save".



## 3.2.2 Explanation of operation screen


### Setting screen



| No. | Name                         | Explanation   |
|-----|------------------------------|---|
| 1   | OPEN icon                    | Icon to open the fingers of Pneumatic Gripper.<br>Use it by dragging to the flow area.  |
| 2   | CLOSE icon                   | Icon to close the fingers of Pneumatic Gripper.<br>Use it by dragging to the flow area.   |
| 3   | Pneumatic Gripper CLOSE Node | The node that closes the fingers of Pneumatic Gripper is installed.<br>Digital I/O settings of valve, grip wait error time, and wait time can be set. |
| 4   | OK Node                      | Node when the work is gripped.  |
| 5   | NG Node                      | Node when the work grip error occurs.   |
| 6   | Pneumatic Gripper OPEN Node  | The node that opens the fingers of Pneumatic Gripper is installed.<br>Digital I/O settings of valve, grip wait error time, and wait time can be set.  |
| 7   | OK Node                      | Node when the work is gripped.  |
| 8   | NG Node                      | Node when the work grip error occurs.   |

## ■ Setting screen of Pneumatic Gripper Node

When you select "Pneumatic Gripper Open" or "Pneumatic Gripper Close", a pencil mark is displayed. Click the pencil mark to set the digital I/O settings of valve, grip wait error time, and wait time.







| No. | Name                        | Explanation   |
|-----|-----------------------------|---|
| 1   | Digital OUT Setting (Open)  | Set the I/O of valve when the Pneumatic Gripper is open.<br>The default value is DO 0:H, DO 1:L.  |
| 2   | Opening Wait Time Setting   | Set the time to display the error if it takes time to open the fingers. The speed control valve can be adjusted to set the time.<br>The default value is 1 second.  |
| 3   | Wait Time (Open)            | Set the wait time after the fingers are opened, in order to carry the work stably.<br>The default value is 1 second.  |
| 4   | Digital OUT setting (Close) | Set the I/O of valve when the Pneumatic Gripper is closed.<br>The default value is DO 0:L, DO 1:H.  |
| 5   | Closing Wait Time Setting   | Set the time to display the error if it takes time to close the fingers. The speed control valve can be adjusted to set the time.<br>The default value is 1 second. |
| 6   | Wait Time (Close)           | Set the wait time after the fingers are closed, in order to carry the work stably.<br>The default value is 1 second.  |

### 3.2.3 Sensor status and indicator display

#### ■ Sensor status and indicator display

Make settings so that the gripper opening/closing direction and indicator display are as shown in the table below when the digital I/O is set.

Error message will be outputted when the lamp turns light blue, so move the cylinder switch position to an appropriate place.

| Open sensor | Close sensor | Color of flange | Gripper  | message                                 |
|-------------|--------------|-----------------|--|---|
| ON          | OFF          | Blue            | OPEN<br>                   | None                                    |
| OFF         | ON           | Green           | CLOSE<br>                  | None                                    |
| OFF         | OFF          | Lights out      | Intermediate position<br>   | None                                    |
| ON          | ON           | Light blue      | Intermediate position<br> | Display<br>check the "Position Sensors" |



#### ■ Screen display


The following screen will be displayed when the program runs.

| No. | Screen                    | Explanation   |
|-----|---------------------------|---|
| 1   | Open OK                   | It shows that the Pneumatic Gripper is opened without any problem.  |
| 2   | Open NG                   | Pneumatic Gripper cannot recognize the cylinder switch when opened. This is an abnormal condition. Confirm the sensor position and work size. |
| 3   | Close OK                  | It shows that the Pneumatic Gripper is closed without any problem.  |
| 4   | Close NG                  | Pneumatic Gripper cannot recognize the cylinder switch when closed. This is an abnormal condition. Confirm the sensor position and work size. |
| 5   | Check the Position Sensor | The cylinder switch is lighting in both open and closed. Move the cylinder switch to an appropriate place.                                    |


### 3.2.4 Center of gravity setting of CKD Pneumatic Gripper

Set up TCP when installing Pneumatic Gripper.

- 1 Click the main menu icon , and then select the  menu to display the "Robot Setting" screen.



- 2 Select "TCP Setting" and after clicking , enter the center position of gravity and mass of the Pneumatic Gripper by referring to the table below.



| Model | Center of gravity (mm) |     |      | Weight (kg) <sup>Note 1</sup> |
|-------|------------------------|-----|------|-------------------------------|
|       | X                      | Y   | Z    |                               |
| RLSH  | 1.1                    | 0.0 | 56.7 | 0.8                           |
| RHLF  | 1.8                    | 0.0 | 58.5 | 1.0                           |
| RCKL  | 1.4                    | 0.0 | 63.6 | 1.0                           |

Note 1 : If the attachment is made according to the work piece, enter the total center of gravity and the total weight of the gripper and the attachment.

## 4. MAINTENANCE AND INSPECTION

### WARNING

**Do not touch electrical wiring connections (bare live parts) of actuators equipped with solenoid valves, actuators equipped with switches, and other such actuators.**

**Do not touch live parts with bare hands.**

An electric shock may occur.

### CAUTION

**Plan and perform daily and periodic inspections so that maintenance can be managed properly.**

If maintenance is not properly managed, the product's functions may deteriorate significantly and this may lead to faults (such as short service life, damage, and malfunction) or accidents.

## 4.1 Periodic Inspection

In order to use the product under optimum conditions, perform a periodic inspection every six months or when the operation count reaches 5 hundred thousand times.

### 4.1.1 Inspection item

- Actuation state
- Air leakage
- Looseness of screws and bolts
- Backlash in the finger
- Stroke abnormality


### 4.1.2 Maintenance of the product

Regularly grease the sliding section of the finger with lithium grease. Regular greasing can extend service life further.

| Manufacturer | Model      |
|--------------|------------|
| THK          | AFF grease |

### 4.1.3 Maintenance of the circuit

- Discharge the drainage accumulated in the air filter periodically before it exceeds the specified line.
- Since foreign matters such as carbide (carbon or tar substance) from the compressor oil may contaminate the circuit and cause an operation fault of the solenoid valve or the cylinder, be careful when performing maintenance or inspection of the compressor.



## 5. TROUBLESHOOTING

### 5.1 Problems, Causes, and Solutions

If the product does not operate properly, check the table below for a possible solution.

#### 5.1.1 Finger (cylinder)

| Problem                           | Cause  | Solution   |
|-----------------------------------|--|--|
| Finger does not operate.          | No pressure or insufficient pressure is applied.         | Secure sufficient pressure.  |
|                                   | No signal is input to directional control valve.         | Repair the control circuit.  |
|                                   | Centers were not aligned when mounted.                   | Correct the way the cylinder is mounted.<br>Change the mounting style.   |
|                                   | Piston packing is damaged.                               | Replace the cylinder.  |
| Finger does not operate smoothly. | Speed is lower than minimum working piston speed.        | Mitigate load fluctuation.   |
|                                   | Centers were not aligned when mounted.                   | Correct the way the cylinder is mounted.<br>Change the mounting style.   |
|                                   | Lateral load is applied.                                 | Install a guide.<br>Correct the way the cylinder is mounted.<br>Change the mounting style.                           |
|                                   | Load is too large.                                       | Increase the pressure.<br>Enlarge the bore size.   |
|                                   | Speed control valve has meter-in circuit.                | Change the mounting direction of the speed control valve.  |
| Finger is damaged or deformed.    | Force of shock due to high-speed actuation is excessive. | Decrease the speed.<br>Lighten the load.<br>Install a more effective cushion mechanism (external cushion mechanism). |
|                                   | Lateral load is applied.                                 | Install a guide.<br>Correct the way the cylinder is mounted.<br>Change the mounting style.                           |



## 5.1.2 Sensor

| Problem                                       | Cause                                       | Solution  |
|---|---|---|
| Switch turns on but indicator does not blink. | Indicator is damaged.                       | Replace the switch.   |
|   | External signal is faulty.                  | Check the external circuit.   |
| Switch does not turn on.                      | Cables are disconnected.                    | Replace the switch.   |
|   | External signal is faulty.                  | Check the external circuit.   |
|   | Voltage is wrong.                           | Use specified voltage.  |
|   | Switch is not mounted in right place.       | Mount the switch in right place.  |
|   | Switch is not positioned correctly.         | Position and tighten the switch correctly.  |
|   | Switch is facing opposite direction.        | Mount the switch so that it faces the correct direction.  |
| Switch does not turn off.                     | Piston is not moving.                       | Move the piston.  |
|   | Contact is welded.                          | Replace the switch.   |
|   | Ambient temperature is too high or too low. | Use the switch at an ambient temperature of 0°C to 50°C for RLSH.<br>Use the switch at an ambient temperature of 5°C to 50°C for RHLF,RCKL. |
|   | Magnetic field is nearby.                   | Install a magnetic shield.  |
|   | External signal is faulty.                  | Check the external circuit.   |

If you have any other questions or concerns, contact your nearest CKD sales office or distributor.

## 6. WARRANTY PROVISIONS

### 6.1 Warranty Conditions

#### ■ Warranty coverage

If the product specified herein fails for reasons attributable to CKD within the warranty period specified below, CKD will promptly provide a replacement for the faulty product or a part thereof or repair the faulty product at one of CKD's facilities free of charge.

However, following failures are excluded from this warranty:

- Failure caused by handling or use of the product under conditions and in environments not conforming to those stated in the catalog, the Specifications, or this Instruction Manual.
- Failure caused by incorrect use such as careless handling or improper management.
- Failure not caused by the product.
- Failure caused by use not intended for the product.
- Failure caused by modifications/alterations or repairs not carried out by CKD.
- Failure that could have been avoided if the customer's machinery or device, into which the product is incorporated, had functions and structures generally provided in the industry.
- Failure caused by reasons unforeseen at the level of technology available at the time of delivery.
- Failure caused by acts of nature and disasters beyond control of CKD.

The warranty stated herein covers only the delivered product itself. Any loss or damage induced by failure of the delivered product is excluded from this warranty.

#### ■ Confirmation of product compatibility

It is the responsibility of the customer to confirm compatibility of the product with any system, machinery, or device used by the customer.

#### ■ Others

The terms and conditions of this warranty stipulate basic matters.

When the terms and conditions of the warranty described in individual specification drawings or the Specifications are different from those of this warranty, the specification drawings or the Specifications shall have a higher priority.

### 6.2 Warranty Period

The product is warranted for one (1) year from the date of delivery to the location specified by the customer.