

INSTRUCTION MANUAL SELEX CYLINDER SCA2-W (Two stage type)

- Please read this instruction manual carefully before using this product, particularly the section describing safety.
- Retain this instruction manual with the product for further consultation whenever necessary.

For Safety Use

To use this product safely, basic knowledge of pneumatic equipment, including materials, piping, electrical system and mechanism, is required (to the level pursuant to JIS B 8370 Pneumatic System Rules).

We do not bear any responsibility for accidents caused by any person without such knowledge or arising from improper operation.

Our customers use this product for a very wide range of applications, and we cannot keep track of all of them. Depending on operating conditions, the product may fail to operate to maximum performance, or cause an accident. Thus, before placing an order, examine whether the product meets your application, requirements, and how to use it.

This product incorporates many functions and mechanisms to ensure safety. However, improper operation could result in an accident. To prevent such accidents, **read this operation manual carefully for proper operation.** Observe the cautions on handling described in this manual, as well as the following instructions:

CAUTION:

- Before performing an overhaul inspection on the actuator, deactivate residual pressure completely.
- While the actuator is operating, do not step into or place hands in the driving mechanism.
- To prevent an electric shock, do not touch the electric wiring connections (exposed live parts) of the actuator equipped with a solenoid valve or switch.

Perform an overhaul inspection with the power off. Also, do not touch these live parts with wet hands.

INDEX

SCA2-W

(Two stage type)

Manual No. SM-337344-A

1. UNPACKING	3
2. INSTALLATION	
2.1 Installation	3
2.2 Piping	5
2.3 Fluid	6
2.4 Location of mounting Switches on a Cylinder	7
3. OPERATION	
3.1 Operating the Cylinder	11
3.2 How to use the Switches	12
4. MAINTENANCE	
4.1 Periodical Inspection	18
4.2 Disassembling	19
4.3 Keeping	22
5. TROUBLE SHOOTING	23
6. HOW TO ORDER	
6.1 How to order product	24
6.2 How to order switch	25
7. SPECIFICATION	
7.1 Product Specifications	26
7.2 Switches Specifications	27

1. UNPACKING


- 1) Make sure that the type No. on the nameplate of the delivered Selex Cylinder matches the type No. you ordered.
- 2) Check the appearance for any damage.
- 3) Stop up the piping port with a sealing plug to prevent the entry of foreign substances into the cylinder. Remove the sealing plug before piping.

2. INSTALLATION

2.1 Installation


- 1) The ambient temperature for this cylinder is -10 to 60°C (No freezing).
- 2) Use cylinder with bellows over its rod within the area with much dust.
- 3) Carefully avoid other object from hitting the tube. Otherwise, it may get the tube distorted and cause malfunction of the cylinder.
- 4) Assembly of mounting bracket:
 The mounting brackets are supplied with the cylinder at the time of deliver. Install them as shown in the figures on this page.
 However, the trunnion types (TC, TA and TB) are shipped with the trunnion mounted.

Assembly of mounting bracket (same as disassembling)




2 INSTALLATION

- 5) When cylinder is fixed and rod end is guided:
In case the piston rod of cylinder and the load are misaligned, the bushes and packings of the cylinder are extremely worn out. Hence, connect them with CKD floating connector (spherical bearing).
- 6) When cylinder is fixed and rod end is connected with pin joint:
In case the load acting direction is not parallel with the rod axial center, the rod and tube may get entangled causing seizure, etc. Hence, make sure that the rod axial center and the load transfer direction are aligned to each other.




- 7) When the load acting direction changes with the cylinder operation:
Use an oscillating cylinder (clevis type or trunnion type) capable of making revolution to a certain angle. Furthermore, install the rod and connecting metal (knuckle) so that it moves in the same direction as the cylinder main body does.




2.2 Piping

- 1) For piping beyond the filter, use pipes that are tough against corrosion such as galvanized pipes, nylon tubes, rubber tubes, etc.
- 2) See to it that the pipe connecting cylinder and solenoid valve has effective cross-sectional area which is needed for the cylinder to drive at the specified speed.
- 3) Install filter preferably adjacent to the upper-stream to the solenoid valve for eliminating rust, foreign substance in the drain of the pipe.
- 4) Be sure observe the effective thread length of gas pipe and give a chamfer of approx. 1/2 pitch from the threaded end.
- 5) Flush air into the pipe to blow out foreign substances and chips before piping.




- 6) Refrain from applying sealant or sealing tape approx. two pitches of thread off the tip of pipe to avoid residual substances from falling into piping system.

●Seal Tape




(Correct)




(Incorrect)

●Sealant (liquid)



(Correct)





(Incorrect)

2 INSTALLATION


2.3 Fluid

- 1) It is necessary to use dehumidified air that has been filtered from compressed air. Carefully select an adequate filter that has an adequate filtration rate (preferably $5\ \mu\text{m}$ or less), flow rate and its mounting location (as nearest to the directional control valve as possible).
- 2) Be sure to drain out the accumulation in the filter periodically.
- 3) Note that the intrusion of carbide for the compressor oil (such as carbon or tarry substance) into the circuit causes malfunction of the solenoid valve and the cylinder. Be sure to carry out thorough inspection and maintenance of the compressor.
- 4) This cylinder does not require lubrication. It is recommended, however, to use Turbine oil Grade 1, ISO VG32 as a lubricant, if and when lubrication is needed.



2.4 Location of mounting Switches on a Cylinder

1) Location of mounting switches on a cylinder.



(1) At the stroke end

Refer the illustration above. Mount switches within the rod side dimension RD as well as the head side dimension HD for the purpose of having switches function at the points of the maximum sensitive position.

(2) Intermediate of stroke

Move the piston where it is anticipated to stop and fix it tentatively. Slide a switch carefully along the side of cylinder over the piston to find out the spot where switch turns on. This type spot should be located on both side of piston. The intermediate spot between those points is of the maximum sensitive position and where the switch is supposed to be installed.

(3) Location around the circumference of cylinder

There is no restriction. However, 90° interval around circumference will be the most appropriate location when considered convenient posture of mounting tie rods.

2) Operating range

The switch turns on first and turns off as the piston moves along its stroke. Precise operating range deviate slightly depending upon the direction of piston movement as shown right.

3) Hysteresis

Precise operating range deviate slightly depending upon the direction of piston movement as shown right.

4) Maximum sensitive position, operating range and hysteresis

R type


(Unit : mm)

Item	Maximum sensitive position	Solid state switch type (R1, R2, R3)				Reed switch (R0, R4, R5, R6)	
Bore size (mm)	HD/RD	Operating range		Hysteresis		Operating range	Hysteresis
		1-color type	2-color type	1-color type	2-color type		
φ 40	5.5	6.5 to 11.5	10 to 14	1.5 or less	1.0 or less	9.5 to 12.5	3 or less
φ 50	7.5	8 to 12.5	12 to 16			10.5 to 14.5	
φ 63		7.5 to 12.5				11.5 to 15.5	
φ 80	9	8 to 13.5	12 to 17			12 to 16	
φ 100	13	8 to 14	12 to 17				

T2YD type

(Unit : mm)



Item	Maximum sensitive position	Operating range	Hysteresis
Bore size (mm)	HD/RD		
φ 40	10	6.5 to 9	1.5 or less
φ 50	12	7 to 10	
φ 63		7.5 to 10.5	
φ 80	13.5	8 to 11	
φ 100	17.5		





5) Location of switches mounted at ex-factory

Switches are mounted at the maximum sensitive position on cylinder.
Minimum stroke length of types with switch refers the table below.

(Unit : mm)

Item	Different surface Installation	Same surface Installation
Sketch		
Bore size (mm)		
φ 40	10	34
φ 50		
φ 63	10	10
φ 80		
φ 100		


Item	Rod side trunnion mounted	Head side trunnion mounted
Sketch		
Bore size (mm)		
φ 40	38 (28)	38 (28)
φ 50	36 (26)	36 (26)
φ 63	41 (31)	41 (31)
φ 80	44 (34)	44 (34)
φ 100	50 (40)	50 (40)

Remark : (figure) is for R※B (Terminal box type)

6) Relocation of switch

Loosen the set screws (2 ea.) for approx. 1/2 to 3/4 turn. It enables the switch to slide along the tie rod without letting screws drop off.


After setting the new location of switch, hold switch holder against the tube surface and tighten set screws to the tie rod. Adequate torque of tightening it is 1.7 to 2.0 N · m. It is considered to be sufficient, as a rule of thumb, when Allen wrench starts bending slightly.




7) Installation of switch

Follow the procedures (1) to (3) as described below.

- (1) While holding a switch underneath of switch holder, tighten M4×10 pan headed machine screws to mount it on the bracket.



- (2) Screw-in the set screws to mount the bracket on the tie rod. While letting the mounting bracket hook the tie rod, slightly screw further until it touches the rod. Thus, it eliminates the whole set of switch from falling off the rod, yet enables to slide the set along the rod. Make use this merit when engaged in adjusting location of the switch set.




- (3) To fix the mounting bracket on the tie rod, tighten screws while pressing bracket slightly against tube. Adequate torque of tightening screw is 1.7 to 2.0 N·m. It is considered to be sufficient, as a rule of thumb, when Allen wrench starts bending slightly.

3. OPERATION

3.1 Operating the Cylinder

- 1) The working pressure for this type of cylinder is specified in “Product Specifications”. Operate the system within this range.
- 2) Though the cushion has been adjusted at no load when delivered, adjust the cushion needle when the change of cushion effect is required.
Tightening the needle (clockwise) makes cushion more effective. Tighten the needle lock nut all the way after adjustment.



However, if kinetic energy such as load is heavy or speed is too fast, exceeding the values given in the allowable energy absorption of “7.1 Product Specifications”, consider of providing a shock absorber.

- 3) Adjust the working piston speed with the speed controller mounted.

3.2 How to use the Switches

3.2.1 Common items

1) Magnetic environment

Do not use a switch other than the strong magnetic field proof switch in a place where strong magnetic field or large current (large magnet or spot welding machine, etc.) exists around the switch mounting position. If a cylinder with the switch is installed in parallel to this product or the magnetic substance moves near the cylinder, the mutual interference may occur and affect the detection accuracy.

2) Lead wire wiring

Carefully perform the wiring so that a bending stress or tensile strength does not apply to the lead wire repeatedly.
Additionally, connect wires for robot having the bending resistance to movable parts.

3) Operating temperature

Do not operate the product at a high temperature (Over than 60°C).
Always avoid operation of the product in a hot place due to temperature characteristics of magnetic and electronics parts.

4) Intermediate position detection

When setting the cylinder switch at mid-stroke and driving a load when the piston changes, if the speed is too fast, the cylinder switch will function but operation time will be too short and the load may not respond correctly.


The maximum detectable working piston speed is :

$$V(\text{mm/s}) = \frac{\text{Cylinder switch operation range (mm)}}{\text{Load operation time (s)}}$$

Refer to the minimum value of the table on page 7 4) about cylinder switch operating range.

5) Impact

Do not apply a large vibration or impact to the product when transporting the cylinder, or mounting or adjusting the switch.



3.2.2 Reed switch (R0, R4, R5, R6)

1) Lead wire connections

Do not connect the lead wires of the switch to the power supply directly. Always connect the loads in series. For R0 switch, carefully check following items (1), (2).

- (1) When using the switch for DC power supply, connect the brown and blue lines to the positive and negative sides, respectively. If these lines are connected reversely, the switch is activated, but the indicator light is not lit.
- (2) When the switch is connected to an AC relay or a programmable controller input, the indicator light on the switch is not lit if the half-wave rectification is performed in the connected circuit. If this occurs, reverse the polarities of the switch lead wire connection. The indicator light may then be lit.

Note that the R4 and R5 switches have no polarities.

2) Contact protective measures

When an inductive load, such as relay is used or the wire length exceeds that stated in Table 1, always install a contact protective circuit.

Table 1

Switch	Electric power	Length of wire
R0, 5, 6	DC	100m
R0, 5	AC	10m
R4	AC	50m

- (1) Protective circuit when connecting an inductive type load.




Fig.1 When capacitor resister is used.






Fig.2 When diode is used.

(2) Protective circuit when the wire length exceeds that stated Table 1



- Choke coil
L=a couple hundred μ H to a couple mH
surpassing high frequency characteristic
- Install it near by a switch (within 2m).

Fig.3



- Dash current restriction resistor
R=As much large resistor as the load
circuit can afford.
- Install it near by a switch (within 2m).

Fig.4

(3) Contact capacity

Do not use a load exceeding the maximum contact capacity of the switch. Additionally, if the current is lower than the rated current value, the indicator light may not be lit. (R0, R6)

(4) Relay

Always use the relays listed below.

Omron CorporationMY type
Fuji Electric Co.,Ltd.HH5 type
Panasonic, Ltd.HC type

(5) Series connection

When multiple R0 switches are used with they connected in series, the voltage drop at the switch becomes the sum of voltage drop values of all switches.

Therefore, the voltage applied to the load becomes a voltage that the voltage drop at the switch is subtracted from the power supply voltage. Thus, always check the minimum operating voltage value of the load.

Example: The following shows the voltage drop at the switch when three R0 switches are connected in series.

$$2.4V \times 3 = 7.2 V$$

Since the voltage drop at the R5 switch is 0V, as many switches as required can be connected in series. When one R0 switch is used for checking of operation and R5 switch is used for other switches, they can be used with the voltage drop equivalent to one R0 switch (2.4V). In this case, the indicator light is lit only when all switches are turned ON.

If two R4 switches are connected at 100V AC or three or more R4 switches are connected at 200V AC, the indicator light is not lit. Additionally, the R6 switch cannot be connected in series.

(6) Parallel connection

When multiple R0 and R5 switches are connected in parallel, there are no limitations on the number of switches. When multiple R4 and R6 switches are connected in parallel, the Leakage current increases for the number of switches. Therefore, carefully check the load specifications to determine the number of switches to be connected.

However, if multiple R0 and R6 switches are turned ON at the same time, the indicator light becomes dark or is not lit. For R4 switch, if even one R4 switch is turned ON, all indicator lights go off.

3.2.3 Solid state switch (R1, R2, R3, T2YD)

1) Lead wire connections

Do not connect the lead wires of the switch to the power supply directly. Always connect the loads in series.

- (1) For R2 switch, connect the brown and blue lines to the positive and negative sides, respectively. If these lines are connected reversely, the switch and load are always kept activated. In this case, the indicator light is not lit.

For R3 switch, pay special attention to Fig. 2 below.

- (2) Always connect the lead wires while referring to the colors shown on the lead wires. At this time, turn OFF the power to the unit in the electrical circuit on the connection side before starting the wire connection work.

For R3 switch, if the wiring is performed incorrectly or the load is short-circuited, this may cause the switch, as well as the electrical circuit on the load side to break. Carefully connect the lead wires so that they are not connected incorrectly or short-circuited.

Additionally, the work with the power supplied may cause the switch and electrical circuit to break if the work is performed in an incorrect manner even though the incorrect wiring is not performed.




Fig.1 Fundamental circuit Example (1)
(In case the same source of power is used.)




Fig.2 Fundamental circuit Example (2)
(In case individual sources of power are used.)

2) Connection load

The R1 switch can be connected to a load, such as AC programmable controller, relay, solenoid, or solenoid valve.

The R2 switch is specially designed as a programmable controller switch. Since this switch uses two wires, it is connected to either the sink input or source input.

The R3 switch can be connected to a load, such as digital IC, microcomputer, programmable controller, relay, solenoid, or solenoid valve.

When selecting or designing a load, carefully check the static electrical characteristics, as well as transient electrical characteristics (rush current when the switch is turned ON or surge voltage when the switch is turned OFF) so that they do not exceed the switch ratings. Additionally, if the electrical characteristics may exceed the switch ratings, appropriate protective measures are taken (surge absorbing element or rush current limiting resistance, etc.).


3) Strong magnetic field proof switch (T2YD)

- External magnetic field proof performance (at welding current of AC14000A)

This strong magnetic field proof switch can be used for all T-type strong magnetic field solid state switch (T2YD) built-in cylinder models or operated in a status that the welding cable is in contact with the cylinder or switch. However, this switch cannot be used for two or more welding cables or within the cable loop.

Note: If this switch is used at a welding current of more than AC14000A, the welding cable must be made 35 mm or more apart from the cylinder tube surface.

(Testing conditions: Outside diameter of the cable is ϕ 36.)



4. MAINTENANCE

4.1 Periodical Inspection

- 1) In order to upkeep the cylinder in optimum condition, carry out periodic inspection once or twice a year.
- 2) Inspection items
 - (1) Check the bolts and nuts fitting the piston rod end brackets and mounting brackets for slackening.
 - (2) Check to see that the cylinder operates smoothly.
 - (3) Check any change of the working piston speed and cycle time.
 - (4) Check for internal and/or external leakage.
 - (5) Check the piston rod for flaw (scratch) and deformation.
 - (6) Check the stroke for abnormality.

See “5. Trouble shooting” should there be any trouble found, also carry out additional tightening if bolts, nuts, etc. are slackened.

4.2 Disassembling


Should any air leakage occur, take the following corrective actions.

- 1) Prepare the following tools for disassembling.

Disassembling tools

Name	Qty	Place of use	Applicable tube ID (mm)
Hex. bar spanner (Nominal 8)	2	20	40, 50, 63
Hex. bar spanner (Nominal 12)	2	20	80, 100
Spanner (Nominal 13)	1	22	For all tube ID
Standard driver (Nominal 5.5×75)	1	12, 23	For all tube ID
Minus tip screwdriver (Nominal 9×200)	1	9	For all tube ID
Marret hammer	1	For disassembling 7, 17 and 10	For all tube ID
Ice pick	1	3, 4, 8,21	For all tube ID

- 2) Disassemble the cylinder, referring to the following drawing.



Part No.	Part Name	Qty	Part No.	Part Name	Qty	Part No.	Part Name	Qty
1	Rod nut	1	13	Piston gasket	2	25	Tie rod	4
2	Piston rod (1)	1	14	Magnet	2	26	Conical spring washer	8
3	Dust wiper	1	15	Wear ring	4	27	Round nut	8
4	Rod packing	3	16	Piston (H)	2	28	Needle gasket	4
5	Bush	1	17	Head cover	1	29	Needle nut	4
6	Masking plate	2	18	Intermediate cover (H)	1	30	Cushion needle	4
7	Rod cover	1	19	Metal gasket	2			
8	Cylinder gasket	4	20	Spacer	1			
9	Cushion packing	4	21	Rod bushing	1			
10	Cylinder tube (1)	1	22	Intermediate cover (R)	1			
11	Piston (R)	1	23	Piston rod (2)	1			
12	Piston packing	2	24	Cylinder tube (2)	1			

3) Inspect the following items.

- (a) Scratch marks on the boar surface of the tube
- (b) Scratch marks on the surface of piston rod, peel-off of plating and rusting
- (c) Scratch marks and wear inside of the bush
- (d) Scratch marks, wear and crack of the surface of piston
- (e) Loosened connection of piston and rod
- (f) Crack of both end covers
- (g) Scratch marks and wear of packing in sliding part. (Dust wiper, rod packing, cushion packing and piston packing)

Check all of above items. If any abnormality is found, repair it or replace the parts, when defective.

4) About cushion packing


As for ⑨ cushion packing , the kind of cushion packing changes with manufacture years. Remove in the following procedure after checking the manufacture day of manufacture name plate.

In addition, even if it exchanges for different cushion packing from before, a difference is not in the performance of cushion packing.

〈Manufacture years : The product by March,2002〉

About the product by March, 2002, core metal is contained in the packing part, exchange of only the packing part cannot be performed. Exchange together with the metal ring.


Using the corner of cover as fulcrum and pushing a minus screw driver etc. on the metal ring, the metal ring is removed by patting a grip of the driver.



〈Manufacture years : The product after April, 2002〉

About the product after April, 2002, core metal is not contained in the packing part, exchange of only the packing part can be performed.

Remove only the packing part using sharp pointed tool such as minus screw driver or ice pick. (The metal ring is left as it is without removing.)



5) Assembly

- (1) Clean each component parts.
- (2) Take reversed sequence of disassembly to assemble cylinder after cleaning parts. Carefully avoid giving damage to packings to prevent malfunction or air leakage.
- (3) Apply thinly and uniformly a film of grade grease (Lithium alkali base) over the inner surface of ⑩ cylinder tube, outer surface of ⑪ piston(R), ⑯ piston(H), and packings (③、④、⑤、⑧、⑨、⑫、⑰).

〈About assembling of cushion packing〉

Manufacture years : The product by March, 2002, needs to press the metal ring in the case of cushion packing exchange. Work according to the following procedure.

The packing part is incorporated in the metal ring so that a surface with a protruding portion may be on the metal ringside.

To prevent a damage to packing also a tilt of it, use a jig and carefully press it in the place. Make sure to press it down so as the upper edge of its metal ring sink about 0.1 to 0.2mm below the top surface of the cover.





Table 2 and the illustration is an example of the jig.

Table 2. Press jig dimension

Bore size (mm)	A	B
φ 40	28	20
φ 50, φ 63	32	24
φ 80	45	35
φ 100	55	45



- (4) When tightening the round nuts, gradually tighten each nut on diagonal location to each other respectively, instead of tightening one nut all the way up. The table right displays the recommended range of torque for tightening.

Table 3. Tightening torque

Bore size (mm)	Torque (N·m)
φ 40, φ 50, φ 63	10.0
φ 80, φ 100	35.5

- 4) Followings are expendable parts.
Specify the kit No. when ordering.

(a) SCA2-W

Part No.	Name	Bore size (mm)	ϕ 40	ϕ 50	ϕ 63	ϕ 80	ϕ 100
		Kit No.	SCA2-W-40K	SCA2-W-50K	SCA2-W-63K	SCA2-W-80K	SCA2-W-100K
③	Dust wiper		SFR-16K	SFR-20K	SFR-20K	SFR-25K	SFR-30K
④	Rod packing		PNY-16	PNY-20	PNY-20	PNY-25	PNY-30
⑧	Cylinder gasket		F4-667115	F4-667116	F4-667117	F4-667118	F4-667119
⑨	Cushion packing		F4-436638	F4-436639	F4-436639	F4-436640	F4-436641
⑫	Piston packing		PMY-40	PMY-50	PMY-63	PMY-80	PMY-100
⑮	Wear ring		F4-650239	F4-650240	F4-650241	F4-650242	F4-650243
⑳	Needle gasket		P-3	P-3	P-3	P-3	P-3

4.3 Keeping

When you keep a product, be careful of the following point.

- Keep it away from direct sunlight and radiation.
- Keep it in a dark cool place away from heat source.
- Consider water proof and moisture proof , in order to prevent generating of rust.
- Prevent foreign matter and dust with the packing style before unpacking.

5. TROUBLE SHOOTING


1) Cylinder

Trouble	Causes	Remedies
Does not operate.	No pressure or inadequate pressure.	Provide an adequate pressure source.
	Signal is not transmitted to direction control valve.	Correct the control circuit.
	Improper or misalignment of Installation.	Correct the Installation state and/or change the mounting style.
	Broken piston packing	Replace the cylinder.
Does not function smoothly.	Speed is below the low speed limit	Limit the load variation and consider the adoption of low pressure cylinder.
	Improper or misalignment of Installation.	Correct the Installation state and/or change the mounting style.
	Exertion of transverse (lateral) load.	Install a guide. Revise the Installation state and/or change the mounting style.
	Excessive load.	Increase the pressure itself and/or the inner diameter of the tube.
	Speed control valve is built in the way of "Meter in" circuit.	Change the meter-out circuit of the speed control valve.
Breakage and/or deformation	Impact force due to high speed operation	Turn the speed down. Reduce the load and/or install a mechanism with more secured cushion effect (e.g. external cushion mechanism).
	Exertion of transverse load.	Install a guide. Reverse the Installation state and/or change the mounting style.

2) Switch


Troubles	Causes	Remedies
Indicator light is not lit.	Deposited contact point	Replace the switch.
	Excessive load than rated capacity	Replace the relay with a recommended one or replace the switch.
	Damaged indicator light	Replace the switch.
	Inadequate incoming signal	Review the external signal circuit and remove the causes.
Switch does not function right.	Broken circuit	Replace the switch.
	Inadequate incoming signal	Review the external signal circuit and remove the causes.
	Improper voltage	Correct voltage to specified.
	Incorrect location of switch	Correct its location.
	Aberrant position of switch	Set it back to original position and tighten the mounting device. Tightening torque is 1.5 to 1.9 N·m
	Incorrect direction of switch mounting	Correct the direction of the switch mounting.
	Relay is unable to respond properly	Replace the relay with a recommended one.
	Excessive load than rated capacity	Replace the relay with a recommended one or replace the switch.
	Excessive speed of piston if it is to sense an inter working fluid point of stroke	Reduce the speed of piston.
Switch does not return.	Piston is not moving	Make the piston move.
	Deposited contact point	Replace the switch
	Excessive load (relay) than rated capacity	Replace the relay with a recommended one or replace the switch.
	The ambient temperature is out of the specification range	Adjust the ambient temperature within the range of -10 to 60°C
	Existence of a foreign magnetic field	Shield the magnetic field.
	Inadequate incoming signal	Review the external signal circuit and remove the causes.

Note 1. Refer "2.4 Location of mounting Switches on a Cylinder" as for replacing a switch and correcting its location.



6. HOW TO ORDER

6.1 How to order product



(a) Mounting style Note1		(b) Bore size (mm)		(c) Cushion		(d) Stroke (mm) Note2	
00	Basic type	40	φ 40	B	Both side cushion	25	250
LB	Axial foot type	50	φ 50	R	Rod side cushion	50	300
FA	Rod side flange type	63	φ 63	H	Head side cushion	75	350
FB	Head side flange type	80	φ 80	N	Non cushion	100	400
FC	Special head side flange type	100	φ 100			150	450
CA	Eye bracket type					200	500
CB	Clevis bracket type						
TA	Rod side trunnion type						
TB	Head side trunnion type						

Note1 : Mounting bracket is attached to the product at shipment. (The trunnion mounting types are assembled at shipment.)

Note2 : Refer to catalog as for cylinder exceeding max. stroke.

(e) Switch model No.						(f) Switch quantity		
Grommet type	Terminal box type		Switch type	Display	Lead wire	R	One on rod side	
	Standard type	Splash-prf.				H	One on head side	
R1※	R1B	R1A	Solid state	1 color indicator	2 wire	D	Two	
R2※	R2B	R2A		2 color indicator		T	Three	
R2Y※	R2YB	—		Strong magnetic field proof switch	2 wire			
T2YD※	—	—						
T2YDT※	—	—			1 color indicator	3 wire		
R3※	R3B	R3A					2 color indicator	
R3Y※	R3YB	—	Reed	1 color indicator	2 wire			
R0※	R0B	R0A						
R4※	R4B	R4A						
R5※	R5B	R5A						
R6※	R6B	R6A						


※ mark indicates the length of lead wire.

※ Lead wire length	
Blank	1m (standard)
3	3m (option)
5	5m (option)


(g) Option				(h) Accessory	
		Max. ambient	Min. ambient	I	Rod eye
J	Bellows	100℃	200℃	Y	Rod clevis
L	Bellows	250℃	400℃	B1	Eye bracket
M	Piston rod material change (stainless steel)			B2	Clevis bracket
Blank	Cushion needle position R (standard)			B3	Eye bracket
S	Cushion needle position S			B4	Trunnion type No.2 bracket
T	Cushion needle position T				
P6	Copper and PTFE free				

6.2 How to order switch


(A) Switch body + Mounting bracket



(B) Switch alone




(C) Set of mounting bracket




※ For spatter countermeasures, RF is provided.
(R2YK,R3YK switch only)

(D) Terminal box alone




● How to order T2YD type switch


(A) Switch body + Mounting bracket




(B) Switch alone



(C) Set of mounting bracket





7. SPECIFICATION

7.1 Product specifications

Model		SCA2-W (two stage type)				
Item						
Bore size	mm	φ 40	φ 50	φ 63	φ 80	φ 100
Actuation		Double acting				
Working fluid		Compressed air				
Max. working pressure	MPa	1.0				
Min. working pressure	MPa	0.1				
Proof pressure	MPa	1.6				
Ambient temperature		-10 to 60 (No freezing)				
Port size		Rc1/4	Rc3/8		Rc1/2	
Stroke tolerance	mm	$\begin{matrix} +1.0 \\ 0 \end{matrix}$ (to 300)、 $\begin{matrix} +1.4 \\ 0 \end{matrix}$ (to 500)、 $\begin{matrix} +2.0 \\ 0 \end{matrix}$ (to 1000)				
Working piston speed	mm/s	50 to 1000 (use this within allowable energy absorption range.)				
Cushion		Air cushion				
Effective air cushion length	mm	14.6	16.6	16.6	20.6	23.6
Lubrication		Not required (Use Grade 1 ISO VG 32 Turbine oil, if lubrication is preferred)				
Allowable energy absorption J	Cushioned	4.29	8.37	15.8	27.9	49.8
	Non cushion	The big energy generated by an external load the this cylinder cannot absorbed. We will recommend an outside accumulator to be used together.				

7.2 Switches Specification

Type & Model	Reed 2 wire				
Item	R0			R4	
Applications	Relay, programmable controller			High capacity relay, solenoid valve	
Load voltage	DC12/24V	AC110V	AC220V	AC110V	AC220V
Load current	5 to 50mA	7 to 20mA	7 to 10mA	20 to 200mA	10 to 200mA
Internal voltage drop	2.4V or less			2V or less	
Indicator light	LED (ON lighting)			Neon light OFF (OFF lighting)	
Leakage current	0mA			1mA or less	
Lead wire length (Note 1)	1m (oil resistant vinyl cabtire cord, 2 conductor 0.3mm ²)				
Shock resistance	294m/s ²				
Insulation resistance	20 MΩ over at DC500V megger				
Withstand voltage	No failure at AC1,500V impressed for one minute				
Ambient temperature	-10 to 60℃				
Degree of protection (Note 3)	Grommet type IEC Standards IP67, JIS C0920 (water tight type), Oil resistance				

Type & Model	Reed 2 wire				
Item	R5			R6	
Applications	Programmable controller, relay, IC circuit (without indicator light), serial connection			Programmable controller (DC self hold function)	
Load voltage	DC5/12/24V	AC100V	AC200V	DC24V	
Load current	50mA or less	20mA or less	10mA or less	5 to 50mA(Note 2)	
Internal voltage drop	0V			5V or less	
Indicator light	None			LED (ON lighting)	
Leakage current	0mA			0.1mA or less	
Lead wire length (Note 1)	1m (oil resistant vinyl cabtire cord, 2 conductor 0.3mm ²)				
Shock resistance	294m/s ²				
Insulation resistance	20 MΩ over at DC500V megger				
Withstand voltage	No failure at AC1500V impressed for one minute				
Ambient temperature	-10 to 60°C				
Degree of protection (Note 3)	Grommet type IEC Standards IP67, JIS C0920 (water tight type), Oil resistance				

Type & Model	Solid state 2 wire		
Item	R1	R2	R2Y (2 color indicator)
Applications	Programmable controller, relay, small solenoid valve	Programmable controller	
Power supply voltage	—		
Load voltage	AC85 to 265V	DC10 to 30V	
Load current	5 to 100mA(Note 2)	5 to 30mA (Note 2)	
Current consumption	—		
Internal voltage drop	7V or less	4V or less	
Indicator light	LED (ON lighting)		Red/ green LED (ON lighting)
Leakage current	1mA or less at AC110V 2mA or less at AC220V	1mA or less	1.2mA or less
Lead wire length (Note 1)	1m (oil resistant vinyl cabtire cord, 2 conductor 0.3mm ²)		
Shock resistance	980m/s ²		
Insulation resistance	20 MΩ over at DC500V megger		
Withstand voltage	No failure at AC1500V impressed for one minute	No failure at AC1000V impressed for one minute	
Ambient temperature	-10 to 60°C		
Degree of protection (Note 3)	Grommet type IEC Standards IP67, JIS C0920 (water tight type), Oil resistance		

7
SPECIFICATION

Type & Model	Solid state 3 wire	
Item	R3	R3Y (2 color indicator)
Applications	Programmable controller, relay, IC circuit, solenoid valve	
Power supply voltage	DC4.5 to 28V	
Load voltage	DC30V or less	DC30V or less
Load current	200mA or less	150mA or less
Current consumption	At DC24V (at ON state)	
	10mA or less	16mA or less
Internal voltage drop	0.5V or less at 150mA	0.5V or less
Indicator light	LED (ON lighting)	Red/green LED (ON lighting)
Leakage current	10 μ A or less	
Output delay time (ON delay, OFF delay) (Note 4)	—	
Lead wire length (Note 1)	1 m (oil resistant vinyl cabtire cord, 3 conductor 0.2mm ²)	
Shock resistance	980m/s ²	
Insulation resistance	20 M Ω over at DC500V megger	
Withstand voltage	No failure at AC1000V impressed for one minute	
Ambient temperature	-10 to 60°C	
Degree of protection (Note 3)	Grommet type IEC Standards IP67, JIS C0920 (water tight type), Oil resistance	

Type & Model	Solid state 2 wire	
Item	T2YD	T2YDT
Applications	Programmable controller	
Power supply voltage	—	
Load voltage	DC24V \pm 10%	
Load current	5 to 20mA(Note 2)	
Current consumption	—	
Internal voltage drop	6V or less	
Indicator light	Red/green LED (ON lighting)	
Leakage current	1.0mA or less	
Output delay time (ON delay, OFF delay) (Note 4)	30 to 60mS	
Lead wire length (Note 1)	1 m (oil resistant vinyl cabtire cord, 2 conductor 0.5mm ²)	1 m (flame resistant vinyl cabtire cord, 2 conductor 0.5mm ²) (option)
Shock resistance	980m/s ²	
Insulation resistance	100 M Ω over at DC500V megger	
Withstand voltage	No failure at AC1000V impressed for one minute	
Ambient temperature	-10 to 60°C	
Degree of protection (Note 3)	Grommet type IEC Standards IP67, JIS C0920 (water tight type), Oil resistance	

Note 1 : 3m or 5m long lead wire is optionally available.

Note 2 : Max. load current above is value at 25°C. The current will be lower if the temperature around switch is higher than 25°C.(50% at 60°C)

Note 3 : R※B terminal box is not water-proof. The water-proof R※A type box (Matsushita Denko made) is the order made item.

Note 4 : This shows a period of time between detection of the Magnet by the magnetic sensor and sending of switch output.