



Pneumatic Components  
**To Use This Product Safely**

Be sure to read this before use.  
For general pneumatic components precautions, Intro Page 15 for details.

Individual Precautions: 11 mm Pitch Manifold Dedicated Type VSZPM Series

**Design / Selection**

**Warning**

■The vacuum switching unit (VSZP) allows leakage. Hence, take other safety measures if vacuum retention for long periods is required.

**Caution**

- Manifold silencer specification may cause performance degradation and trouble due to element clogging. Perform periodic maintenance inspections.
- Depending on usage conditions, the manifold may undergo deterioration of vacuum performance or trouble. Hence, fully understand the manifold safety precautions in this catalog before use.
- When all units are not operated at the same time, the ejector exhaust of the operating unit leads to the vacuum port of the stopped unit. If exhaust flow-around poses a problem, please consult us.

For precautions regarding mounting, installation, adjustment, operation, and maintenance, please refer to the CKD Equipment Product Site(<https://www.ckd.co.jp/kiki/en/>) → 'model No.' → [Instruction Manual](#)