

Outdoor Products WP Series F.R.L. Combination Unit CW* Series





Unit reduces work processes by 30% or more*



Replacements decreased significantly

No need for unit connecting parts

No pre-assembly work required

No need to inspect assembly points for leaks

Meets outdoor components requirements Long-term trouble-free operation in harsh outdoor environments Accelerated weathering test

3-year equivalent

7-year

Ozone exposure test
400
hours

-20°C to 60°C

Note: Excluding lubricator

*Comparison of work hours required when connecting components using nipple connections to CW4000 (reference values based on our standard procedures). Leakage inspection after assembly is not included.



F.R.L. combination outdoor series

CW3000, CW4000, CW8000 Series

Space-saving with integrated filter, regulator and lubricator


Port size: 1/4 to 1

Circuit diagram symbol





How to order



		0	Model	No.
2 Po	CW3000	CW4000	CW8000	
Code	Description	ပ	၁	ပ
8	1/4	•	•	
10	3/8	•	•	
15	1/2		•	
20	3/4			•
25	1			•

3 Port thread

	_	
	Code	Description
	Blank	Rc thread
	N	NPT thread
ı	G	G thread

*1: G threads and NPT threads are available for IN, OUT, gauge port and drain discharge port (metal bowl with auto-drain).

4Option

<u></u>

	Type	pe Code Description		
	ge	Blank	Filter with manual cock, lubricator without manual cock	
	char	С	Lubricator with manual cock	
* 2	Drain Discharge	F	Filter/auto-drain with manual (NO: with exhaust when not pressurized)	
	۵	F1	Filter/auto-drain with manual (NC: without exhaust when not pressurized)	
	Element	Blank	5 μm	
	Element	Υ	0.3 µm (submicron) *3	
		Blank	without knob	
	Knob	К	With knob	
	Morrontu	Blank	1 year after delivery	
	Warranty period	G	3 years after delivery *4,*5 (with inspection certificate, inspection guidelines, traceability system diagram)	
	Flow	Blank	Standard flow (left → right)	
	direction	X1	Reverse flow (right → left)	

*1: Select options for the drainage, element, knob, and warranty period Items. When selecting options for several items, list options in order from the top.

- **★**2: For the auto-drain usage conditions, see Page 18.
- *3: For the max. processing flow rate when option "Y" is selected, see Page 2.
- *4: The warranty period of option G is 3 years from the date of delivery or 1 year from initial use, whichever comes first.
- *5: For option G, the specifications and drawings must be agreed upon. See the back cover for more information.

5 Other attachments

Code	Description		
Blank	Not included		
GW49P	Pressure gauge GW49D-6-P10	7	

*1: Pressure gauge options (included) ② can be selected only when the piping thread type is Rc thread.

F.R.L Combination Outdoor Series

Specifications / Flow Characteristics

Specifications

Item		CW3000-W	CW4000-W	CW8000-W		
2 1	Air Filters	FW3000-W	FW4000-W	FW8000-W		
System Components	Regulator	RW3000-W	RW4000-W	RW8000-W		
Components	Lubricator	LW3000-W	LW4000-W	LW8000-W		
Working f	luid		Compressed air			
Max. worki	ng pressure MPa		1.0			
Proof pres	ssure MPa		1.5			
Ambient t	emperature °C		-10 to 60			
Fluid temp	perature °C		5 to 60			
Filtration i	rating µm	5				
Pressure	setting MPa	0.05 to 0.85				
Min. drip 1	flow rate (* 1)	30 6	65	65		
	L/min (ANR)		05			
Pressure	relief	With relief mechanism				
Oil storag	e capacity cm³	85	170	170 (MAX360)		
Drain capacity cm ³		45	80	80 (*2)		
Oil used		Turbine oil Class 1 ISO VG32 (spindle oil cannot be used)				
Port size	Rc, NPT, G	1/4, 3/8	1/4, 3/8, 1/2	3/4, 1		
Weight	kg	1.41	2.04	4.75		
Standard	Accessories		Pressure gauge			


Option weight

★Add to the weight of standard accessories.	Unit: kg
---	----------

Code	Drain discharge			Knob	Attachment
Code	С	F	F1	K	GW49P
CW3000	0	0.02	0.02	0.1	0.1
CW4000	0	0.02	0.02	0.1	0.1
CW8000	0	0.02	0.02	0.1	0.1

- *1: The min. drip flow is that at which five drops of turbine oil drip per minute at the set pressure of 0.5 MPa.
- *2: Only the manual petcock type can store up to 170 cm³.
- *3: In the case of "F" with auto-drain, the min. working pressure of auto-drain is 0.1 MPa. Air is purged with initial drain until pressure reaches 0.1 MPa.
- *4: In the case of "F1" with auto-drain, the min. working pressure of auto-drain is 0.15 MPa.
- *5: Refer to the max. working flow rate table below for the max. flow rate of element option "Y". Set the working flow to less than the max. working flow.

Flow Characteristics



0

0.9

0.5

Primary pressure (MPa)


0.6


0.3 0.4


F.R.L Combination Outdoor Series

Dimensions


● CW3000










Enlarged view of bracket section










● CW4000









Optional dimensions








F.R.L Combination Outdoor Series


Dimensions

Dimensions

● CW8000



*1: Dimensions at 0 MPa pressure setting.



Dimensions of bracket section



W.L. Combination Outdoor Series

CW3010, CW4010, CW8010 Series

Integrated filter, regulator and lubricator


Port size: 1/4 to 1

Circuit diagram symbol





How to order



		0	Vlodel	No.
2 Po	CW3010	CW4010	CW8010	
Code	Description	ပ	C	ပ
8	1/4	•	•	
10	3/8	•	•	
15	1/2		•	
20	3/4			•
25	1			•

3 Port thread

Code	Description	
Blank	Rc thread	
N	NPT thread	
G	G thread	

*1: G threads and NPT threads are available for IN, OUT, gauge port and drain discharge port (metal bowl with auto-drain).

4Option

	Type	Code	Description		
	ge	Blank	Filter with manual cock, lubricator without manual cock		
	char	С	Lubricator with manual cock		
* 2	Drain Discharge	F	Filter/auto-drain with manual (NO: with exhaust when not pressurized)		
	۵	F1	Filter/auto-drain with manual (NC: without exhaust when not pressurized)		
	Element	Blank	5 μm		
	Element	Υ	0.3 µm (submicron)	* 3	
		Blank	without knob		
	Knob	К	With knob	1	
	Marranti	Blank	1 year after delivery		
	Warranty period	G	3 years after delivery (with inspection certificate, inspection guidelines, traceability system diagram	4, * 5 n)	
	Flow	Blank	Standard flow (left → right)		
	direction	X1	Reverse flow (right → left)		

*1: Select options for the drainage, element, knob, and warranty period Items. When selecting options for several items, list options in order from the top.

★2: For the auto-drain usage conditions, see Page 18.

*3: For the max. processing flow rate when option "Y" is selected, see Page 2.

5 Other attachments

Code	Description		
Blank	Not included		
GW49P	Pressure gauge GW49D-6-P10	7)	

*1: Pressure gauge options (included) ② can be selected only when the piping thread type is Rc thread.

^{*4:} The warranty period of option G is 3 years from the date of delivery or 1 year from initial use, whichever comes first.

^{*5:} For option G, the specifications and drawings must be agreed upon. See the back cover for more information.

W.L Combination Outdoor Series

Specifications / Flow Characteristics

Specifications

Item		CW3010-W	CW4010-W	CW8010-W	
System	Filter / Regulator	WW3000-W	WW4000-W	WW8000-W	
Components	Lubricator	LW3000-W	LW4000-W	LW8000-W	
Working flu	id		Compressed air		
Max. working	pressure MPa		1.0		
Proof press	sure MPa		1.5		
Ambient te	mperature °C		-10 to 60		
Fluid tempe	erature °C		5 to 60		
Filtration ra	ting µm		5		
Pressure s	etting MPa		0.05 to 0.85		
Min. drip flo	ow rate (* 1)	20	65	65	
	L/min (ANR)	30		65	
Pressure re	elief		With relief mechanism		
Oil storage	capacity cm³	85	170	170 (MAX360)	
Drain capa	city cm³	45	80	80 (*2)	
Oil used		Turbine o	Turbine oil Class 1 ISO VG32 (spindle oil cannot be used)		
Port size		1/4, 3/8	1/4, 3/8, 1/2	3/4, 1	
	Rc, NPT, G	(1/2 uses an adaptor)	(3/4 uses an adaptor)	(1 1/4 uses an adaptor)	
Weight	kg	1.27	1.75	3.97	
Standard A	ccessories		Pressure gauge		

^{*1:} The min. drip flow is that at which five drops of turbine oil drip per minute at the set pressure of 0.5 MPa.

Option weight

*Add to the weight of standard accessories.

Unit: kg

Codo	Drain discharge			Knob	Attachment
Code	С	F	F1	K	GW49P
CW3010	0	0.02	0.02	0.1	0.1
CW4010	0	0.02	0.02	0.1	0.1
CW8010	0	0.02	0.02	0.1	0.1

^{*}2: Only the manual petcock type can store up to 170 cm³.

^{*3:} In the case of "F" with auto-drain, the min. working pressure of auto-drain is 0.1 MPa. Air is purged with initial drain until pressure reaches 0.1 MPa.


^{*4:} In the case of "F1" with auto-drain, the min. working pressure of auto-drain is 0.15 MPa.


^{*5:} When element option "Y" is selected, the max. flow rate is the max. working flow rate table (Page 2). Set the working flow to less than the max. working flow.


W.L Combination Outdoor Series

Dimensions


● CW3010










Optional dimensions Manual cock (C) Tube center 143.5 Drain outlet






● CW4010








Rc1/4 Drain outlet With knob (K) Tube center

· Optional dimensions



With auto-drain (F, F1)


Additional weight: 0.1 kg


W.L Combination Outdoor Series


Dimensions


Dimensions


● CW8010












*1: Dimensions at 0 MPa pressure setting.



Dimensions of bracket section



F.R. Combination Outdoor Series

CW3020, CW4020, CW8020 Series

Integrated filter and regulator

Port size: 1/4 to 1


Circuit diagram symbol





How to order

40ption



		1 Model No.		No.
2 Po	rt size	CW3020	CW4020	CW8020
Code	Description	ပ	ပ	၁
8	1/4	•	•	
10	3/8	•	•	
15	1/2		•	
20	3/4			•
25	1			•

3 Port thread

Code	Description		
Blank	Rc thread		
N	NPT thread		
G	G thread		

*1: G threads and NPT threads are available for IN, OUT, gauge port and drain discharge port (metal bowl with auto-drain).

Туре Code Description **Blank** Filter with manual cock Drain Discharge Filter/auto-drain with manual (NO: with exhaust when not pressurized) Filter/auto-drain with manual F1 (NC: without exhaust when not pressurized) **Blank** Ele ment 0.3 µm (submicron) *****3 **Blank** without knob Knob with knob **Blank** 1 year after delivery quarantee 3 years after delivery Period G (with inspection certificate, inspection guidelines, traceability system diagram **Blank** Standard flow (left → right) Flow

*1: Select options for the drainage, element, knob, and warranty period Items. When selecting options for several items, list options in order from the top.

IN/OUT reverse flow (right to left)

- *2: For the auto-drain usage conditions, see Page 18.
- \$3: For the max. processing flow rate when option "Y" is selected, see Page 2.
- *4: The warranty period of option G is 3 years from the date of delivery or 1 year from initial use, whichever comes first.
- *5: For option G, the specifications and drawings must be agreed upon. See the back cover for more information.

5 Other attachments

Code	Description		
Blank	Not included		
GW49P	Pressure gauge GW49D-6-P10	7	

*1: Pressure gauge options (included) **3** can be selected only when the piping thread type is Rc thread.

F.R Combination Outdoor Series

Specifications / Flow Characteristics

Specifications

Item		CW3020-W	CW4020-W	CW8020-W			
System	Filter	FW3000-W	FW4000-W	FW8000-W			
Components	Regulator	RW3000-W	RW4000-W	RW8000-W			
Working fl	luid		Compressed air				
Max. Workii	ng Pressure, MPa		1.0				
Proof pres	ssure MPa		1.5				
Ambient to	emperature °C	mperature °C -20 to 60					
Fluid temp	perature °C	-20 to 60 (no freezing)					
Degree of	f Filtration µm		5				
Set pressure MPa 0.05 to 0.85		0.05 to 0.85					
Pressure	relief		With relief mechanism				
Drain capacity cm³		45	80	80 (* 1)			
Port size	Rc, NPT, G	1/4, 3/8	1/4, 3/8, 1/2	3/4, 1			
Weight	kg	0.94	1.25	2.93			
Standard Accessories			Pressure gauge, bracket, bowl guard				

^{*1:} Only the manual petcock type can store up to 170 cm³.

Option weight

*Add to the weight of standard accessories.

Unit: kg

Codo	Drain di	scharge	Knob	Attachment
Code	F	F1	K	GW49P
CW3020	0.02	0.02	0.1	0.1
CW4020	0.02	0.02	0.1	0.1
CW8020	0.02	0.02	0.1	0.1

^{*2:} In the case of "F" with auto-drain, the min. working pressure of auto-drain is 0.1 MPa. Air is purged with initial drainage until pressure reaches 0.1 MPa.


^{*3:} In the case of "F1" with auto-drain, the min. working pressure of auto-drain is 0.15 MPa.


^{*4:} For the max. flow rate when element option "Y" is selected, see Page 2. Set the working flow to less than the max. working flow.

F.R Combination Outdoor Series


Dimensions

● CW3020






Optional dimensions
 With auto-drain (F, F1)





With knob (K)




Enlarged view of bracket section


● CW4020






Optional dimensions
 With auto-drain (F, F1)








Enlarged view of bracket section

F.R Combination Outdoor Series


Dimensions


Dimensions

● CW8020




Optional dimensions
 With auto-drain (F, F1)





*1: Dimensions at 0 MPa pressure setting.



Dimensions of bracket section



W.M. Combination Outdoor Series

CW3040, CW4040, CW8040 Series

Filter/regulator and oil mist filter integrated

Port size: 1/4 to 1


Circuit diagram symbol





How to order

40ption



		1 Model No.		No.
2 Po	rt size	CW3040	CW4040	CW8040
Code	Description	Ö	S	Ö
8	1/4	•	•	
10	3/8	•	•	
15	1/2		•	
20	3/4			•
25	1			•

3 Port thread

Code	Description	
Blank	Rc thread	
N	NPT thread	
G	G thread	

*1: G threads and NPT threads are available for IN, OUT, gauge port and drain discharge port (metal bowl with auto-drain).

Туре Code Description **Blank** Filter with manual cock Drain Discharge Filter/auto-drain with manual *****2 (NO: with exhaust when not pressurized) Filter/auto-drain with manual F1 (NC: without exhaust when not pressurized) **Blank** Element 0.3 µm (submicron) *****3 Blank without knob Knob with knob **Blank** 1 year after delivery Warranty 3 years after delivery period G

*1: Select options for the drainage, element, knob, and warranty period Items. When selecting options for several items, list options in order from the top.

Standard flow (left → right)

IN/OUT reverse flow (right to left)

(with inspection certificate, inspection guidelines, traceability system diagram

- *2: For the auto-drain usage conditions, see Page 18.
- \$3: For the max. processing flow rate when option "Y" is selected, see Page 2.
- *4: The warranty period of option G is 3 years from the date of delivery or 1 year from initial use, whichever comes first.
- *5: For option G, the specifications and drawings must be agreed upon. See the back cover for more information.

5 Other attachments

Code	Description		
Blank	Not included		
GW49P	Pressure gauge GW49D-6-P10	7	

*1: Pressure gauge options (included) **3** can be selected only when the piping thread type is Rc thread.

Blank

Flow

W.M Combination Outdoor Series

Specifications / Flow Characteristics

Specifications

Item		CW3040-W	CW4040-W	CW8040-W			
System	Filter regulator	WW3000-W	WW4000-W	WW8000-W			
Components	Oil Mist Filter	MW3000-W	MW4000-W	MW8000-W			
Working fluid			Compressed air				
Max. Working F	ressure, MPa		1.0				
Proof pressu	re MPa		1.5				
Ambient tem	perature °C		-20 to 60				
Fluid tempera	ature °C		-20 to 60 (no freezing)				
Set pressure	MPa	0.1 to 0.85 * 2, * 3					
Pressure relie	ef		With relief mechanism				
Port size	Rc, NPT, G	1/4, 3/8	1/4, 3/8, 1/2	3/4, 1			
Weight	kg	0.97	1.52	3.52			
Secondary side oil concentration		0.01 mg/m	0.01 mg/m³ Below (0.1 mg/ after oil saturation m³ or less)				
Max. flow rate (*1) L/min		360	825	2600			

^{*1:} Max. flow rate is for the regulator set pressure 0.7 MPa. In addition, refer to the max. flow rate of element option "Y" on Page 2.

Option weight

*Add to the weight of standard accessories.

Unit: kg

Codo	Drain di	scharge	Knob	Attachment
Code	F	F1	K	GW49P
CW3040	0.02	0.02	0.1	0.1
CW4040	0.02	0.02	0.1	0.1
CW8040	0.02	0.02	0.1	0.1


^{*2:} In the case of "F" with auto-drain, the supply air pressure is 0.2 MPa or more. The minimum set pressure is 0.15 MPa. The supply air pressure of the auto-drain of the filter regulator is 0.1 MPa. Air is purged with initial drain until pressure reaches 0.1 MPa.


^{*3:} In the case of "F1" with auto-drain, the supply air pressure is 0.2 MPa or more. The minimum set pressure is 0.15 MPa.

W.M Combination Outdoor Series


Dimensions

● CW3040







 Optional dimensions With auto-drain (F, F1)




With knob (K)







Enlarged view of bracket section









 Optional dimensions With auto-drain (F, F1)



With knob (K)






Enlarged view of bracket section

W.M Combination Outdoor Series


Dimensions

Dimensions


● CW8040




Optional dimensions
 With auto-drain (F, F1)



With knob (K)



*1: Dimensions at 0 MPa pressure setting.



Dimensions of bracket section



Safety Precautions

Be sure to read this section before use.

When designing and manufacturing a device using CKD products, the manufacturer is obligated to check that device safety mechanism, pneumatic control circuit, or water control circuit and the system operated by electrical control that controls the devices is secured.

It is important to select, use, handle and maintain the product appropriately to ensure that the CKD product is used safely. Observe warnings and precautions to ensure device safety.

Check that device safety is ensured, and manufacture a safe device.



WARNING

- 1 This product is designed and manufactured as a general industrial machine part. It must be handled by an operator having sufficient knowledge and experience.
- 2 Use this product in accordance with specifications.

This product must be used within its stated specifications. In addition, never modify or additionally machine this product. This product is intended for use in general industrial machinery equipment or parts. It is not intended for use outdoors (except for products with outdoor specifications) or for use under the following conditions or environments. (Note that this product can be used when CKD is consulted prior to its usage and the customer consents to CKD product specifications. The customer should provide safety measures to avoid danger in the event of problems.)

- 1 Use for applications requiring safety, including nuclear energy, railways, aircraft, marine vessels, vehicles, medical devices, devices or applications in contact with beverages or foodstuffs, amusement devices, emergency cutoff circuits, press machines, brake circuits, or safety devices or applications.
- Use for applications where life or assets could be significantly affected, and special safety measures are required.
- 3 Observe organization standards and regulations, etc., related to the safety of device design and control, etc. ISO4414, JIS B 8370 (Pneumatics fluid power - General rules and safety requirements for systems and their components) JFPS2008 (Principles for pneumatic cylinder selection and use) Including the High Pressure Gas Safety Act, Industrial Safety and Health Act, other safety rules, organization standards and regulations, etc.
- 4 Do not handle, pipe, or remove devices before confirming safety.
 - Inspect and service the machine and devices after confirming safety of all systems related to this product.
 - 2 Note that there may be hot or charged sections even after operation is stopped.
 - 3 When inspecting or servicing the device, turn OFF the energy source (air supply or water supply), and turn OFF power to the facility. Discharge any compressed air from the system, and pay attention to possible water leakage and leakage of electricity.
 - When starting or restarting a machine or device that incorporates pneumatic components, make sure that the system safety, such as pop-out prevention measures, is secured.
- 5 Observe warnings and cautions in the following pages to prevent accidents.
- The precautions are ranked as "DANGER", "WARNING" and "CAUTION" in this section.



DANGER: When a dangerous situation may occur if handling is mistaken leading to fatal or serious injuries, and when there is a high degree of emergency to a warning.



WARNING: If handled incorrectly, a dangerous situation may occur, resulting in death or serious injury.



CAUTION: When a dangerous situation may occur if handling is mistaken leading to minor injuries or physical damage.

Note that some items described as "CAUTION" may lead to serious results depending on the situation. Every item provides important information and must be observed.

Warranty

1 Warranty period

The product specified herein is warranted for one (1) year from the date of delivery to the location specified by the customer.

2 Warranty coverage

If the product specified herein fails for reasons attributable to CKD within the warranty period specified above, CKD will promptly provide a replacement for the faulty product or a part thereof or repair the faulty product at one of CKD's facilities free of charge. However, following failures are excluded from this warranty:

- 1) Failure caused by handling or use of the product under conditions and in environments not conforming to those stated in the catalog, the Specifications, or the Instruction Manual.
- 2) Failure caused by use of the product exceeding its durability (cycles, distance, time, etc.) or caused by consumable parts.
- 3) Failure not caused by the product.
- 4) Failure caused by use not intended for the product.
- 5) Failure caused by modifications/alterations or repairs not carried out by CKD.
- 6) Failure caused by reasons unforeseen at the level of technology available at the time of delivery.
- 7) Failure caused by acts of nature and disasters beyond control of CKD.

The warranty stated herein covers only the delivered product itself. Any loss or damage induced by failure of the delivered product is excluded from this warranty.

Note: For details on the durability and consumable parts, contact your nearest CKD sales office.

3 Compatibility check

The customer is responsible for confirming the compatibility of CKD products with the customer's systems, machines





Safety precautions

WP Series: Warnings and Cautions

Be sure to read this section before use.

Refer to "Air Preparation Unit/Auxiliary components (RJ-007)" for general and product-specific precautions.

Product-specific cautions: FRL pressure gauge (Outdoor Series)

*For product-specific cautions other than those below, refer to Safety Precautions of the F.R.L. unit (modular design) and F.R.L. unit (compact type) in "Air Preparation Unit / Auxiliary Components (No. RJ-007AA)".



WARNING

Design / Consideration

- This product is for industrial use. Do not use for medical purposes, or in any equipment or circuit that concerns human life.
- Be sure to attach a safety device where output pressure exceeding the regulator's set pressure value will cause damage or malfunction of the secondary side equipment.

Working environment

- This product has outdoor specifications, but should not be used in the following environments.
- · When ambient temperature exceeds the specifications. (The product temperature is at risk of exceeding the ambient temperature when exposed to direct sunlight.)
- · When air freezes.
- · In atmospheres containing corrosive gases, liquids and chemicals.
- · Locations with vibration or impact.

■Precautions for use in cold climates

When using this product in a cold climate, take the necessary measures to prevent freezing.

Freezing can cause leakage or operation failure. Conduct appropriate dew point management of air quality.

Use / Maintenance

Do not disassemble the filter/regulator or regulator cover.



CAUTION

Design / Selection

Use the auto-drain under the working conditions below. This may cause malfunction.

NO auto-drain (exhaust without pressurized): For "F"

- · Use a compressor with a capacity of 0.75 kw {90 L/min [ANR]} or more.
- \cdot Set the working pressure to 0.1 MPa or more. (Air is purged with initial drainage until pressure reaches 0.1 MPa.)

NC auto-drain (no exhaust without pressurized) For "F1"


- ·A compressor with a capacity of 0.75 kw or less can also be used.
- · Set the working pressure to 0.15 MPa or more.
- · Set the working flow to less than the max. working flow.
- · Avoid use of this in places with high vibration, such as where a compressor is installed, because air could leak from the drain outlet when the float vibrates.
- · Avoid drain overflow, which may lead to malfunctions.

Use / Maintenance

- Except when adjusting the pressure, tighten the hex nut and secure the adjusting screw.Please. (Use without tightening may lead to damage.)
- Do not apply a load to the product unless it is within the parameters of use. (Do not climb/step onto the product.)
- •Using the regulator with the cover facing downward may cause the pressure regulation to fail due to freezing. It is possible. Be especially careful in low-temperature environments.
- The set pressure changes from the initial set point due to the working environment and conditions, as well as aging of part materials. Check the pressure regularly, and reset if conditions have changed.
- Perform regular maintenance every six months to one year.
- Consumable parts (metal bowl assembly, valve assembly, bottom spring, element, mantle assembly,
 O-rings) should be replaced every other year. Contact a CKD sales representative for details regarding consumable parts.
- When the set pressure is high, the operating force for rotating the adjusting screw (knob) will increase.

Working fluids

•Use only compressed air. Air containing corrosive gases, fluids or chemicals could result in improper pressure adjustment due to body damage or rubber deterioration.




Outdoor Series



CAUTION

Other

- This product guarantees outdoor use, but not corrosion resistance (no rust or discoloration).
- Fix the hex side of the adaptor nut before screwing the fitting, etc., into the drain outlet of the auto-drain with metal cup. If the hex side of the adaptor nut is not fixed, the product may break due to excessive screw-in of the adaptor nut. When using the metal bowl with auto-drain, if the drain is piped with a tightening fitting, manual operation is not possible.
- Piston drain uses automatic discharge for intermittent flow. Drainage is not discharged under working conditions where air flows constantly.




3-year warranty after delivery (Option G)

When ordering the above options, we will prepare a specification sheet with the following information. Please fill in the date of commencement of use, sign it, and return it to us through the supplier. Please indicate the date of commencement of use to within 3 years from the date of delivery.

Scheduled date of service life: / / _____sign Warranty period: The warranty provided is 3 years from the date of delivery or 1 year from initial use, whichever comes first.

- *Please return the specification sheet after entering the scheduled start date. The warranty for 3 years will not apply if there is no indication or no return.
- *Includes inspection certificate, inspection guidelines, drawings, specifications, traceability system diagram



*Chart shows case of 2 years of storage and 1 year of use.

Related products

Outdoor products WP Series

Proven durability for outdoor use


Accelerated weathering test: 3-year acceleration or equivalent

Compound cycle test: Equivalent to 7-year acceleration

Ozone exposure test: 400 hours

- Lineup of products compatible with min. ambient temperature -20°C
- Each product has a maximum warranty of 3 years

Catalog No.CC-1276A



The goods and/or their replicas, the technology and/or software found in this catalog are subject to complementary export regulations by Foreign Exchange and Foreign Trade Law of Japan. The law requires a license from Ministry of Economy, Trade and Industry to export them.



[Website] https://www.ckd.co.jp/en/

Head Office • Plant Tokyo Office

Osaka Office

2-250, Ouji, Komaki, Aichi 485-8551 4F, Bunkahousou Media Plus, 1-31-1, Hamamatsu-cho, Minato-ku, Tokyo 105-0013 6F, PMO EX Shin-Osaka, 4-2-10 Miyahara, Yodogawa-ku, Osaka 532-0003

TEL(0568)77-1111 F TEL(03)5402-3620 F

FAX(0568)77-1123 FAX(03)5402-0120

TEL(06)6396-9630 FAX(06)6396-9631