Displacement at point A

[Displacement of table due to M1 moment]

Displacement at the table end when load (F1) is applied to the table end



LCR-6(M1)



LCR-8(M1)



LCR-12(M1)



LCR-16(M1)



LCR-20(M1)



LCR-25(M1)



Displacement at point A

[Displacement of table due to M2 moment]

Displacement at the table end (point A) when load (F2) is applied to a point L mm away from the center of the cylinder



L value
ø 6: L= 70, ø 8: L= 70
ø12: L= 90, ø16: L=100
ø20: L=100, ø25: L=200

LCR-6(M2)



LCR-8(M2)



LCR-12(M2)



LCR-16(M2)



LCR-20(M2)



LCR-25(M2)



Displacement at point A

[Displacement of table due to M3 moment]

Displacement angle of the table when rotation moment (M3) is applied to the cylinder



LCR-6(M3)



LCR-8(M3)



LCR-12(M3)



LCR-16(M3)



LCR-20(M3)



LCR-25(M3)